

Timever L6615E

Timever Kids Digital Watch L6615E Instruction Manual

Your guide to setting up, operating, and maintaining your Timever L6615E Kids Digital Watch.

[Setup](#)[Operating
Instructions](#)[Maintenance
Warranty &
Support](#)[Troubleshooting](#)[Specifications](#)

1. SETUP

1.1 Initial Charging

Before first use, fully charge your Timever L6615E Kids Digital Watch. The watch features a convenient USB interface for charging. Simply connect the included charging cable to the watch's charging port and plug the USB end into any standard USB adapter (e.g., smartphone adapter, computer USB port).

A full charge typically takes approximately 2 hours and provides over 15 days of battery life, reducing the need for frequent recharging.



Image: The Timever L6615E Kids Digital Watch being charged via its magnetic USB cable, highlighting its long battery life and convenient charging method.

1.2 Setting Time and Date

To set the time and date, press and hold the main button (usually on the side) until the display flashes. Use short presses to adjust the hour, minute, month, day, and year. Press and hold again to confirm each setting and move to the next. Refer to the small instruction leaflet included in the packaging for detailed button functions.

2. OPERATING INSTRUCTIONS

2.1 Basic Navigation

The Timever L6615E watch features a clear LED display. Press the main button to cycle through different modes: Time, Date, Pedometer (steps), Calories burned, Mileage, Alarm Clock, and Stopwatch. The display will show the current mode's information.



Image: A visual representation of the watch's multi-functional display, showcasing icons for its various features like time, date, pedometer, and alarm.

2.2 Fitness Tracker (Pedometer, Calories, Mileage)

This watch functions as a kids' fitness tracker without requiring a mobile phone connection or app. Simply wear the watch to automatically monitor steps, manage calories burned, and track exploration mileage. The breathable silicone strap ensures comfort during physical activity.



Image: A child actively engaged in sports, wearing the Timever L6615E Kids Digital Watch, demonstrating its fitness tracking capabilities.

2.3 Alarm Clock

The watch allows for setting two silent vibration alarms. This feature helps children manage their daily schedule, including study time, rest, or water breaks, without disturbing others in quiet environments like classrooms or libraries. To set an alarm, navigate to the alarm mode and use the buttons to adjust the desired time.

Gentle Vibration Alarm Clock



Image: A child sleeping with the watch, highlighting the silent vibration alarm feature for gentle wake-ups or reminders.

2.4 Stopwatch

To use the stopwatch function, navigate to the stopwatch mode. Press the main button once to start the timer and again to pause it. A long press will reset the stopwatch.

2.5 Product Overview Video

Watch this video for a quick overview of the Timever Kids Digital Watch features.

Your browser does not support the video tag.

Video: A short video showcasing the various functions and benefits of the Timever Kids Digital Watch for boys and girls.

3. MAINTENANCE

3.1 Water Resistance

The Timever L6615E Kids Digital Watch is designed with daily waterproofing. It can withstand hand washing, splashing, and rain. However, it is not suitable for full immersion in water, such as swimming or bathing. Avoid

wearing the watch during these activities to prevent damage.



Image: The watch being worn during hand washing, illustrating its daily waterproof capabilities and limitations.

3.2 Cleaning

To clean the watch, wipe it gently with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the display or strap.

3.3 Battery Care

For optimal battery longevity, if the watch is not used for an extended period, it is recommended to recharge it every three months.

3.4 Waterproofing and Features Video

Learn more about the watch's upgraded waterproof design and other features.

Your browser does not support the video tag.

Video: A detailed video highlighting the upgraded waterproof features and various digital functionalities of the kids' watch.

4. TROUBLESHOOTING

4.1 Watch Not Turning On

Ensure the watch is fully charged. If it still doesn't turn on, try connecting it to a different USB power source or cable.

4.2 Incorrect Time/Date

Follow the instructions in Section 1.2 to reset the time and date. If the settings do not save, ensure the battery is sufficiently charged.

4.3 Pedometer Inaccuracy

The pedometer uses motion sensors. For best accuracy, ensure the watch is worn snugly on the wrist. Extreme arm movements unrelated to walking may affect step count.

4.4 Charging Issues

Verify that the charging cable is securely connected to both the watch and the USB power source. Check for any debris in the charging port. If the watch is not used for a long time, it may take a few minutes for the charging indicator to appear.

4.5 Water Damage

If the watch has been exposed to water beyond its daily waterproof limits (e.g., swimming or bathing), dry it immediately and do not attempt to charge or operate it. Contact customer support for assistance.

5. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	L6615E
Brand	Timever
Special Feature	Activity Tracker, Alarm Clock, Lightweight, Time Display
Connectivity Technology	USB
Wireless Communication Standard	Bluetooth (for internal functions, no app needed)
Shape	Square
Target Audience	Unisex Kids
Display Type	Digital
Band Material Type	Silicone
Case Material Type	Acrylonitrile Butadiene Styrene (ABS)
Water Resistance Level	Waterproof (Daily use, not for swimming/bathing)
Water Resistance Depth	50 Meters (for daily activities, not immersion)

Human Interface Input	Buttons
Clasp Type	Deployant Clasp
Supported Application	Fitness Tracker, Pedometer (built-in, no external app)
Metrics Measured	Distance
Item Weight	0.09 Kilograms
Band Length	7.6 Inches
Resolution	240 x 240

6. WARRANTY & SUPPORT

The Timever L6615E Kids Digital Watch comes with a limited warranty. For specific details regarding warranty coverage, please refer to the documentation included with your product or contact Timever customer support. If you encounter any issues or have questions not covered in this manual, please reach out to our customer support team for assistance. Contact information can typically be found on the product packaging or the official Timever website.

6.1 Lifestyle and Usage Video

See how the Timever Kids Digital Watch integrates into daily activities for exercise, play, and fashion.

Your browser does not support the video tag.

Video: A video demonstrating the Timever Kids Digital Watch being used during various activities, highlighting its versatility for exercise, play, and as a stylish accessory.