

## Tesla AF701BX

# Tesla AF701BX Air Fryer User Manual

Model: AF701BX

## INTRODUCTION

Thank you for purchasing the Tesla AF701BX Air Fryer. This appliance is designed to provide a healthy and efficient way to cook your favorite meals with little to no oil. Please read this manual carefully before using the appliance to ensure safe and optimal operation. Keep this manual for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before use.
- Do not immerse the main unit in water or any other liquid.
- Ensure the voltage indicated on the appliance matches your local mains voltage.
- Keep the appliance out of reach of children.
- Do not operate any appliance with a damaged cord or plug.
- Always unplug the appliance when not in use and before cleaning.
- Do not place the appliance against a wall or other appliances. Leave at least 10 cm free space on the back and sides and 10 cm free space above the appliance.
- Hot air is released through the air outlet vents. Keep your hands and face at a safe distance from the steam and air outlet openings.
- Do not touch hot surfaces. Use handles or knobs.
- Never use the appliance for any purpose other than described in this manual.

## PRODUCT OVERVIEW

### Components

- Main Unit

- Removable Frying Basket
- Digital Touchscreen Control Panel
- Air Inlet
- Air Outlet Vents
- Power Cord

## Control Panel

The Tesla AF701BX features an intuitive digital touchscreen for easy operation. Refer to the image below for a visual guide to the control panel functions.



Figure 1: Tesla AF701BX Air Fryer with its digital touchscreen control panel. The panel displays temperature, time, and various preset cooking icons.

- **Power Button:** Turns the appliance on/off.
- **Temperature Control (+/-):** Adjusts cooking temperature (60°C to 200°C).
- **Time Control (+/-):** Adjusts cooking time (up to 60 minutes).

- **Preset Programs:** 12 pre-set cooking functions for common dishes.
- **Preheat:** Initiates a preheating cycle.
- **Start/Pause:** Starts or pauses the cooking process.
- **Stop/Cancel:** Stops the current cooking program.
- **Turn Reminder:** Alerts you to shake or turn food during cooking.

## SETUP

---

1. **Unpack:** Carefully remove all packaging materials and any promotional labels from the air fryer.
2. **Clean:** Before first use, wash the frying basket with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth.
3. **Placement:** Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is adequate air circulation around the appliance (at least 10 cm clearance on all sides).
4. **Power Connection:** Plug the power cord into a grounded wall outlet.

## OPERATING INSTRUCTIONS

---

### General Operation

1. **Prepare Food:** Place your ingredients into the frying basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the frying basket back into the air fryer until it clicks into place.
3. **Power On:** Press the Power button to turn on the appliance. The digital display will illuminate.
4. **Select Settings:**
  - **Manual Setting:** Use the Temperature (+/-) and Time (+/-) buttons to set your desired cooking temperature (60-200°C) and time (1-60 minutes).
  - **Preset Program:** Select one of the 12 pre-set cooking icons for common dishes. The appliance will automatically set the recommended temperature and time. You can adjust these settings manually if needed.
5. **Preheat (Optional):** For best results, especially with certain foods, press the "Preheat" button before adding food. The air fryer will heat to the set temperature and notify you when ready.
6. **Start Cooking:** Press the "Start" button to begin the cooking process.
7. **Turn Reminder:** During cooking, the "Turn Reminder" icon may illuminate, accompanied by a beep, indicating that the food should be shaken or turned for even cooking. Carefully pull out the basket, shake or turn the food, and reinsert the basket. Cooking will resume automatically.
8. **Completion:** Once the cooking time has elapsed, the air fryer will beep and automatically shut off.
9. **Remove Food:** Carefully pull out the frying basket using the handle. Use heat-resistant tongs to remove the cooked food.
10. **Power Off:** Press the Power button to turn off the appliance, or it will automatically enter standby mode after a period of inactivity.



Figure 2: The Tesla AF701BX Air Fryer with its removable basket partially pulled out, demonstrating how food is placed inside for cooking.

## MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

- 1. Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
- 2. Clean Frying Basket:** The frying basket is dishwasher-safe. Alternatively, wash it with hot water, dish soap, and a non-abrasive sponge. For stubborn food residue, soak the basket in warm, soapy water for about 10 minutes before cleaning.
- 3. Clean Interior:** Wipe the inside of the appliance with a damp cloth. Do not use abrasive cleaners or steel wool.

- Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth.
- Heating Element:** If necessary, gently clean the heating element with a soft brush to remove any food residue.
- Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Power outlet is not working.	Ensure the power cord is securely plugged into a grounded outlet. Test the outlet with another appliance.
Food is not cooked evenly.	Basket is overcrowded. Food was not shaken/turned.	Cook food in smaller batches. Shake or turn food halfway through cooking, especially when prompted by the "Turn Reminder".
White smoke coming from the appliance.	Grease residue from previous use. Fatty ingredients being cooked.	Clean the basket and interior thoroughly after each use. For very fatty foods, you may need to drain excess fat during cooking.
Food is not crispy.	Too much moisture in food. Not enough oil (if applicable). Temperature too low or time too short.	Pat food dry before air frying. Lightly spray or brush food with oil. Increase temperature or cooking time.

## SPECIFICATIONS

<b>Brand:</b>	Tesla
<b>Model Number:</b>	AF701BX
<b>Capacity:</b>	7 Liters
<b>Power/Wattage:</b>	1700 Watts
<b>Temperature Range:</b>	60°C to 200°C
<b>Timer:</b>	Up to 60 minutes
<b>Control Method:</b>	Touchscreen
<b>Material:</b>	Stainless Steel
<b>Product Dimensions:</b>	36 x 32 x 38 cm (D x W x H)
<b>Special Features:</b>	Automatic shut-off, Programmable, Temperature control, Timer

## WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the documentation provided with your purchase or contact Tesla customer service directly. Keep your proof of purchase for any warranty claims.

For further assistance or to report issues, please visit the official Tesla support website or contact their customer service hotline.