



Manuals.plus /

› deime /

› DEIME 3 Quart Digital Air Fryer User Manual

deime 3 Quart Digital Air Fryer

DEIME 3 Quart Digital Air Fryer User Manual

Model: B0DPK89WV2

INTRODUCTION

Thank you for purchasing the DEIME 3 Quart Digital Air Fryer. This appliance is designed to provide a convenient and healthy way to cook a variety of meals with less oil. Please read this manual thoroughly before operation to ensure safe and efficient use of your new air fryer.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the basket is properly inserted before operating.
- Do not block any ventilation openings.

PRODUCT OVERVIEW

Familiarize yourself with the components of your DEIME Air Fryer.



Figure 1.1: The DEIME 3 Quart Digital Air Fryer with its basket containing fries and a toast rack accessory. This image highlights the compact design and the digital control panel.



Figure 1.2: Dimensions of the DEIME Air Fryer, showing its compact footprint suitable for small spaces. The image also illustrates the precise time and temperature control features.



Figure 1.3: The air fryer demonstrating its capacity to cook a whole chicken, emphasizing its suitability for single servings or small meals.



Figure 1.4: Illustrates the healthy cooking benefits of the air fryer, including reduced fat, crispy results, and efficient 360-degree air circulation for quick cooking.

Key Components:

- **Digital Touch Screen:** For setting time and temperature.
- **Air Inlet:** Located at the top of the unit.
- **Air Outlet Vent:** Located at the back of the unit.
- **Removable Basket:** 3-quart capacity, non-stick, dishwasher safe.
- **Basket Handle:** For safe removal of the basket.
- **Toast Rack:** Included accessory for versatile cooking.

1. **Unpacking:** Carefully remove all packaging materials and accessories.
2. **Cleaning:** Before first use, clean the basket and toast rack with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space on the back and sides, and 10 cm (4 inches) above the appliance to allow for proper air circulation.
4. **Power Connection:** Plug the power cord into a grounded wall outlet.

OPERATING INSTRUCTIONS

Preheating the Air Fryer:

1. Plug in the air fryer.
2. Press the power button to turn on the display.
3. Set the desired temperature (e.g., 375°F) and time (e.g., 5 minutes) using the temperature and time control buttons.
4. Press the start button to begin preheating. The air fryer will indicate when preheating is complete.

Cooking with the Air Fryer:

1. After preheating (or if not preheating), pull out the basket from the appliance.
2. Place your ingredients into the basket. Do not overfill the basket to ensure even cooking.
3. Slide the basket back into the air fryer.
4. Set the desired temperature (up to 400°F) and cooking time (up to 60 minutes) using the digital touch screen controls.
5. Press the start button to begin cooking.
6. Some foods may require shaking or tossing halfway through the cooking process. Pull out the basket, shake the contents, and reinsert the basket. The air fryer will resume cooking automatically.
7. When the cooking time is complete, the air fryer will beep. Carefully pull out the basket and remove the cooked food.



Figure 2.1: Example of food cooked in the air fryer, demonstrating the ability to cook frozen items to a crispy finish in minutes.



Figure 2.2: The air fryer positioned on a kitchen counter, showcasing its compact size and versatility for preparing various meals.

MAINTENANCE

Cleaning:

Clean the air fryer after every use.

- Unplug the appliance and allow it to cool down completely before cleaning.
- The basket and toast rack are dishwasher safe. Alternatively, they can be washed with hot water, dish soap, and a non-abrasive sponge.
- Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads.
- Clean the heating element with a cleaning brush to remove any food residue.
- Ensure all parts are thoroughly dry before storing or next use.

Storage:

Store the air fryer in a cool, dry place. Ensure the power cord is neatly wrapped and secured.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in.	Ensure the power cord is securely plugged into a grounded outlet.
Food is not cooked evenly.	Basket is overfilled; food not shaken.	Do not overfill the basket. Shake or toss ingredients halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and heating element thoroughly. For fatty foods, absorb excess oil before cooking.
Food is not crispy.	Too much moisture; not enough oil (for certain foods).	Pat food dry before air frying. Lightly coat with oil if desired for extra crispiness.

SPECIFICATIONS

Model: B0DPK89WV2

Capacity: 3 Quarts

Power: 900 Watts

Voltage: 120V~60Hz

Temperature Range: Up to 400°F

Timer: Up to 60 minutes

Dimensions (L x W x H): 20.32 x 26.42 x 20.83 cm (8 x 10.4 x 8.2 inches)

Weight: 3.08 kg (6.79 lbs)

Material: Stainless Steel (housing), Non-stick (basket)

Special Features: Digital Touch Screen, Dishwasher Safe Basket, Stain Resistant

WARRANTY AND SUPPORT

DEIME products are manufactured to the highest quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official DEIME website.

Please retain your proof of purchase for warranty claims.

