

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Run Bison](#) /

> [Run Bison 18W LED Emergency Driver Instruction Manual](#)

Run Bison RBHV18W-EM-170V

Run Bison 18W LED Emergency Driver Instruction Manual

Model: RBHV18W-EM-170V-4PK

1. INTRODUCTION

The Run Bison 18W LED Emergency Driver is designed to provide emergency illumination for LED light fixtures during a power outage. This driver ensures a minimum of 90 minutes of illumination, making it suitable for various commercial lighting applications. It is UL listed, ensuring compliance with safety standards.

This emergency driver is compatible with LED commercial lights with an input power between 10W and 150W that feature a 0-10V dimming function. It also supports 10W-16W LED lights without a 0-10V dimming function. The unit includes a test switch/pilot light for monitoring system operation.

2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- Installation must be performed by a qualified electrician in accordance with national and local electrical codes.
- Ensure power is disconnected at the circuit breaker before installation or servicing.
- Do not use this device with incompatible lighting fixtures or outside its specified voltage range.
- The emergency driver contains a rechargeable battery. Do not expose to fire or extreme temperatures.
- Dispose of batteries properly according to local regulations.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- LED Emergency Backup Driver
- Installation accessories (e.g., test switch/pilot light, wiring connectors)

4. SPECIFICATIONS

Feature	Specification
---------	---------------

Feature	Specification
Brand	Run Bison
Model Number	RBHV18W-EM-170V-4PK
Product Dimensions	13.6 x 1.6 x 1 inches
Input Voltage	AC 100-277V
Output Voltage	DC 150-270V
Wattage	18 watts
Emergency Time	Over 90 minutes
Charging Time	24 hours for full charge
Max Input Current	120mA
Average Life	50,000 Hours
Operating Temperature	41°F to 122°F (5°C to 50°C)
Certifications	UL Certified
Material	Metal

5. SETUP AND INSTALLATION

Before installation, ensure the main power supply to the fixture is turned off at the circuit breaker.

5.1 Product Overview



>24 Hours
Charging Time



90 Minutes
Backup



18W
Output Power



120mA
Max Input Current



100-277V



0-10V
Dimming



Image: The 18W LED Emergency Driver unit, highlighting its key features such as 24+ hours charging time, 90 minutes backup, 18W output power, 120mA max input current, 100-277V compatibility, and 0-10V dimming capability.

5.2 Dimensions



Image: A diagram showing the physical dimensions of the emergency LED driver (13.6 inches long, 1.6 inches wide, 1 inch high) and the separate LED indicator test switch.

5.3 Wiring Diagram




Image: A detailed wiring diagram illustrating connections for the emergency LED driver, normal LED driver, LED module, dimmer, and test switch. It shows AC line (red), Neutral (white), AC line switch (black), Ground (green), Dimmer (purple/pink), and connections to the emergency driver (gray/orange) and normal LED driver (brown/blue).

1. **Connect AC Power:** Connect the AC line (red wire) and Neutral (white wire) from the building's power supply to the corresponding inputs on the emergency driver.
2. **Connect to AC Line Switch:** Connect the AC line switch (black wire) to the designated input on the emergency driver.
3. **Ground Connection:** Ensure the ground wire (green wire) is properly connected to a suitable ground.
4. **Dimmer Connections (if applicable):** If using a 0-10V dimmable fixture, connect the dimmer's purple (+) and pink (-) wires to the corresponding Dim+ and Dim- terminals on the emergency driver.
5. **Connect to LED Module:** Connect the emergency driver's output wires (gray and orange) to the LED module. Ensure correct polarity.
6. **Connect to Normal LED Driver:** Connect the emergency driver to the normal LED driver using the brown (L) and blue (N) wires as indicated.
7. **Install Test Switch/Pilot Light:** Mount the test switch/pilot light in an accessible location and connect its wires to

the emergency driver as per the diagram.

5.4 Compatible Lighting Fixtures



- **18W-300W (0-10V dimmable fixture)**
- **≤ 17W (Without dimming function)**

Image: The emergency LED driver shown alongside various commercial lighting fixtures, indicating compatibility with 18W-300W (0-10V dimmable fixtures) and ≤17W (without dimming function) LED lights.

5.5 Application Examples



LED Panel Light



LED High Bay Light



LED Troffer Light



LED Wrap Light

Image: A collage of commercial environments demonstrating the wide application of the emergency LED driver with different light types, including LED Panel Light, LED High Bay Light, LED Troffer Light, and LED Wrap Light.

6. OPERATING INSTRUCTIONS

6.1 Normal Operation

When AC power is present, the emergency driver charges its internal battery. The pilot light on the test switch will illuminate, indicating that the battery is charging and the system is ready for emergency operation.

6.2 Emergency Mode

Upon loss of normal AC power, the emergency driver automatically switches to emergency mode, providing power to the connected LED fixture for over 90 minutes. The pilot light on the test switch will typically turn off or change color to indicate emergency operation.

6.3 Rest Mode

To conserve battery life during storage or extended periods without AC power, the emergency driver can be put into 'Rest

Mode'. Press and hold the test switch for more than 3 seconds while in emergency mode to activate this feature. In rest mode, the leakage current is significantly reduced, extending the battery's storage time.

6.4 Testing the System

Press the test switch briefly to simulate a power outage and verify that the emergency lighting system is functioning correctly. The connected LED fixture should illuminate in emergency mode. Release the button to return to normal operation.

7. MAINTENANCE

Regular maintenance ensures the longevity and reliability of your emergency LED driver.

- **Initial Charge:** Allow the unit to charge for at least 24 hours after initial installation to ensure the battery is fully charged and ready for emergency use.
- **Monthly Testing:** Conduct a monthly 30-second test using the test switch to ensure the emergency function is operational.
- **Annual Testing:** Perform an annual 90-minute discharge test. Disconnect AC power to the unit and allow it to operate in emergency mode for the full 90 minutes. Reconnect AC power and allow the battery to recharge for 24 hours.
- **Battery Replacement:** The internal battery is designed for a long life, but its capacity will diminish over time. If the unit fails to provide 90 minutes of emergency illumination during the annual test, the battery may need replacement. Contact a qualified technician for service.
- **Cleaning:** Keep the unit clean and free from dust. Use a dry cloth for cleaning. Do not use liquid cleaners.

8. TROUBLESHOOTING

If you encounter issues with your emergency LED driver, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
LED fixture does not illuminate in emergency mode.	No AC power to the unit; Battery not charged; Faulty wiring; Damaged battery.	Check AC power supply. Allow 24 hours for initial charge. Verify all wiring connections. If problem persists, contact support.
Emergency illumination lasts less than 90 minutes.	Battery not fully charged; Battery nearing end of life.	Ensure unit has charged for 24 hours. If issue persists after full charge, battery may need replacement.
Pilot light on test switch is off during normal operation.	No AC power; Faulty wiring to test switch; Faulty test switch.	Check AC power. Verify test switch wiring. Replace test switch if necessary.
Unit does not enter Rest Mode.	Test switch not held long enough; Unit not in emergency mode.	Ensure unit is in emergency mode (AC power off) and hold test switch for more than 3 seconds.

If troubleshooting steps do not resolve the issue, please contact customer support.

9. WARRANTY AND SUPPORT

9.1 Warranty

This Run Bison LED Emergency Driver is covered by a **5-year manufacturer's warranty** from the date of purchase. This

warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by improper installation, misuse, abuse, or acts of nature.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Run Bison LED Emergency Driver, please contact Run Bison customer support. Refer to your purchase documentation or the manufacturer's website for contact information.