



Manuals.plus /

› Necchi /

› Necchi NK815DT 5L 1400W Air Fryer Instruction Manual

Necchi NK815DT

Necchi NK815DT 5L 1400W Air Fryer Instruction Manual

Model: NK815DT

INTRODUCTION

Thank you for choosing the Necchi NK815DT 5L 1400W Air Fryer. This appliance is designed to provide a healthier way to cook your favorite meals, using hot air circulation to achieve crispy results with little to no oil. Please read this manual carefully before using the appliance and keep it for future reference.



Figure 1: Necchi NK815DT Air Fryer with digital display and transparent window, showing food cooking inside.

SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

PRODUCT OVERVIEW

The Necchi NK815DT Air Fryer features a compact design with a user-friendly interface. Familiarize yourself with its components for optimal use.



Figure 2: Necchi NK815DT Air Fryer with the cooking basket pulled out, revealing a perfectly cooked whole chicken inside.

Main Components:

- **Digital Touch Panel:** For setting temperature, time, and selecting pre-set programs.

- **Cooking Basket (5L capacity):** Removable basket with non-stick coating for food.
- **Removable Non-stick Grill:** Sits inside the basket for optimal air circulation and easy cleaning.
- **Transparent Window:** Allows monitoring of cooking progress without opening the basket.
- **Handle:** For safely pulling out and inserting the cooking basket.
- **Air Outlet:** Located at the back of the appliance for hot air release.

SETUP

Before first use, follow these steps:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Clean the cooking basket and the removable grill thoroughly with hot water, some dishwashing liquid, and a non-abrasive sponge.
3. Wipe the inside and outside of the appliance with a damp cloth.
4. Place the appliance on a stable, horizontal, and level surface. Do not place the appliance on non-heat-resistant surfaces.
5. Ensure there is at least 10 cm of free space on the back and sides of the appliance and 10 cm above it.

OPERATING INSTRUCTIONS

The Necchi NK815DT Air Fryer features a digital touch panel for easy operation.

Control Panel Functions:

- **Power Button:** Turns the appliance on/off.
- **Temperature Control:** Adjusts temperature from 80°C to 200°C.
- **Timer Control:** Sets cooking time up to 60 minutes.
- **Pre-set Programs:** 7 dedicated icons for common dishes (fries, cutlets, shrimp, chicken, steak, cake, fish).
- **Start/Pause Button:** To begin or temporarily stop cooking.

Using Pre-set Programs:

1. Place food in the cooking basket.
2. Press the Power Button to turn on the air fryer.
3. Select one of the 7 pre-set program icons. The appliance will automatically set the optimal temperature and time for that dish.
4. Press the Start/Pause Button to begin cooking.

Manual Settings:

1. Place food in the cooking basket.
2. Press the Power Button to turn on the air fryer.
3. Use the Temperature Control buttons to set your desired temperature (80°C - 200°C).
4. Use the Timer Control buttons to set your desired cooking time (up to 60 minutes).
5. Press the Start/Pause Button to begin cooking.

You can monitor the cooking process through the transparent window. The auto-shutoff feature ensures

safety once the timer completes.

Video: Cecofry Neon 5000 Overview

This video provides a general overview of a similar air fryer model, demonstrating the control panel and basket usage. Note that specific features may vary slightly.

Video: Using Parchment Paper in Air Fryer

This video demonstrates the use of parchment paper liners in an air fryer, which can help with cleaning and prevent food from sticking.

COOKING GUIDE

Here are some general guidelines for cooking various foods in your Necchi NK815DT Air Fryer. Cooking times and temperatures may vary based on food quantity, thickness, and desired crispiness.

Food Item	Temperature	Time	Notes
Frozen Fries	180°C	15-20 min	Shake basket halfway through.
Fresh Chicken Breast	180°C	18-22 min	Flip halfway through.
Fish Fillets	170°C	12-15 min	Brush with oil for extra crispiness.
Vegetables (e.g., broccoli, bell peppers)	160°C	10-15 min	Toss with a little oil and seasoning.

Examples of Cooked Dishes:



Crispy chicken strips cooked in the air fryer.



Fish and chips prepared with the air fryer.



Golden fried calamari rings.



Perfectly cooked chicken drumsticks with salad.

MAINTENANCE AND CLEANING

Regular cleaning will ensure the longevity and optimal performance of your air fryer.

1. Always unplug the appliance and allow it to cool down completely before cleaning.
2. Clean the cooking basket and the removable grill with hot water, dishwashing liquid, and a non-abrasive sponge. These parts are also dishwasher safe.
3. Wipe the exterior of the appliance with a damp cloth. Do not use abrasive cleaning agents or scouring pads.
4. Clean the interior of the appliance with a non-abrasive sponge and warm water.
5. Never immerse the main unit in water or any other liquid.

TROUBLESHOOTING

If you encounter any issues with your Necchi NK815DT Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; Power button not pressed.	Ensure the power cord is securely plugged into a working outlet; Press the Power button.
Food is not cooked evenly.	Too much food in the basket; Food not shaken/flipped.	Cook in smaller batches; Shake or flip food halfway through cooking.
Food is not crispy.	Insufficient cooking time/temperature; Not enough oil (for some foods).	Increase cooking time or temperature; Lightly brush food with oil.
White smoke coming from the appliance.	Grease residue from previous use; Fatty food being cooked.	Clean the basket and grill thoroughly; This is normal for fatty foods.

SPECIFICATIONS

- **Brand:** Necchi
- **Model:** NK815DT
- **Capacity:** 5 Liters
- **Wattage:** 1400 Watts
- **Voltage:** 220 Volts
- **Temperature Range:** 80°C - 200°C
- **Timer:** Up to 60 minutes
- **Material:** Metal and heat-resistant plastic
- **Special Features:** 7 pre-set programs, auto-shutoff, removable non-stick basket, transparent viewing window.
- **Product Dimensions:** 32.6 x 27 x 32.1 cm
- **Item Weight:** 3.7 Kilograms

WARRANTY AND SUPPORT

This Necchi NK815DT Air Fryer comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in the product packaging or contact Necchi customer support. For technical assistance, spare parts, or any other inquiries, please visit the official Necchi website or contact their customer service.