



[Manuals.plus](#) /

> [Rareelectrical](#) /

> Rareelectrical New Heater Core Compatible With Continental 1977-1978 By Numbers 94597 394158 398023 99017 98597 - Instruction Manual

## Rareelectrical 98597-2Z8

# Rareelectrical Heater Core Instruction Manual

Model: 98597-2Z8 | Brand: Rareelectrical

## 1. INTRODUCTION

---

This manual provides essential information for the Rareelectrical Heater Core, designed for compatible Continental models from 1977-1978. It covers product features, specifications, general installation guidelines, maintenance, and troubleshooting to ensure optimal performance and longevity. Please read this manual thoroughly before installation and use.

## 2. PRODUCT OVERVIEW

---

The Rareelectrical Heater Core is a critical component of your vehicle's heating, ventilation, and air conditioning (HVAC) system. It is responsible for transferring heat from the engine's coolant to the air circulating inside the vehicle cabin, providing warmth during colder conditions. This aftermarket heater core is engineered to offer a drop-in fit, form, and function, addressing original design failures and improving the life of high mileage vehicles.

Key features include:

- **Direct Fit Replacement:** Designed for seamless integration into compatible vehicle models.
- **Premium Grade Materials:** Constructed with high-quality materials to ensure added product longevity and durability.
- **Rigorous Testing:** Utilizes cycle, vibration, burst, and environmental state-of-the-art testing for consistent quality and reliability.
- **Improved Performance:** Engineered to enhance heating efficiency and extend the lifespan of the vehicle's heating system.




Figure 2.1: Front view of the heater core, showing the core fins and inlet/outlet pipes.




Figure 2.2: Top-down view of the heater core, highlighting the fin structure.



Figure 2.3: Side view of the heater core, showing the overall dimensions and pipe angles.




Figure 2.4: Another perspective of the heater core, possibly a different angle or detail shot.



Figure 2.5: A collage image promoting the Rareelectrical brand, showing various applications like automotive, marine, and heavy equipment.

### 3. COMPATIBILITY

---

This Rareelectrical Heater Core is compatible with Continental models manufactured between 1977 and 1978. It is designed as a direct replacement for various OEM and aftermarket part numbers. Please verify your vehicle's original part number to ensure proper fitment.

Known compatible part numbers include:

- Rareelectrical Manufacturer Part Number: 98597
- Spectra Premium: 94597
- Vista Pro: 394158, 398023
- OSC: 99017

### 4. SPECIFICATIONS

---

Specification	Detail
Manufacturer	RAREELECTRICAL
Brand	Rareelectrical
Model Number	98597-2Z8
Item Weight	4 pounds
Product Dimensions	14 x 10 x 6 inches
Country of Origin	China
ASIN	B0DQYNTCK7
Date First Available	December 19, 2024

## 5. SETUP AND INSTALLATION

---

Installation of a heater core typically involves working with the vehicle's cooling system and dashboard components. Due to the complexity and potential safety risks, **professional installation by a certified mechanic is highly recommended.**

### 5.1. Safety Precautions

- Always disconnect the vehicle's battery before beginning any work.
- Allow the engine to cool completely before working on the cooling system to avoid burns from hot coolant.
- Wear appropriate personal protective equipment (PPE), including safety glasses and gloves.
- Ensure proper ventilation when working with coolants and other automotive fluids.
- Dispose of old coolant and parts responsibly according to local regulations.

### 5.2. General Installation Steps (Consult Service Manual)

The exact steps for heater core replacement vary significantly by vehicle make and model. Always refer to your vehicle's specific service manual for detailed instructions. General steps often include:

1. Drain the engine coolant from the cooling system.
2. Access the heater core, which typically requires removal of dashboard components, glove box, or center console.
3. Disconnect heater hoses from the heater core.
4. Remove the old heater core.
5. Install the new Rareelectrical Heater Core, ensuring all connections are secure.
6. Reconnect heater hoses and other components.
7. Refill the cooling system with the appropriate coolant, bleeding air from the system as necessary.
8. Test the heating system for proper operation and check for leaks.

## 6. OPERATING THE HEATER CORE

---

The heater core operates as an integral part of your vehicle's HVAC system. Once installed, its function is largely automatic, controlled by the vehicle's climate control settings. When you select heat, hot engine coolant flows through the heater core, and a fan blows air across its fins, transferring heat into the cabin. Ensure your vehicle's cooling system is properly maintained for optimal heater core performance.

## 7. MAINTENANCE

---

Proper maintenance of your vehicle's cooling system is crucial for the longevity and efficient operation of the heater core. While the heater core itself requires minimal direct maintenance, adhering to the following practices will help ensure its optimal performance:

- **Regular Coolant Flushes:** Follow your vehicle manufacturer's recommendations for coolant flush intervals. This prevents corrosion and buildup that can clog the heater core.
- **Use Correct Coolant:** Always use the type and concentration of coolant specified by your vehicle manufacturer. Mixing incompatible coolants can lead to system damage.
- **Check for Leaks:** Periodically inspect the heater hoses and connections for any signs of leaks. Address any leaks promptly to prevent coolant loss and potential damage.
- **Monitor Coolant Levels:** Regularly check your coolant reservoir level and top up as needed. Low coolant levels can lead to poor heating performance and potential overheating.
- **Inspect Cabin Air Filter:** If your vehicle has a cabin air filter, ensure it is clean. A clogged filter can restrict airflow, impacting heating efficiency.

## 8. TROUBLESHOOTING

---

If you experience issues with your vehicle's heating system after installing the Rareelectrical Heater Core, consider the following common problems and their potential solutions:

### 8.1. No Heat or Insufficient Heat

- **Low Coolant Level:** Check the coolant reservoir and radiator. Top up with the correct coolant if low.
- **Air in Cooling System:** Air pockets can prevent hot coolant from reaching the heater core. Bleed the cooling system according to your vehicle's service manual.
- **Thermostat Malfunction:** A stuck-open thermostat can prevent the engine from reaching operating temperature, leading to cold air.
- **Clogged Heater Core:** Although new, if the rest of the system is dirty, debris can quickly clog it. A professional flush might be needed.
- **Faulty Blend Door Actuator:** The blend door controls the mix of hot and cold air. If it's stuck, you may only get cold air.

### 8.2. Coolant Leak Inside Cabin

- **Heater Core Leak:** While unlikely for a new part, inspect the heater core and its connections for any signs of leakage.
- **Loose Connections:** Ensure all hose clamps and connections to the heater core are tight and secure.

### 8.3. Fogging Windows

- **Minor Heater Core Leak:** A small leak can release coolant vapor into the cabin, causing a sweet smell and window fogging.
- **HVAC System Issues:** Ensure the defrost system is functioning correctly and that the cabin air filter is clean.

If troubleshooting steps do not resolve the issue, it is recommended to consult a qualified automotive technician.

## 9. WARRANTY AND SUPPORT

---

Rareelectrical stands behind the quality of its products. This heater core is designed for durability and reliability. For

specific warranty details, please refer to the purchase terms and conditions provided by your retailer or contact Rareelectrical directly.

Generally, products purchased may be eligible for a return or replacement within 30 days of receipt, subject to the seller's return policy.

### 9.1. Customer Support

For technical assistance, warranty claims, or any questions regarding your Rareelectrical Heater Core, please contact Rareelectrical customer support through their official website or the platform where the product was purchased. When contacting support, please have your product model number (98597-2Z8) and purchase details readily available.

You can visit the Rareelectrical Store for more information: [Rareelectrical Store](#)

© 2024 Rareelectrical. All rights reserved.

This manual is for informational purposes only. Always consult a qualified professional for vehicle repairs.