

[Manuals.plus](#) /

› [Lafocuse](#) /

› Lafocuse 5.7" LED Digital Alarm Clock User Manual

Lafocuse ZH0156

Lafocuse 5.7" LED Digital Alarm Clock User Manual

Model: ZH0156

1. INTRODUCTION

Thank you for purchasing the Lafocuse 5.7" LED Digital Alarm Clock. This versatile clock is designed to provide accurate timekeeping, temperature, and humidity readings, along with convenient alarm and charging features. Please read this manual thoroughly before use to ensure proper operation and to maximize the lifespan of your device.



Image 1.1: The Lafocuse 5.7" LED Digital Alarm Clock, showcasing its large display with time, day of the week, temperature, and humidity.

2. PRODUCT FEATURES

- **5.7-inch LED Display:** Large numbers for easy reading of time, temperature, and humidity from a distance.
- **Snooze Function:** Allows for an additional 5 minutes of sleep after the alarm sounds.
- **USB Charging Output:** Conveniently charge your phone or other devices overnight via the integrated USB port. (Note: Power adapter not included).
- **Adjustable Brightness:** Features 3 levels of brightness, with both manual adjustment and an automatic photosensitive function to prevent disturbance during sleep.
- **Dual Alarms & 3 Modes:** Set two independent alarms with flexible scheduling options: 5-day (Monday-Friday), 6-day (Monday-Saturday), or 7-day (Monday-Sunday).
- **Multi-function Display:** Shows time, date, day of the week, temperature, and humidity.



Image 2.1: Overview of the Lafocuse Digital Alarm Clock's main features.

3. PACKAGE CONTENTS

Please check the package contents upon unboxing:

- Lafocuse 5.7" LED Digital Alarm Clock (x1)
- USB Charging Cable (x1)
- User Manual (x1)

Overview



- 1 Set
- 2 Alarm
- 3 Light/Snooze
- 4 Up
- 5 Down
- 6 Battery Compartment
- 7 Type-C Input
- 8 USB Output



Charging Cable x 1

Image 3.1: The back of the alarm clock with labeled buttons and ports, and the included USB charging cable.

4. PRODUCT OVERVIEW (BUTTONS AND PORTS)

Familiarize yourself with the buttons and ports on your alarm clock:

No.	Label	Function
1	SET	Enter setting mode for time, date, and alarms.
2	ALARM	Enter alarm setting mode.
3	LIGHT/SNOOZE	Adjust brightness (short press) or activate snooze (during alarm).
4	UP	Increase value in setting mode.
5	DOWN	Decrease value in setting mode.
6	Battery Compartment	Holds backup batteries (not included).

No.	Label	Function
7	Type-C Input	Main power input for the clock.
8	USB Output	USB port for charging external devices.

5. SETUP

5.1 Powering the Device

The Lafocuse Digital Alarm Clock can be powered in two ways:

- **USB Power (Recommended):** Connect the provided USB cable to the Type-C input port (7) on the back of the clock and plug the other end into a USB power adapter (not included) or a computer USB port. When powered by USB, the display will remain continuously on.
- **Battery Power (Backup):** Insert 3 AAA batteries (not included) into the battery compartment (6). When powered by batteries, the display will turn off automatically after a few seconds to conserve power. Press any button to activate the display for 10 seconds.

2 Power Modes



6. OPERATING INSTRUCTIONS

6.1 Setting Time and Date

1. Press and hold the **SET** button (1) for 3 seconds to enter time setting mode. The hour digits will flash.
2. Use the **UP** (4) or **DOWN** (5) buttons to adjust the hour.
3. Press **SET** again to move to minute setting. Adjust minutes using **UP** or **DOWN**.
4. Continue pressing **SET** to cycle through year, month, and day settings, adjusting each with **UP** or **DOWN**.
5. After setting the day, press **SET** one last time to exit setting mode.

6.2 Setting Alarms

The clock supports two independent alarms (AL1 and AL2).

1. Press the **ALARM** button (2) to select AL1 or AL2. The alarm icon will appear.
2. Press and hold the **ALARM** button for 3 seconds to enter alarm setting mode. The alarm hour will flash.
3. Use **UP** (4) or **DOWN** (5) to adjust the alarm hour.
4. Press **ALARM** again to set the alarm minute.
5. Press **ALARM** again to select the alarm mode:
 - **LUN-FRI (5-day)**: Alarm sounds Monday to Friday.
 - **LUN-SAT (6-day)**: Alarm sounds Monday to Saturday.
 - **LUN-SUN (7-day)**: Alarm sounds every day.
6. Press **ALARM** one last time to confirm and exit.
7. To enable/disable an alarm, short press the **ALARM** button until the desired alarm (AL1 or AL2) is selected, then press **UP** or **DOWN** to toggle it on or off.

6.3 Snooze Function

When the alarm sounds, press the **LIGHT/SNOOZE** button (3) to activate the snooze function. The alarm will pause for 5 minutes and then sound again. To stop the alarm completely, press any other button on the top of the clock.

Easy Snooze for 5 Minutes



Image 6.1: Using the snooze function by pressing the large button on top of the clock.

6.4 Adjusting Brightness

The clock offers 3 levels of brightness and an automatic photosensitive mode:

- **Manual Adjustment:** Short press the **LIGHT/SNOOZE** button (3) to cycle through the 3 brightness levels (High, Medium, Low).
- **Automatic Brightness:** To activate the photosensitive function, continue pressing the **LIGHT/SNOOZE** button until the display shows 'AUTO'. In this mode, the clock will automatically adjust its brightness based on ambient light conditions.

3 Levels Brightness

Automatic & Manual



Image 6.2: The three adjustable brightness levels of the clock display.

6.5 USB Charging Port

The USB output port (8) on the back of the clock allows you to conveniently charge your smartphone or other USB-powered devices. Simply connect your device's charging cable to this port. This feature is active when the clock is powered via its main USB input.

Plug-in Alarm Clock

with USB Charging Port



Image 6.3: The alarm clock's USB output port being used to charge a smartphone.

6.6 Display Modes (Time, Date, Temperature, Humidity)

The clock can display time, date, temperature, and humidity. By default, it cycles through these displays or shows time continuously depending on the setting.

- **Switching Display:** Short press the **UP** button (4) to toggle between displaying time continuously and cycling through time, date, temperature, and humidity.
- **Temperature Unit:** In time display mode, press and hold the **DOWN** button (5) to switch between Celsius (°C) and Fahrenheit (°F).

Display Mode to Choose



Image 6.4: Switching between time and date display modes.

7. MAINTENANCE

- Clean the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the clock to extreme temperatures, direct sunlight, or high humidity.
- If not in use for an extended period, remove the batteries to prevent leakage.
- Keep the clock away from strong magnetic fields.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	No power, low batteries, or brightness set too low.	Ensure USB cable is properly connected. Replace batteries if using battery power. Adjust brightness using the LIGHT/SNOOZE button.

Problem	Possible Cause	Solution
Alarm does not sound.	Alarm is not enabled or set incorrectly.	Check if the alarm icon (AL1/AL2) is displayed. Re-set the alarm time and mode.
Time/Date is incorrect.	Time/Date not set or power interruption.	Re-set the time and date following Section 6.1. Ensure continuous USB power for uninterrupted display.
USB charging port not working.	Clock not powered by USB or device cable issue.	Ensure the clock is connected to a USB power source. Try a different charging cable or device.

9. SPECIFICATIONS

Feature	Detail
Brand	Laforcuse
Model Number	ZH0156
Color	Multi
Product Dimensions	9.8 x 3.81 x 12.9 cm (3.86 x 1.5 x 5.08 inches)
Product Weight	160 g (0.35 lbs)
Material	Plastic
Display Type	Digital LED
Power Source	USB Powered (AC adapter not included), Battery Operated (3x AAA, not included)
Special Features	Dual Alarms & 3 Modes, Adjustable Brightness, Multi-function Display, USB Charging Output

10. WARRANTY AND SUPPORT

Laforcuse products are manufactured to high-quality standards. For warranty information and customer support, please refer to the documentation provided with your purchase or contact your retailer. Keep your purchase receipt as proof of purchase for any warranty claims.