

## Juboos 24211

# Juboos Kids Digital Watch Model 24211 Instruction Manual

## INTRODUCTION

---

Thank you for choosing the Juboos Kids Digital Watch, Model 24211. This manual provides essential information for setting up, operating, and maintaining your watch. Please read these instructions carefully to ensure proper use and to maximize the lifespan of your product.

## PRODUCT OVERVIEW

---

The Juboos Kids Digital Watch is designed for children aged 7-16, offering a blend of functionality and durability. Key features include:

- **Digital Display:** Clear and easy-to-read time, date, and other functions.
- **Night Light:** Illuminates the display for visibility in low-light conditions.
- **Alarm Clock:** Programmable alarm to help with daily routines.
- **Stopwatch:** For timing activities and sports.
- **3ATM Water Resistance:** Suitable for daily use like hand washing and rain exposure.
- **Wear-resistant Structure:** Features a high-definition plexiglass mirror and a shockproof case.
- **Comfortable Design:** Soft, skin-friendly, and adjustable strap for a secure fit.



Image: Front view of the Juboos Kids Digital Watch in black.

**Press the "LIGHT"**  
**will keep the**  
**light on for 3s**



Image: The watch highlighting its multi-function capabilities including alarm, stopwatch, calendar, 12/24H display, LED light, hourly chime, 30M water resistance, and anti-shock design.

## WATCH COMPONENTS

Familiarize yourself with the buttons and display areas of your watch:





Image: Labeled diagram of the watch's buttons and display features.

- **LIGHT Button (Top Left):** Activates the backlight.
- **MODE Button (Bottom Left):** Cycles through different modes (Time, Alarm, Stopwatch).
- **START Button (Top Right):** Used to start/stop functions in Stopwatch mode, and adjust settings.
- **RESET Button (Bottom Right):** Used to reset functions in Stopwatch mode, and adjust settings.

## OPERATING INSTRUCTIONS

---

### Setting Time and Date

1. From the normal time display, press the **MODE** button three times to enter time setting mode. The seconds will flash.
2. Press the **RESET** button to set the seconds to zero.
3. Press the **START** button to move to the next setting (e.g., hour, minute, month, date, day of the week).
4. Use the **RESET** button to adjust the flashing value.
5. Repeat steps 3 and 4 until all desired settings (hour, minute, month, date, day of the week) are adjusted.
6. Press the **MODE** button once to exit setting mode and return to the normal time display.

### Using the Alarm Clock

1. From the normal time display, press the **MODE** button once to enter Alarm mode. The hour digits will flash.
2. Press the **RESET** button to adjust the hour.
3. Press the **START** button to move to the minute setting.
4. Press the **RESET** button to adjust the minute.
5. Press the **MODE** button to exit Alarm setting mode.
6. To activate/deactivate the alarm, press the **START** button while in Alarm mode. An alarm icon will appear/disappear on the display.

### Using the Stopwatch

1. From the normal time display, press the **MODE** button twice to enter Stopwatch mode.
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to clear the stopwatch to zero.
5. Press the **MODE** button to exit Stopwatch mode.

### Activating the Night Light

To illuminate the display in dark environments, simply press the **LIGHT** button located on the top left side of the watch. The light will stay on for approximately 3 seconds.

# Kids digital watch Multi-function



Alarm clock



Stopwatch



Calendar



12/24H



LED Light



Hourly Chime



30M  
Waterproof



Anti-Shock



Image: A hand pressing the 'LIGHT' button to activate the watch's backlight.

## Official Product Videos

Video: Demonstrates the Juboos youth sports digital watch features, including the night light and water resistance.

Video: Showcases the various functions of the Children's Square Sports Digital Watch.

## WATER RESISTANCE GUIDELINES

The Juboos Kids Digital Watch has a 3ATM water resistance rating. This means it is suitable for:

- Daily splashes
- Hand washing
- Rain exposure
- Sweat

### Important Precautions:

- DO NOT press any buttons while the watch is submerged in water.
- DO NOT wear the watch during bathing, showering, or swimming.
- Avoid exposure to high temperatures (e.g., hot tubs, saunas) as this can compromise the water resistance seals.



Image: Demonstrating the watch's water resistance during hand washing.

## MAINTENANCE

To keep your Juboos Kids Digital Watch in optimal condition:

- Clean the watch regularly with a soft, dry cloth.
- Avoid exposing the watch to extreme temperatures or direct sunlight for prolonged periods.
- Do not use chemical cleaners or abrasive materials on the watch.
- If the watch becomes wet, wipe it dry immediately.

## TROUBLESHOOTING

If you encounter any issues with your watch, please consider the following:

- **Display is blank or dim:** The battery may need replacement. Consult a professional watch repair service.
- **Time is inaccurate:** Re-set the time following the instructions in the 'Setting Time and Date' section.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this

model does not specify one). If the issue persists, a reset may be required (consult manufacturer support if a specific reset procedure is not provided).

## SPECIFICATIONS

Feature	Detail
Model Number	24211
Brand	Juboos
Water Resistance	3ATM (30 meters / 98 feet)
Clasp Type	Buckle
Display Type	Digital
Features	Night Light, Alarm Clock, Stopwatch, Calendar
Package Dimensions	10.39 x 2.32 x 0.75 inches
Item Weight	0.92 ounces



Image: Detailed dimensions of the watch.

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the retailer where the watch was acquired. Keep your proof of purchase for any warranty claims.