

## Radiola RADF31225W

# Radiola RADF31225W Air Fryer User Manual

Model: RADF31225W | Brand: Radiola

## IMPORTANT SAFEGUARDS

---

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before using the appliance.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.
- This appliance is for household use only.

## PRODUCT OVERVIEW

---

The Radiola RADF31225W Air Fryer is designed for healthy, oil-free cooking. Familiarize yourself with its components before use.



*Image: Front view of the Radiola RADF31225W Air Fryer. It features a white body, a silver metallic band, a black digital control panel on top, and a black handle for the removable frying basket.*

### Main Components:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Digital interface for setting temperature and time. Located on the top surface.
- **Frying Basket:** Removable basket with a non-stick coating for food. Features a handle for easy removal.
- **Air Inlet/Outlet:** For proper air circulation during operation.

### BEFORE FIRST USE

---

Before using your new air fryer for the first time, follow these steps:

1. **Unpack:** Carefully remove all packaging materials and promotional labels from the appliance.
2. **Clean:** Wash the frying basket and any removable accessories in warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 10 cm of free space at the back, sides, and above the appliance.
4. **Initial Run (Optional):** For the first use, it is recommended to run the air fryer empty for about 10-15

minutes at 180°C to burn off any manufacturing residues. A slight odor may be present, which is normal and will dissipate.

## OPERATING INSTRUCTIONS

---

Follow these steps to operate your Radiola Air Fryer:

1. **Prepare Food:** Place the ingredients you wish to air fry into the frying basket. Do not overfill the basket; ensure there is enough space for air to circulate. The maximum capacity is 2.5 liters, suitable for up to 300 grams of fries.
2. **Insert Basket:** Slide the frying basket back into the main unit until it clicks securely into place.
3. **Plug In:** Connect the power cord to a grounded wall outlet (240 Volts).
4. **Set Temperature:** Use the control panel to set the desired cooking temperature. The temperature is adjustable from 80°C to 200°C.
5. **Set Timer:** Use the control panel to set the cooking time. The timer can be set for up to 30 minutes. The appliance features an automatic shut-off function once the timer reaches zero.
6. **Start Cooking:** Press the start button on the control panel to begin the air frying process. The indicator light will illuminate, and the fan will start operating.
7. **Shake Basket (Optional):** For even cooking, especially with items like fries, pull out the basket halfway through the cooking time and gently shake its contents. Then, slide the basket back in. The air fryer will resume cooking automatically.
8. **Check Doneness:** Once the timer sounds, carefully pull out the basket and check if the food is cooked to your preference. If more cooking time is needed, slide the basket back in and set the timer for a few extra minutes.
9. **Remove Food:** Use heat-resistant tongs to remove the cooked food from the basket. Be careful of hot steam.
10. **Unplug:** After use, unplug the appliance from the wall outlet and allow it to cool down before cleaning.

### Pre-set Programs:

This air fryer includes 6 pre-set programs for common dishes. Refer to the icons on the control panel for specific program selections. These programs automatically set optimal temperature and time for various foods.

## CLEANING AND MAINTENANCE

---

Regular cleaning and maintenance will ensure the longevity and optimal performance of your air fryer.

1. **Cool Down:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Clean Basket:** The removable frying basket with its non-stick coating is dishwasher-safe. Alternatively, wash it with warm water and a mild dishwashing liquid. Use a non-abrasive sponge to avoid damaging the non-stick surface.
3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. For stubborn food residues, use a mild detergent.
4. **Clean Exterior:** Wipe the exterior of the air fryer with a soft, damp cloth. Do not use harsh abrasive cleaners or scouring pads.
5. **Storage:** Ensure all parts are clean and dry before storing the appliance. Store it in a cool, dry place.

## TROUBLESHOOTING

---

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Power outlet is not working. Overheat protection activated.	Ensure the power cord is securely plugged into a grounded outlet. Test the outlet with another appliance. Unplug the appliance and let it cool down for at least 30 minutes before plugging it back in.
Food is not cooked evenly.	Basket is overcrowded. Food was not shaken.	Reduce the amount of food in the basket. Cook in smaller batches. Shake the basket halfway through the cooking process.
White smoke comes from the appliance.	Grease residue from previous use. Fatty ingredients being cooked.	Clean the basket and interior thoroughly after each use. This is normal for fatty foods. Ensure the basket is clean.
Food is not crispy.	Too much moisture in food. Not enough oil (if applicable). Temperature too low or time too short.	Pat food dry before air frying. For some foods, a light spray of oil can enhance crispiness. Increase temperature or cooking time.

## SPECIFICATIONS

<b>Model Number</b>	RADF31225W
<b>Brand</b>	Radiola
<b>Capacity</b>	2.5 Litres
<b>Power</b>	1200 Watts
<b>Voltage</b>	240 Volts
<b>Temperature Range</b>	80°C to 200°C
<b>Timer</b>	Up to 30 minutes with automatic shut-off
<b>Material</b>	Non-stick coating (basket)
<b>Dimensions (L x W x H)</b>	30 x 28.7 x 23.5 cm
<b>Weight</b>	3 Kilograms
<b>Special Features</b>	6 pre-set programs, Overheat protection, Automatic shut-off, Dishwasher-safe basket
<b>Country of Origin</b>	China

## WARRANTY AND SUPPORT

This Radiola appliance comes with a warranty for spare parts availability for 2 years from the date of purchase.

For any support inquiries, technical assistance, or warranty claims, please contact your retailer or the official Radiola customer service.

Please retain your proof of purchase for warranty purposes.