

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RAF](#) /

› [RAF R.2862 3-in-1 Cordless Food Processor User Manual](#)

RAF R.2862

RAF R.2862 3-in-1 Cordless Food Processor User Manual

Model: **R.2862** | Manufacturer: Silver

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your RAF R.2862 Cordless Food Processor. Keep this manual for future reference.

- Always ensure the appliance is fully charged before use for optimal performance.
- Keep hands and utensils out of the processing bowl while operating to prevent injury.
- Blades are sharp. Handle with extreme care during assembly, disassembly, and cleaning.
- Do not immerse the motor base in water or any other liquid. Clean with a damp cloth only.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Ensure the lid is securely locked in place before operating the food processor.
- Do not attempt to process extremely hard foods that may damage the blades or motor.

2. PRODUCT OVERVIEW AND COMPONENTS

The RAF R.2862 is a versatile 3-in-1 cordless food processor designed for chopping, mixing, and blending various ingredients. Familiarize yourself with its components:

- **Motor Base:** Contains the powerful 200W motor and rechargeable battery.
- **Processing Bowl:** Transparent bowl for holding ingredients.
- **Lid with Feeder Tube:** Secures the bowl and allows adding ingredients during operation.
- **Pusher:** Used to guide ingredients through the feeder tube.
- **Chopping Blade Assembly:** Sharp blades for efficient chopping and blending.
- **Disc Accessory:** For slicing or grating (refer to specific disc type if included).

- **Control Switch:** On/Off and speed selection (if applicable).
- **Charging Port:** For connecting the charging cable.



Figure 2.1: Front view of the RAF R.2862 Cordless Food Processor.



Figure 2.2: Side view of the RAF R.2862 Cordless Food Processor, showing the control switch.



Figure 2.3: RAF R.2862 Cordless Food Processor with approximate dimensions.



Figure 2.4: The RAF R.2862 Cordless Food Processor shown with its packaging and an example disc accessory.

3. SETUP AND INITIAL USE

3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Remove any protective films or packaging materials.
3. Inspect the appliance for any damage. Do not use if damaged.

3.2 Initial Charging

As this is a cordless appliance, it requires charging before first use.

1. Locate the charging port on the motor base.
2. Connect the provided charging cable to the port and plug the other end into a suitable power outlet.
3. Allow the unit to charge fully. The charging indicator light (if present) will change or turn off when charging is complete. This may take several hours.

3.3 Assembly

1. Place the motor base on a clean, stable, and dry surface.
2. Carefully place the chopping blade assembly onto the central shaft inside the processing bowl. Ensure it sits firmly.
3. Place the processing bowl onto the motor base, aligning the tabs and twisting clockwise until it locks into place.
4. Place the lid onto the processing bowl, aligning the tabs and twisting clockwise until it locks securely.
The appliance will not operate unless the lid is properly locked.

3.4 First Use Cleaning

Before first use, wash all parts that will come into contact with food (processing bowl, lid, blades, pusher, discs) in warm, soapy water. Rinse thoroughly and dry completely.

4. OPERATING INSTRUCTIONS

4.1 Preparing Ingredients

- Cut large food items into smaller, uniform pieces (approximately 2-3 cm) to ensure even processing.
- Remove any hard pits, bones, or tough skins from fruits and vegetables.

4.2 Processing Food

1. Ensure the food processor is fully assembled and charged.
2. Place the prepared ingredients into the processing bowl. Do not overfill; observe the maximum fill line if indicated.
3. Securely attach the lid by twisting it clockwise until it locks.
4. If using the feeder tube for slicing/grating, place the desired disc onto the shaft before securing the lid. Then, place ingredients into the feeder tube and use the pusher to guide them.
5. Press and hold the control switch to start processing. Release to stop. For pulse action, press and release repeatedly.
6. Process until the desired consistency is achieved.
7. Once processing is complete, release the control switch. Wait for the blades to completely stop before attempting to remove the lid.
8. Twist the lid counter-clockwise to unlock and remove it. Carefully remove the blade assembly before emptying the bowl.

Note: For optimal results and to prevent motor strain, avoid continuous operation for extended periods. Use pulse action for tough ingredients.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your food processor.

5.1 Disassembly for Cleaning

1. Ensure the appliance is turned off and disconnected from the charger.
2. Remove the lid, then carefully remove the blade assembly or disc.
3. Remove the processing bowl from the motor base.

5.2 Cleaning Components

- Processing Bowl, Lid, Blades, Pusher, Discs:** Wash these parts in warm, soapy water. Use a brush for hard-to-reach areas and exercise extreme caution when handling blades. Rinse thoroughly and dry immediately to prevent water spots and rust. These parts may be dishwasher safe (top rack only), but hand washing is recommended for longevity.
- Motor Base:** Wipe the exterior of the motor base with a soft, damp cloth. Do not immerse the motor base in water or rinse it under running water. Ensure it is completely dry before storing or recharging.

5.3 Storage

Store the food processor in a clean, dry place, out of reach of children. Ensure all parts are dry before reassembling for storage.

6. TROUBLESHOOTING

If you encounter issues with your food processor, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Battery is depleted. Lid or bowl not properly assembled/locked.	Charge the unit fully. Ensure the bowl and lid are securely locked into place.
Poor processing results (uneven chopping).	Ingredients are too large or too much. Overfilling the bowl.	Cut ingredients into smaller, uniform pieces. Process in smaller batches. Do not exceed the MAX fill line.
Motor sounds strained or stops.	Overloaded with ingredients. Processing very hard foods.	Reduce the amount of ingredients. Cut hard foods into smaller pieces or avoid processing them. Use pulse function.
Unusual noise during operation.	Blade assembly not seated correctly. Foreign object in the bowl.	Disassemble and reassemble the blade correctly. Turn off, unplug, and check for any foreign objects.

7. SPECIFICATIONS

Feature	Specification
Product Brand	RAF
Manufacturer	Silver
Model Number	R.2862
Power	200W
Type	3-in-1 Cordless Food Processor

Feature	Specification
Item Weight	4 Kilograms
Item Dimensions (D x W x H)	25D x 33W x 30H centimeters
Color	Multicolor (primarily silver/black)
Included Components	Motor Base, Processing Bowl, Lid, Chopping Blade Assembly, Pusher (additional discs may vary)

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support or service inquiries, please contact the manufacturer or your local distributor.

© 2025 Silver. All rights reserved.