

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [RAF](#) /

> [RAF Electric Blender and Chopper 3-in-1, Model R.2865 - User Manual](#)

RAF R.2865

RAF Electric Blender and Chopper 3-in-1 User Manual

Model: R.2865

INTRODUCTION

Thank you for purchasing the RAF Electric Blender and Chopper 3-in-1, Model R.2865. This appliance is designed for efficient blending, stirring, chopping, and mixing of various food items and fruits. Please read this manual carefully before use to ensure safe and optimal operation. Keep this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Always operate the appliance on a flat, stable surface.
- Blades are sharp. Handle with care.
- Do not process hot liquids in the blender.

PRODUCT COMPONENTS

The RAF R.2865 is a versatile 3-in-1 appliance. It typically includes the following main components:

- Motor Base Unit
- Blender Jar with Lid and Blade Assembly
- Chopper Bowl with Lid and Blade Assembly
- Grinder Cup (for dry ingredients like coffee beans, spices)



Image: Overview of the RAF R.2865 3-in-1 appliance showing the motor base, blender jar, chopper bowl, and grinder cup attachments.

SETUP

Before First Use:

1. Unpack all components and remove any packaging materials.
2. Wash the blender jar, chopper bowl, grinder cup, lids, and blade assemblies in warm soapy water. Rinse thoroughly and dry.
3. Wipe the motor base unit with a damp cloth. Do not immerse the motor unit in water.
4. Ensure all parts are completely dry before assembly.

Assembling the Blender:

1. Place the motor base unit on a stable, flat surface.
2. Ensure the blade assembly is securely attached to the bottom of the blender jar.
3. Place the blender jar onto the motor base, aligning the grooves. Turn clockwise until it locks into place.
4. Place the lid securely on the blender jar. Ensure the measuring cup is inserted into the lid opening.



Image: Front view of the RAF R.2865 motor base with the blender jar assembled and ready for use.

Assembling the Chopper:

1. Place the motor base unit on a stable, flat surface.
2. Carefully place the chopper blade assembly onto the central shaft inside the chopper bowl.
3. Add ingredients to the chopper bowl.
4. Place the chopper lid onto the bowl, ensuring it is securely locked.
5. Place the assembled chopper bowl onto the motor base, aligning the grooves. Turn clockwise until it locks into place.



Image: Side view of the RAF R.2865 motor base with the chopper bowl assembled.

OPERATING INSTRUCTIONS

Always ensure the appliance is correctly assembled and locked before plugging it in and operating.

General Operation:

1. Plug the appliance into a suitable power outlet.

2. Use the "ON/OFF" switch to turn the appliance on or off.
3. The "Power OFF/ON" switch controls the main power to the unit.
4. Adjust the speed using the rotary dial. Start with lower speeds for coarse chopping or blending and increase as needed.
5. For short bursts of power, use the "Pulse" button. This is ideal for controlling consistency or breaking down larger pieces.
6. Do not operate the appliance continuously for more than 1 minute. Allow it to cool down for at least 2 minutes before resuming.
7. After use, switch off the appliance, unplug it, and wait for the blades to stop completely before disassembling.

Using the Blender:

1. Add ingredients to the blender jar. Do not exceed the maximum fill line indicated on the jar.
2. For best results, add liquids first, then soft ingredients, and finally harder ingredients or ice.
3. Secure the lid.
4. Select the desired speed or use the pulse function.
5. If ingredients stick to the sides, switch off the blender, unplug it, remove the lid, and use a spatula to push them down. Never use your hands or utensils while the blender is running.



Image: The RAF R.2865 blender jar filled with fruits and liquids, demonstrating typical use.

Using the Chopper:

1. Cut large ingredients into smaller pieces (approx. 2-3 cm) before placing them in the chopper bowl.
2. Do not overfill the chopper bowl.
3. Secure the lid.
4. Use the pulse function for controlled chopping, or a low speed setting for continuous operation.
5. For even chopping, process in short bursts and shake the bowl if necessary (after switching off and unplugging).

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your appliance.

1. Always unplug the appliance before cleaning.
2. **Motor Base Unit:** Wipe with a damp cloth. Do not immerse in water or any other liquid.
3. **Blender Jar, Chopper Bowl, Grinder Cup, Lids, and Blade Assemblies:**
 - Wash immediately after use to prevent food from drying on.
 - Wash in warm soapy water using a brush for the blades. **Handle blades with extreme care as they are very sharp.**
 - Rinse thoroughly and dry completely before storing.
 - Some parts may be dishwasher safe (refer to product markings if available), but hand washing is generally recommended for longevity.
4. Do not use abrasive cleaners or scouring pads on any part of the appliance.
5. Store the appliance in a dry place, out of reach of children.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power switch off; attachment not correctly assembled/locked.	Ensure plug is firmly in outlet; turn on "ON/OFF" and "Power OFF/ON" switches; reassemble attachment correctly until it locks.
Motor runs, but blades do not turn.	Blade assembly not correctly attached; ingredients jammed.	Switch off and unplug. Check blade assembly is secure. Remove some ingredients if overloaded or use a spatula to free jammed items.
Loud noise or vibration.	Appliance not on a flat surface; ingredients too large or too much.	Place on a stable, flat surface. Reduce ingredient quantity or cut into smaller pieces.
Smoke or burning smell.	Overheating due to prolonged use or overload.	Immediately switch off and unplug. Allow the motor to cool down completely (at least 30 minutes). Reduce load and processing time. If problem persists, discontinue use and contact service.

SPECIFICATIONS

- **Brand:** RAF
- **Model Number:** R.2865
- **Power/Wattage:** 2600 Watts
- **Power Source:** Corded Electric
- **Blade Material:** Stainless Steel
- **Item Weight:** 4 Kilograms
- **Product Dimensions (D x W x H):** 25 cm x 33 cm x 30 cm

- **Recommended Uses:** Blending, Chopping, Mixing
- **Included Components:** Motor Base, Blender Jar, Chopper Bowl, Grinder Cup

WARRANTY AND SUPPORT

This product is provided without a manufacturer's warranty as per the product specifications. For any operational issues or questions, please refer to the troubleshooting section or contact your retailer for assistance.

