

Escape B0DVBJ7SJF

Escape AM/FM Alarm Clock Radio

Model: B0DVBJ7SJF

1. SAFETY INFORMATION

- Read all instructions carefully before use.
- Keep this manual for future reference.
- Do not expose the unit to rain or moisture.
- Do not place near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Clean only with a dry cloth.
- Unplug this apparatus during lightning storms or when unused for long periods of time.

2. PACKAGE CONTENTS

- Escape AM/FM Alarm Clock Radio
- Power Adapter
- Instruction Manual

3. PRODUCT OVERVIEW

The Escape AM/FM Alarm Clock Radio is designed for reliable timekeeping and customizable wake-up options. It features a compact design, digital display, and intuitive controls for ease of use.

Front View



Front view of the Escape AM/FM Alarm Clock Radio, showing the digital display and top control buttons.

Key Features



Product packaging highlighting key features like snooze, sleep timer, and alarm options.

- Digital Time Display
- AM/FM Radio Tuner
- Dual Alarm Settings (Buzzer or Radio)
- Snooze Function
- Sleep Timer
- Telescopic Antenna for improved radio reception
- 9V Battery Backup Option (battery not included)

4. SETUP

4.1 Power Connection

Plug the power adapter into a standard wall outlet and connect it to the DC input port on the back of the alarm clock. The display will illuminate, and the time will flash, indicating it is ready for time setting.

4.2 Battery Backup

For power outage protection, insert a 9V battery (not included) into the battery compartment located on the bottom of the unit. This will maintain time and alarm settings during a power interruption.

4.3 Setting the Time

When the unit is first plugged in, the time display will flash. To set the current time:

1. Press the **SET TIME** button. The hour digits will begin to flash.

2. Use the **HR** (Hour) button to adjust the hour. Press and hold for faster adjustment. Observe the PM indicator for correct AM/PM setting.
3. Press the **MIN** (Minute) button to adjust the minutes. Press and hold for faster adjustment.
4. Press **SET TIME** again to confirm and save the time. The display will stop flashing.

To adjust the time after initial setup, press and hold the **SET TIME** button until the display flashes, then follow steps 2-4.

Your browser does not support the video tag.

Video: Instructions on how to set the time on a similar alarm clock model. Please note that button labels or exact steps may vary slightly from your Escape model.

5. OPERATING INSTRUCTIONS

5.1 Setting the Alarm

The alarm clock features two independent alarms. To set an alarm:

1. Ensure the radio is off. If the radio is playing, press the **AM/FM** button to turn it off.
2. Press and hold either the **ALARM 1** or **ALARM 2** button for 2 seconds. The alarm time will start flashing.
3. Use the **HR** (Hour) and **MIN** (Minute) buttons to set your desired alarm time.
4. Press the **ALARM 1** or **ALARM 2** button repeatedly to cycle through alarm options: Buzzer, Radio, or Off. The corresponding icon (bell for buzzer, music note for radio) will appear on the display.
5. Press the **SET TIME** button or wait 10 seconds for the settings to save automatically.

The alarm volume cannot be adjusted independently; it will sound at a preset level for the buzzer or the last radio volume for the radio alarm.

Your browser does not support the video tag.

Video: Instructions on how to set the alarm on a similar alarm clock model. Please note that button labels or exact steps may vary slightly from your Escape model.

5.2 Using the Radio

1. Press the **AM/FM** button to turn on the radio.
2. Adjust the telescopic antenna for optimal reception.
3. Use the **TUNING** knob (usually on the side) to select your desired radio station.
4. Use the **VOLUME** knob (usually on the side) to adjust the sound level.
5. To turn off the radio, press the **AM/FM** button again.

5.3 Snooze Function

When the alarm sounds, press the large **SNOOZE** button (often labeled SNOOZE/SLEEP/DIM) on the top of the unit. The alarm will pause for approximately 9 minutes and then sound again.

5.4 Sleep Timer

The sleep timer allows you to fall asleep to the radio, which will automatically turn off after a set period.

1. While the radio is playing, press the **SLEEP** button (often combined with SNOOZE).
2. Each press will cycle through preset sleep times (e.g., 90, 60, 30, 15 minutes, or OFF). Select your

desired duration.

3. The radio will play for the selected duration and then automatically turn off.

6. MAINTENANCE

- Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the unit away from direct sunlight, extreme temperatures, and dusty environments.
- Ensure the telescopic antenna is not bent or damaged.

7. TROUBLESHOOTING

Problem	Solution
Clock display is blank.	Ensure the power adapter is securely plugged into both the unit and a working wall outlet. Check if the power outlet is functional.
Alarm does not sound.	Verify that the alarm time is set correctly and the alarm is activated (Buzzer or Radio icon visible). Check if the volume is not set too low for radio alarm.
Poor radio reception.	Extend and adjust the telescopic antenna. Try repositioning the unit to improve signal.
Time is incorrect after power outage.	Ensure a fresh 9V battery is installed for backup. Reset the time manually if no backup battery is present or if the battery is depleted.

8. SPECIFICATIONS

- **Brand:** Escape
- **Model:** B0DVBJ7SJF
- **Color:** Black
- **Product Dimensions:** 11 x 3.81 x 5 cm
- **Power Source:** AC Power Adapter, 9V Battery Backup (not included)
- **Alarm Type:** Buzzer or AM/FM Radio
- **Display:** Digital LED

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Escape website. Keep your purchase receipt as proof of purchase.