



[Manuals.plus](#) /

> [Acer](#) /

> Acer TravelMate P2 16" Laptop User Manual

**Acer NX.BB7EG.002**

# Acer TravelMate P2 16" Laptop User Manual

Model: TMP216-51-G2-TCO-5949 (NX.BB7EG.002)

## 1. INTRODUCTION

---

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your Acer TravelMate P2 16" laptop. Designed for productivity and reliability, this device features an Intel Core 5-120U processor, 16GB DDR5 RAM, a 512GB SSD, and comes with eShell operating system. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your device.



**Figure 1.1:** Front view of the Acer TravelMate P2 16" laptop. This image shows the laptop open, revealing the 16-inch display, keyboard, and touchpad. The screen displays a vibrant, abstract blue and green pattern, highlighting the WUXGA (1920 x 1200) resolution.

## 2. INITIAL SETUP

---

### 2.1 Unpacking and Inspection

Carefully remove all components from the packaging. Verify that all items listed below are present and undamaged. If any item is missing or damaged, contact your retailer immediately.

- Acer TravelMate P2 16" Laptop
- AC Power Adapter and Power Cord
- Quick Start Guide (if included)
- Warranty Information (if included)

### 2.2 Connecting to Power

Before first use, ensure the laptop battery is fully charged. Connect the AC power adapter to the laptop's power input port and then plug the power cord into a wall outlet. The charging indicator light will illuminate.

### 2.3 Initial Boot and Operating System Setup

Press the power button to turn on the laptop. The system will guide you through the initial setup process for the eShell operating system. Follow the on-screen prompts to configure language, region, network settings, and user accounts.

### 2.4 Connecting Peripherals

Your laptop is equipped with various ports for connecting external devices. Refer to the "Operating" section for details on port usage.

## 3. OPERATING YOUR LAPTOP

---

### 3.1 Powering On/Off and Sleep Mode

- **Power On:** Press the power button located on the keyboard deck.
- **Power Off:** From the operating system, select "Shut Down" from the power options.
- **Sleep Mode:** Close the lid or select "Sleep" from the power options. Press any key or the power button to wake the laptop.

### 3.2 Using the Keyboard and Touchpad

The laptop features a full-size keyboard and a precision touchpad. The keyboard includes a numeric keypad for enhanced data entry. The touchpad supports multi-touch gestures for navigation.



**Figure 3.1:** Top-down view of the Acer TravelMate P2 16" laptop's keyboard and touchpad. This image highlights the full-size keyboard layout, including the numeric keypad, and the large, central touchpad. The keys appear backlit, indicating a potential feature for low-light use.

### 3.3 Connecting to a Network

Your laptop supports Wi-Fi connectivity. To connect to a wireless network, access the network settings in your operating system, select your desired Wi-Fi network, and enter the password if required.

### 3.4 Using Ports and Connectors

The Acer TravelMate P2 16" is equipped with various ports for connectivity:

- **USB 3.0 Ports:** For connecting high-speed USB devices such as external hard drives, flash drives, and peripherals. (2 ports available)

- **HDMI Port:** For connecting to external displays, projectors, or TVs.
- **Ethernet (RJ-45) Port:** For wired network connections.
- **Audio Jack:** For headphones or external speakers.
- **Power Input:** For connecting the AC adapter.
- **SD Card Reader:** For reading data from SD memory cards.



**Figure 3.2:** Side view of the Acer TravelMate P2 16" laptop, illustrating the arrangement of its various ports. This image shows USB ports, an HDMI port, and potentially an Ethernet port or other connectivity options, providing a visual guide for connecting peripherals.

### 3.5 Fingerprint Reader

The laptop includes a fingerprint reader for secure and convenient login. To set up the fingerprint reader, navigate to the security settings within your eShell operating system and follow the instructions to register your fingerprints.

## 4. MAINTENANCE AND CARE

---

### 4.1 Cleaning Your Laptop

- **Screen:** Use a soft, lint-free cloth specifically designed for electronics. Dampen the cloth slightly with water or a screen cleaner solution. Do not spray liquid directly onto the screen.
- **Chassis and Keyboard:** Use a soft, dry cloth. For stubborn dirt, a slightly dampened cloth with mild soap solution can be used, ensuring no liquid enters openings.
- **Ports:** Use compressed air to gently clear dust from ports.

### 4.2 Battery Care

To prolong battery life:

- Avoid extreme temperatures.
- Do not fully discharge the battery frequently.
- If storing the laptop for an extended period, charge the battery to about 50% before storage.

### 4.3 Software Updates

Regularly check for and install operating system and driver updates to ensure optimal performance, security, and compatibility. Refer to your eShell operating system's documentation for update procedures.

### 4.4 Storage Management

Periodically review and delete unnecessary files to maintain sufficient free space on your 512GB SSD, which contributes to system performance.

## 5. TROUBLESHOOTING

---

This section addresses common issues you might encounter. For more complex problems, consult Acer's official support resources.

### 5.1 No Power / Laptop Not Turning On

- Ensure the AC adapter is securely connected to both the laptop and a working power outlet.
- Check if the power outlet is functional by plugging in another device.
- If the battery is completely drained, allow it to charge for at least 30 minutes before attempting to power on.

### 5.2 Display Issues

- **Blank Screen:** Ensure the laptop is powered on. Try pressing the display toggle function key (often Fn + F5 or similar) to cycle through display modes.
- **External Monitor Not Detected:** Verify the HDMI cable connection. Ensure the external monitor is powered on and set to the correct input source.

### 5.3 Network Connectivity Problems

- **Wi-Fi Not Connecting:** Check if Wi-Fi is enabled in the operating system settings. Restart your router and modem. Ensure you are entering the correct Wi-Fi password.
- **Slow Connection:** Move closer to your Wi-Fi router. Disconnect other devices from the network if they are consuming significant bandwidth.

### 5.4 System Performance Issues

- **Slow Performance:** Close unnecessary applications. Check for background processes consuming high CPU or RAM. Ensure sufficient free space on the SSD.
- **Overheating:** Ensure the laptop's vents are not blocked. Use the laptop on a hard, flat surface to allow for proper airflow.

## 6. TECHNICAL SPECIFICATIONS

---

Feature	Specification
Model Name	TMP216-51-G2-TCO-5949 (NX.BB7EG.002)
Processor	Intel Core 5-120U (up to 5.00 GHz)

<b>RAM</b>	16GB DDR5
<b>Storage</b>	512GB SSD
<b>Display</b>	16-inch WUXGA (1920 x 1200 pixels)
<b>Operating System</b>	eShell
<b>Ports</b>	2x USB 3.0, HDMI, Ethernet, Audio Jack, SD Card Reader
<b>Dimensions (LxWxH)</b>	14.15 x 10.28 x 0.9 inches (369 x 261 x 22.9 mm)
<b>Weight</b>	6.2 pounds (1.7 kg)
<b>Color</b>	All Grey
<b>Special Feature</b>	Fingerprint Reader

## 7. WARRANTY AND SUPPORT

---

### 7.1 Product Warranty

Your Acer TravelMate P2 laptop comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official Acer website for detailed terms and conditions, including warranty duration and coverage.

### 7.2 Technical Support

For technical assistance, driver downloads, or further troubleshooting, please visit the official Acer support website. You may need your product's serial number (located on a sticker on the bottom of the laptop) when contacting support.

**Acer Official Website:** [www.acer.com/support](http://www.acer.com/support)

