



[Manuals.plus](#) /

› [MYADDICTION](#) /

› MYADDICTION Digital Alarm Clock (Model LR53089803) User Manual

MYADDICTION LR53089803

MYADDICTION Digital Alarm Clock (Model LR53089803) User Manual

Brand: MYADDICTION | Model: LR53089803

1. INTRODUCTION

Thank you for choosing the MYADDICTION Digital Alarm Clock. This device features a large mirrored LED display, adjustable brightness, and multiple alarm settings to enhance your daily routine. This manual provides comprehensive instructions for its setup, operation, and maintenance.



Image 1.1: Front view of the MYADDICTION Digital Alarm Clock displaying time and alarm indicators.

2. SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the clock to strong impacts.
- Use only the specified power sources (USB or AAA batteries).
- Keep out of reach of children.
- Do not attempt to disassemble or repair the device yourself. Contact qualified personnel for service.

3. PACKAGE CONTENTS

Upon unpacking, please ensure all items are present and in good condition:

- 1x MYADDICTION Digital Alarm Clock
- 1x USB Power Cable (for continuous power)

- User Manual (this document)

Note: AAA batteries are not included and must be purchased separately for battery-powered operation.

4. PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your digital alarm clock.



Image 4.1: Rear view of the alarm clock, highlighting control buttons and power input.

Controls and Ports:

- **MODE Button:** Used to switch between time, date, and temperature display modes, and to enter setting modes.
- **UP Button:** Used to increase values during settings or navigate menus.
- **DOWN Button:** Used to decrease values during settings or navigate menus.
- **SNOOZE Button:** Activates snooze during an alarm, or adjusts display brightness in normal mode.

- **USB Power Input:** For connecting the USB power cable.
- **Battery Compartment:** For AAA batteries (backup power or temporary display).

5. SETUP

5.1 Powering the Clock

The clock supports dual power supply modes:

1. **USB Power Supply (Recommended for continuous display):** Connect the provided USB cable to the USB power input port on the back of the clock and plug the other end into a USB power adapter (not included) or a powered USB port. The display will remain continuously on.
2. **AAA Battery Power Supply (Backup or temporary display):** Open the battery compartment on the back and insert 3 AAA batteries (not included), ensuring correct polarity. When powered by batteries, the display will automatically turn off after 10-16 seconds to conserve power. Press any button to reactivate the display for 10-16 seconds.

5.2 Initial Time Setting

After powering on, the clock will typically display a default time. Follow these steps to set the correct time:

1. Press and hold the **MODE** button for approximately 3 seconds to enter time setting mode. The hour digits will start flashing.
2. Use the **UP** or **DOWN** buttons to adjust the hour.
3. Press the **MODE** button again to confirm the hour and move to minute setting. The minute digits will flash.
4. Use the **UP** or **DOWN** buttons to adjust the minutes.
5. Press the **MODE** button once more to exit time setting mode.

6. OPERATING INSTRUCTIONS

6.1 Adjusting Display Brightness

The clock offers 5 levels of brightness. To adjust:

- In normal time display mode, short press the **SNOOZE** button repeatedly to cycle through the 5 brightness levels.
- The clock also features a Night Mode (22:00-06:00) where brightness automatically reduces to a low level.

6.2 Setting Alarms

The clock supports two independent alarms (Alarm 1 and Alarm 2) and three weekday alarm modes.

1. Press the **MODE** button repeatedly until "AL1" or "AL2" appears on the display.
2. Press and hold the **MODE** button for 3 seconds to enter alarm setting mode. The hour digits for the selected alarm will flash.
3. Use the **UP** or **DOWN** buttons to set the desired alarm hour.
4. Press **MODE** to confirm the hour and move to minute setting. Use **UP** or **DOWN** to set the minutes.
5. Press **MODE** again to select the alarm mode:
 - "1-5": Alarm sounds Monday to Friday.
 - "1-6": Alarm sounds Monday to Saturday.
 - "1-7": Alarm sounds Monday to Sunday (every day).

Use **UP** or **DOWN** to select the desired mode.

6. Press **MODE** to exit alarm setting. The alarm icon (1 or 2) will appear on the display, indicating the alarm is active.
7. To turn an alarm ON/OFF, short press the **UP** button in normal time display mode to cycle through alarm activation.

6.3 Snooze Function

When an alarm sounds, short press the **SNOOZE** button to temporarily silence the alarm. The alarm will sound again after a few minutes (typical snooze duration is 5-9 minutes, refer to product specifics if available, otherwise general). To turn off the alarm completely, press any other button.

6.4 Display Modes (Time, Date, Temperature)

The clock offers two main display modes:

- **Mode 1: Only display time.**
- **Mode 2: Time, date, and temperature cycle display.** The display will automatically cycle through showing the time, then the date, then the temperature.

To switch between these modes, short press the **MODE** button in normal time display mode.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mirrored display and casing. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** If using AAA batteries, replace them when the display becomes dim or the clock functions erratically. Ensure correct polarity.
- **Storage:** If storing the clock for an extended period, remove the AAA batteries to prevent leakage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	No power, low batteries, or in battery-saving mode.	Ensure USB cable is securely connected and powered. Replace AAA batteries if using battery power. If on battery power, press any button to activate display.
Alarm does not sound.	Alarm not set, alarm turned off, or incorrect weekday mode.	Verify alarm time and activation (alarm icon visible). Check the selected weekday alarm mode (1-5, 1-6, 1-7).
Time/Date/Temperature display is incorrect.	Incorrect settings.	Refer to Section 5.2 for time setting. Refer to Section 6.4 for display mode selection.

9. SPECIFICATIONS

- **Brand:** MYADDICTION
- **Model Number:** LR53089803
- **Display Type:** Digital LED, Mirrored Surface

- **Brightness Levels:** 5 adjustable levels
- **Display Modes:** Time only; Time, Date, Temperature cycle
- **Alarm Functions:** Dual alarms, 3 weekday modes (Mon-Fri, Mon-Sat, Mon-Sun)
- **Snooze Function:** Yes
- **Power Source:** USB (DC 5V) or 3x AAA Batteries (not included)
- **Product Dimensions:** 128mm (L) x 65mm (H) x 35mm (W) (approx. 5.04 x 2.56 x 1.38 inches)
- **Item Weight:** 200 Grams



Image 9.1: Product dimensions of the MYADDICTION Digital Alarm Clock.

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer's policy or contact MYADDICTION customer service through their official channels. Please have your model number (LR53089803) and purchase details ready when contacting support.

Manufacturer: LR HOME DÉCOR

© 2023 MYADDICTION. All rights reserved.