

[Manuals.plus](#) /

> [Ymiko](#) /

> Ymiko Alarm Clock with Bed Shaker User Manual - Model Ymikovzge57sar2

Ymiko Ymikovzge57sar2

Ymiko Alarm Clock with Bed Shaker User Manual

Model: Ymikovzge57sar2

PRODUCT OVERVIEW

The Ymiko Alarm Clock with Bed Shaker is designed to provide a reliable wake-up solution, especially for heavy sleepers. It features adjustable volume, multiple wake-up modes, and a vibrating bed shaker to ensure you wake up on time.



Image: The Ymiko Alarm Clock, bed shaker, and USB cable. This image displays all components included in the package.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Alarm Clock
- 1 x Bed Shaker
- 1 x Instruction Manual
- 1 x USB Cable

SETUP

Powering the Alarm Clock

The alarm clock can be powered via the included USB cable or by batteries for backup.

1. Connect the USB cable to the alarm clock's power input port and plug the other end into a compatible USB power adapter (not included) or a USB port.
2. For battery backup, open the battery compartment on the back of the alarm clock and insert 2 x AAA batteries (not included), ensuring correct polarity.

Connecting the Bed Shaker

To utilize the vibration feature, connect the bed shaker to the alarm clock.

- Locate the dedicated port for the bed shaker on the alarm clock.
- Insert the bed shaker's plug firmly into this port.
- Place the bed shaker under your pillow or mattress for optimal vibration.



Image: Rear view of the alarm clock, highlighting the power input and bed shaker port.

OPERATING INSTRUCTIONS

Setting the Time

1. Press the **TIME SET** button. The time display will begin to flash.
2. Rotate the **left bell knob** (HR SETTING / DIMMER) to adjust the hour.
3. Rotate the **right bell knob** (MIN SETTING / DIMMER) to adjust the minute.
4. Press **TIME SET** again to confirm and exit time setting mode.



Image: Side view of the alarm clock showing the "TIME SET" button and other controls.

Switching 12/24 Hour Format

The default time format is 12-hour.

- Press the **12/24 HR** button to toggle between 12-hour and 24-hour display formats.

Setting Alarm 1

1. Press and hold the **ALARM 1 SET (HOLD)/ON/OFF** button for 3 seconds. The Alarm 1 time will flash.
2. Rotate the **left bell knob** to adjust the alarm hour.
3. Rotate the **right bell knob** to adjust the alarm minute.

4. Press **ALARM 1 SET** again to confirm and exit alarm setting mode.
5. To turn Alarm 1 ON or OFF, short press the **ALARM 1 SET (HOLD)/ON/OFF** button. An indicator will appear on the display when Alarm 1 is active.



Image: Side view of the alarm clock showing the "ALARM 1 SET" and "ALARM 2 SET" buttons.

Setting Alarm 2

Follow the same steps as Setting Alarm 1, but use the **ALARM 2 SET (HOLD)/ON/OFF** button.

Adjusting Alarm Sound and Wake-up Mode

The alarm clock offers 3 wake-up modes and 3 music alarm tones.

- Press the **ALARM SOUND** button to cycle through the available alarm tones (e.g., beeping, bird

chirping, music).

- Use the **SOUND / VIBRATION / BOTH** switch to select your preferred wake-up mode:
 - **SOUND:** Alarm will only use the selected sound tone.
 - **VIBRATION:** Alarm will only use the bed shaker.
 - **BOTH:** Alarm will use both the selected sound tone and the bed shaker.

Adjusting Volume

The alarm volume can be adjusted to suit your preference.

- Press the **VOLUME** button to adjust the alarm sound level.

Adjusting Screen Brightness (Dimmer)

The display brightness can be continuously adjusted.

- Rotate the **HR SETTING / DIMMER** knob (left bell knob) or **MIN SETTING / DIMMER** knob (right bell knob) to adjust the screen brightness.



Image: Top view of the alarm clock, indicating the hour and minute setting knobs which also function as dimmer controls.

Snooze Function

When the alarm sounds, press the **SNOOZE** button located on top of the clock to temporarily pause the alarm. The alarm will sound again after a short interval.

MAINTENANCE

To ensure the longevity and proper functioning of your Ymiko Alarm Clock, follow these maintenance guidelines:

- **Cleaning:** Wipe the alarm clock and bed shaker with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the surfaces.

- **Storage:** If storing the device for an extended period, remove the AAA batteries to prevent leakage. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Water:** Keep the alarm clock and bed shaker away from water and high humidity. This device is not waterproof.
- **Handle with Care:** Avoid dropping the device or subjecting it to strong impacts.

TROUBLESHOOTING

If you encounter issues with your Ymiko Alarm Clock, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Clock display is blank or flickering.	No power or low battery.	<ul style="list-style-type: none"> • Ensure the USB cable is securely connected to a working power source. • Check if the AAA batteries are inserted correctly and are not depleted. Replace if necessary.
Alarm does not sound or vibrate.	Alarm not activated, volume too low, or bed shaker not connected.	<ul style="list-style-type: none"> • Verify that the alarm is set and activated (check for alarm indicator on display). • Adjust the volume using the VOLUME button. • Ensure the SOUND / VIBRATION / BOTH switch is set to "SOUND", "VIBRATION", or "BOTH" as desired. • Confirm the bed shaker is properly plugged into its port.
Cannot set time or alarm.	Incorrect button sequence or mode.	<ul style="list-style-type: none"> • Refer to the "Operating Instructions" section for the correct steps to set time and alarms. • Ensure you press and hold the alarm set button for 3 seconds to enter setting mode.
Display is too bright or too dim.	Dimmer setting needs adjustment.	<ul style="list-style-type: none"> • Rotate the HR SETTING / DIMMER or MIN SETTING / DIMMER knobs to adjust brightness.

SPECIFICATIONS

Feature	Detail
Brand	Ymiko
Model Number	Ymikovzge57sar2
Display Type	Digital

Feature	Detail
Product Dimensions (W x H)	4.72"W x 4.33"H
Power Source	AC/DC (USB connectivity)
Battery Requirement	2 x AAA batteries (not included)
Frame Material	Acrylonitrile Butadiene Styrene
Special Features	Adjustable volume, 3 wake-up modes, 3 alarm tones, bed shaker, screen brightness dimmer.
Indoor/Outdoor Usage	Indoor

WARRANTY INFORMATION

For detailed warranty information regarding your Ymiko Alarm Clock, please refer to the warranty card included in your product packaging or visit the official Ymiko website. Warranty terms and conditions may vary by region and retailer.

SUPPORT

If you require further assistance or have questions not covered in this manual, please contact Ymiko customer support.

- **Online Support:** Visit the official Ymiko store on Amazon for product information and support resources: [Ymiko Store](#)
- **Contact Information:** Refer to your product packaging or the Ymiko website for specific customer service contact details.