

RHYTHM TESTAMENT 30854, 37416751, 37416751-A, 636762M1, 72080025, 731208M1, 731208M1-A, VPC5200, s41371, s41371-A

RHYTHM TESTAMENT Tachometer Drive Seal Instruction Manual

For Massey Ferguson Tractors (Models 35, 50, 135, and others)

1. PRODUCT OVERVIEW

This document provides essential information for the RHYTHM TESTAMENT Tachometer Drive Seal. This seal and gasket set is designed to maintain proper sealing between the tachometer drive housing and engine components in compatible Massey Ferguson tractor models. Its primary function is to prevent oil migration at the drive connection point, which is crucial for stable tachometer operation and long-term engine function.

The seal is engineered to match original specifications, ensuring correct fitment and sealing performance without requiring modifications during installation. It replaces various part numbers, including 30854, 37416751, 37416751-A, 636762M1, 72080025, 731208M1, 731208M1-A, VPC5200, s41371, and s41371-A.

2. COMPATIBILITY

This tachometer drive seal is compatible with a range of Massey Ferguson tractor models. Please verify your specific model against the list below to ensure proper fitment:

- Massey Ferguson 35, 50, 135
- Massey Ferguson 148, 158, 165
- Massey Ferguson 20B, 20D, 20E, 20F
- Massey Ferguson 230, 240, 250, 254, 255, 260
- Massey Ferguson 30E, 30H, 350
- Massey Ferguson 40E, 550 UK, 765

Refer to the product images and specifications to confirm that this seal meets your requirements before installation.

3. SETUP AND INSTALLATION

Proper installation of the tachometer drive seal is critical for its function. It is recommended that installation be performed by a qualified technician or individual with experience in tractor maintenance.

3.1. Required Tools and Materials

- Basic hand tools (wrenches, screwdrivers)
- Seal removal tool (if necessary)
- Clean rags
- Appropriate lubricant (e.g., engine oil)
- New RHYTHM TESTAMENT Tachometer Drive Seal

3.2. Installation Steps

1. **Preparation:** Ensure the tractor engine is turned off and cooled down. Disconnect the battery if working near electrical components.
2. **Locate Tachometer Drive:** Identify the tachometer drive housing on your engine. Consult your tractor's service manual for its exact location.
3. **Remove Old Seal:** Carefully remove the existing tachometer drive seal. Use a seal removal tool if the seal is stubborn or damaged. Be cautious not to scratch or damage the housing or shaft surfaces.
4. **Clean Surfaces:** Thoroughly clean the seal seating area on the tachometer drive housing and the shaft. Remove any old gasket material, oil residue, or debris. A clean surface is essential for a proper seal.
5. **Inspect Components:** Inspect the tachometer drive shaft and housing for any wear, corrosion, or damage. Address any issues before installing the new seal.
6. **Lubricate New Seal:** Lightly lubricate the inner and outer edges of the new RHYTHM TESTAMENT Tachometer Drive Seal with clean engine oil. This aids in smooth installation and helps prevent damage to the seal.
7. **Install New Seal:** Carefully position the new seal into the housing. Ensure it is seated squarely. Gently press or tap the seal into place using an appropriate tool (e.g., a seal driver or a socket of the correct size) until it is fully and evenly seated. Do not use excessive force or distort the seal.
8. **Reassemble:** Reattach any components that were removed to access the seal.
9. **Test:** After reassembly, start the engine and check for any oil leaks around the tachometer drive area. Monitor the tachometer operation to ensure it is stable.



Image 1: Front view of the RHYTHM TESTAMENT Tachometer Drive Seal. This image shows the circular design and the internal spring mechanism responsible for maintaining a tight seal around the shaft.

4. OPERATING PRINCIPLES

Once correctly installed, the RHYTHM TESTAMENT Tachometer Drive Seal functions passively to maintain the integrity of the tachometer drive system. It creates a barrier that prevents engine oil from leaking out of the tachometer drive housing and protects the internal components from external contaminants.

A properly functioning seal ensures:

- **Oil Retention:** Prevents engine oil from escaping the tachometer drive connection point.
- **Stable Tachometer Readings:** By preventing oil migration, the seal helps maintain the correct environment for the tachometer drive, contributing to accurate and stable RPM readings.
- **Component Protection:** Shields the tachometer drive mechanism from dirt, dust, and moisture, extending its lifespan.



Image 2: Angled view of the Tachometer Drive Seal, highlighting its profile and material composition. This perspective helps illustrate the seal's robust construction.

5. MAINTENANCE

The tachometer drive seal is a wear item and does not require active maintenance beyond periodic inspection and timely replacement.

5.1. Inspection

- Regularly inspect the area around the tachometer drive housing for any signs of oil leakage.
- Look for cracks, hardening, or deterioration of the seal material.
- Any visible oil seepage or damage indicates that the seal may be failing and requires replacement.

5.2. Replacement Schedule

While there isn't a fixed replacement schedule for seals, it is advisable to replace the tachometer drive seal whenever the

tachometer drive housing is serviced or if any signs of leakage or wear are observed. Proactive replacement during related repairs can prevent future issues.



Image 3: Side view of the Tachometer Drive Seal, showing its thickness and overall dimensions. This view is helpful for understanding the seal's physical form.

6. TROUBLESHOOTING

If you experience issues related to the tachometer drive, a failing seal could be a contributing factor.

Symptom	Possible Cause	Solution
Oil leakage around tachometer drive housing	Worn, damaged, or improperly installed seal	Inspect and replace the tachometer drive seal. Ensure proper installation.

Symptom	Possible Cause	Solution
Erratic or inaccurate tachometer readings	Oil migration affecting drive mechanism, or other tachometer drive component failure	Check for oil leaks and replace the seal if necessary. If the issue persists, inspect the tachometer cable and drive unit.
Excessive dirt or debris near tachometer drive	Compromised seal allowing ingress of contaminants	Replace the seal and clean the area thoroughly.

7. SPECIFICATIONS

Below are the key specifications for the RHYTHM TESTAMENT Tachometer Drive Seal:

- **Product Dimensions:** 2.4 x 2.4 x 0.35 inches
- **Item Weight:** 4 ounces
- **Manufacturer:** RHYTHM TESTAMENT
- **Replaces Part Numbers:** 30854, 37416751, 37416751-A, 636762M1, 72080025, 731208M1, 731208M1-A, VPC5200, s41371, s41371-A
- **ASIN:** B0DX1WJFZP

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or any product-related inquiries, please contact RHYTHM TESTAMENT directly through their official channels or the retailer from whom the product was purchased. Please have your purchase details and the product's ASIN (B0DX1WJFZP) available when contacting support.

© 2026 RHYTHM TESTAMENT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DX1WJFZP>

More documents and user manuals: <https://manuals.plus/>