

Tradeweld EWM0136M

Tradeweld MIG 200 M Multi-Process Welding Machine User Manual

Model: EWM0136M

[Overview](#) [Safety](#) [Features](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#)

1. PRODUCT OVERVIEW

The Tradeweld 200M Compact Multi-Process Welding Machine is a versatile and portable solution designed for light industrial and DIY applications. This advanced multi-process welder can perform MIG, MMA (Manual Metal Arc), and TIG (Tungsten Inert Gas) welding, ensuring high-quality welds on various metals, including mild steel, stainless steel, and aluminum. With its user-friendly interface and digital display, this welding machine is suitable for small-scale fabrication and repair tasks.



Image: Tradeweld company logo.

2. SAFETY INSTRUCTIONS

Always prioritize safety when operating welding equipment. Failure to follow safety precautions can result in serious injury or death. Read and understand all instructions before use.

- **Personal Protective Equipment (PPE):** Always wear a welding helmet with appropriate shade, flame-resistant clothing, welding gloves, and safety shoes.
- **Ventilation:** Ensure adequate ventilation to remove welding fumes. Work in a well-ventilated area or use fume extraction equipment.
- **Fire Hazards:** Keep flammable materials away from the welding area. Have a fire extinguisher readily available.
- **Electrical Safety:** Ensure the machine is properly grounded. Do not operate in wet conditions. Inspect cables for damage before each use.
- **Eye and Skin Protection:** Welding arcs emit intense UV and IR radiation that can cause severe burns to eyes and skin.
- **Gas Cylinders:** Handle gas cylinders with care. Secure them to prevent tipping.
- **Work Area:** Keep the work area clean and free of clutter.

3. PACKAGE CONTENTS

Verify that all items are present in the package before beginning setup.

- 1 x Tradeweld MIG 200 M Multi-Process Welding Machine
- Welding Torch (MIG)
- Earth Clamp
- Electrode Holder (for MMA)
- User Manual (this document)
- Other standard accessories (check packaging for full list)



Image: The Tradeweld MIG 200 M Multi-Process Welding Machine, showing its front panel and connections.

4. PRODUCT FEATURES

The Tradeweld MIG 200 M offers a range of features designed for efficient and versatile welding:

- Suitable for MIG, MMA, and TIG DC Welding.
- Ideal for light-duty aluminum welding with a spool gun (spool gun sold separately).
- Excellent welding characteristics across various processes.
- Less power consumption for improved efficiency.
- Internal 2-wheel wirefeed system for consistent wire delivery.
- User-friendly interface with digital display.
- Compact and portable design.



Image: The Tradeweld MIG 200 M welding machine shown with its included welding torch, earth clamp, and electrode holder.

5. SETUP GUIDE

Proper setup is crucial for safe and effective operation. Refer to the specific instructions for each welding process.

5.1 General Setup

1. **Placement:** Place the welding machine on a stable, level surface in a well-ventilated area.
2. **Power Connection:** Connect the machine to a suitable power supply. Ensure the voltage and current ratings match the machine's requirements.
3. **Grounding:** Attach the earth clamp securely to the workpiece or a dedicated grounding point.

5.2 MIG Welding Setup

1. **Gas Cylinder:** Connect the appropriate shielding gas cylinder (e.g., Argon/CO2 mix for steel, pure Argon for aluminum) to the machine's gas inlet.
2. **Wire Feed:** Install the welding wire spool into the internal wire feed system. Thread the wire through the feeder mechanism and into the MIG torch liner.
3. **Torch Connection:** Connect the MIG torch to the front panel.
4. **Polarity:** Set the polarity according to the wire type (usually DC+ for solid wire with gas).

5.3 MMA (Stick) Welding Setup

1. **Electrode Holder:** Connect the electrode holder cable to the appropriate terminal (usually positive for most electrodes).
2. **Earth Clamp:** Connect the earth clamp cable to the remaining terminal.
3. **Electrode:** Insert the desired electrode into the electrode holder.

5.4 TIG Welding Setup (DC Lift TIG)

1. **TIG Torch:** Connect a TIG torch (sold separately) to the machine.
2. **Gas Cylinder:** Connect a pure Argon shielding gas cylinder to the machine.
3. **Tungsten Electrode:** Prepare and install the tungsten electrode in the TIG torch.
4. **Polarity:** Set the polarity (usually DC- for most TIG applications).

6. OPERATING INSTRUCTIONS

Before operating, ensure all safety precautions are followed and the machine is correctly set up for the chosen welding process.

6.1 Power On and Mode Selection

1. Turn on the main power switch located on the machine.
2. Use the control panel to select the desired welding process: MIG, MMA, or TIG.
3. Adjust welding parameters (current, voltage, wire speed) according to the material thickness and welding process. Refer to welding charts for guidance.

6.2 MIG Welding Operation

1. Open the gas cylinder valve and set the gas flow rate.
2. Position the MIG torch at the starting point of the weld.
3. Press the torch trigger to initiate the arc and wire feed. Maintain a consistent travel speed and torch angle.
4. Release the trigger to stop welding.

6.3 MMA (Stick) Welding Operation

1. Strike the electrode against the workpiece to initiate the arc.
2. Maintain a consistent arc length and travel speed, allowing the electrode to melt and deposit filler material.
3. Continue welding until the electrode is consumed or the weld is complete.

6.4 TIG Welding Operation (Lift TIG)

1. Open the gas cylinder valve and set the gas flow rate.
2. Gently touch the tungsten electrode to the workpiece and then lift it slightly to initiate the arc (Lift TIG).
3. Maintain a short arc length and feed filler rod manually if required.
4. Finish the weld and allow post-flow gas to protect the cooling weld puddle.

7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your welding machine.

- **Cleaning:** Regularly clean the machine's exterior with a dry cloth. Use compressed air to blow out dust and debris from inside the machine, especially around cooling vents.
- **Torch and Cables:** Inspect welding torches, cables, and connections for wear, cuts, or damage. Replace damaged components immediately.
- **Wire Feed System (MIG):** Clean the wire feed rollers and liner regularly to prevent blockages and ensure smooth wire feeding. Check for proper tension.
- **Electrode Holder/Earth Clamp:** Ensure good electrical contact by keeping the jaws of the electrode holder and earth clamp clean.
- **Gas Hoses and Connections:** Check gas hoses for leaks and ensure all connections are tight.
- **Storage:** Store the machine in a clean, dry environment when not in use.

8. TROUBLESHOOTING

This section provides solutions to common issues you might encounter. For problems not listed here, contact customer support.

Problem	Possible Cause	Solution
No power to machine	Power cable disconnected, circuit breaker tripped, machine switch off.	Check power cable, reset circuit breaker, ensure machine switch is ON.
Poor arc starting/unstable arc	Incorrect settings, poor earth connection, contaminated workpiece, worn consumables.	Adjust current/voltage, clean earth clamp contact, clean workpiece, replace torch tip/electrode.

Problem	Possible Cause	Solution
Wire feed issues (MIG)	Wire tangled, liner blocked, drive roller tension incorrect, wrong size tip.	Untangle wire, clean/replace liner, adjust drive roller tension, use correct tip size.
No gas flow (MIG/TIG)	Gas cylinder empty, valve closed, hose kinked, regulator faulty.	Check cylinder level, open valve, straighten hose, check regulator.
Overheating protection activated	Exceeded duty cycle, poor ventilation.	Allow machine to cool down, ensure adequate ventilation.

9. TECHNICAL SPECIFICATIONS

Specification	Detail
Manufacturer	Tradeweld
Model Number	EWM0136M
Product Dimensions	66.6 x 47.6 x 33.6 cm
Item Weight	24.2 kg
Colour	Blue/Black
Power Source	DC
Included Components	1 x Tradeweld MIG 200 M Multi-Process Welding Machine
Welding Processes	MIG, MMA, TIG DC

10. WARRANTY AND SUPPORT

Warranty information for the Tradeweld MIG 200 M Multi-Process Welding Machine is typically provided with the product packaging or can be found on the official Tradeweld website. Please retain your proof of purchase for any warranty claims.

For technical support, spare parts, or service inquiries, please contact your authorized Tradeweld dealer or visit the Tradeweld official website for contact information.