

B0DZX3GWZ3

12L Electric Air Fryer User Manual

Model: B0DZX3GWZ3

Brand: Generic

INTRODUCTION

Thank you for purchasing the 12L Electric Air Fryer. This appliance is designed to provide a healthier alternative to traditional frying, allowing you to cook a variety of delicious meals with significantly less oil. Its transparent oven door, intuitive touch controls, and intelligent temperature control make cooking simple and enjoyable. Please read this manual thoroughly before using the appliance to ensure safe and efficient operation.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

PRODUCT OVERVIEW

Components

Familiarize yourself with the main parts of your 12L Electric Air Fryer.

- Main Unit with Control Panel
- Transparent Oven Door
- Removable Cooking Basket/Trays
- Power Cord
- BBQ Grill Rack (Special Feature)

Key Features

- **Visible Cooking:** The transparent oven door allows you to monitor your food's progress without opening the unit, preserving heat and ensuring consistent results.
- **Large Capacity:** A generous 12-liter capacity is ideal for preparing meals for families or entertaining guests.
- **Multi-Functionality:** Combines air frying and baking capabilities. Features 360-degree circulating hot air for even cooking without the need for flipping.
- **Easy Operation:** User-friendly interface with touch controls for straightforward cooking.
- **Intelligent Control:** Advanced temperature control ensures precise cooking and perfect results every time.



Figure 1: Front view of the 12L Electric Air Fryer. This image shows the appliance's sleek design, the digital control panel, and the transparent oven door, which allows for easy monitoring of food during cooking.

Multi layer grill Simultaneous frying



Figure 2: Multi-layer grill for simultaneous frying. This image illustrates the air fryer's internal capacity, demonstrating how multiple trays can be used concurrently to cook different food items, such as dried fruits and nuts.

Intelligent touch full screen

Easy to reach with just a touch



Figure 3: Intelligent touch full screen. This image highlights the user-friendly digital touch control panel, showing a hand interacting with the screen to select settings, emphasizing ease of use.



Figure 4: Product Dimensions. This image provides a visual representation of the air fryer's physical dimensions, indicating its depth (31.5cm), width (28.5cm), and height (34.5cm) for placement consideration.

SETUP

- Unpacking:** Carefully remove the air fryer and all accessories from the packaging. Retain packaging for future storage or transport.
- Initial Cleaning:** Before first use, wipe the exterior of the appliance with a damp cloth. Wash all removable parts (cooking basket, trays, grill rack) with warm, soapy water. Rinse thoroughly and dry completely.
- Placement:** Place the air fryer on a stable, flat, heat-resistant surface. Ensure there is at least 6 inches (15 cm) of clear space on all sides and above the appliance to allow for proper air circulation. Do not place it directly against a wall or under cabinets.
- Power Connection:** Ensure the voltage of your power outlet matches the voltage specified on the appliance's rating label (110 Volts). Plug the power cord into a grounded wall outlet.
- First Use (Burn-in):** It is recommended to run the air fryer empty for about 10-15 minutes at 350°F (175°C) before cooking food for the first time. This helps to burn off any manufacturing residues and eliminate initial odors. A slight odor or smoke may be present during this process; this is normal. Ensure the area is well-ventilated.

OPERATING INSTRUCTIONS

Basic Operation

1. **Prepare Food:** Place your desired food items into the cooking basket or on the trays. Do not overfill to ensure even cooking.
2. **Insert Basket/Trays:** Slide the cooking basket or trays securely into the air fryer.
3. **Power On:** Plug the appliance into a power outlet. The control panel will illuminate.
4. **Select Cooking Mode:** Use the touch control panel to select a preset cooking mode or manually set the temperature and time.
5. **Adjust Settings:** Use the temperature and time adjustment buttons to fine-tune your cooking settings. The temperature range is typically from 180°F to 400°F (80°C to 200°C).
6. **Start Cooking:** Press the Start/Pause button to begin the cooking process.
7. **Monitor Progress:** Utilize the transparent oven door to visually check on your food without interrupting the cooking cycle.
8. **Shake/Flip (if needed):** For some foods, you may need to pause the cooking, remove the basket/trays, shake or flip the food, and then reinsert to resume cooking.
9. **Completion:** The air fryer will typically beep when the cooking cycle is complete. Carefully remove the cooked food using heat-resistant tongs or mitts.
10. **Power Off:** Unplug the appliance from the wall outlet after use.

Cooking Modes and Presets

Your air fryer comes with various preset functions for common dishes. Refer to the icons on the touch control panel for specific presets. These typically include:

- Fries
- Chicken
- Fish
- Steak
- Shrimp
- Bake
- Roast
- Dehydrate (if applicable)

These presets offer optimized temperature and time settings, but can be adjusted manually to suit your preference.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your air fryer. Always unplug the appliance and allow it to cool completely before cleaning.

Cleaning the Interior and Exterior

- Wipe the exterior of the air fryer with a damp cloth and mild detergent. Do not use abrasive cleaners or scouring pads.
- For the interior, wipe down with a damp cloth. For stubborn food residue, a non-abrasive sponge with warm, soapy water can be used.
- Clean the heating element gently with a soft brush if necessary, ensuring the appliance is unplugged and cool.

Cleaning Removable Parts

- The cooking basket, trays, and grill rack are **not dishwasher safe**.
- Wash these parts in warm, soapy water using a non-abrasive sponge.
- For baked-on food, soak the parts in warm water for about 10 minutes before cleaning.
- Rinse thoroughly and dry completely before reassembling or storing.

Storage

Ensure the air fryer is clean and dry before storing. Store it in a cool, dry place, away from direct sunlight and moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Power outlet is not working.	Ensure the power cord is securely plugged into a grounded outlet. Test the outlet with another appliance.
Food is not cooked evenly.	Basket/trays are overloaded. Food not shaken/flipped.	Cook food in smaller batches. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use. High fat content food.	Clean the cooking basket/trays and interior thoroughly after each use. For high-fat foods, drain excess oil from the bottom of the basket.
Food is not crispy.	Too much moisture in food. Not enough oil (for certain foods).	Pat food dry before air frying. Lightly brush or spray food with a small amount of oil.
Appliance smells during first use.	Manufacturing residues burning off.	This is normal. Run the air fryer empty for 10-15 minutes in a well-ventilated area before first use.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Model:	B0DZX3GWZ3
Brand:	Generic
Capacity:	12 Liters
Power Output:	1350 Watts
Voltage:	110 Volts
Control Method:	Touch Control

Material:	Stainless Steel
Product Dimensions (D x W x H):	12.4"D x 11.22"W x 13.58"H (31.5cm D x 28.5cm W x 34.5cm H)
Item Weight:	15.7 Pounds
Special Feature:	BBQ Grill Rack
Dishwasher Safe Parts:	No

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer. Keep your proof of purchase for any warranty claims.

If you encounter any issues or have questions regarding your 12L Electric Air Fryer, please reach out to the manufacturer's customer service or the point of purchase for assistance.