

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SANNCE](#) /

› [SANNCE 5MP PoE Security System NVR \(Model N98PBM2-58EW\) - Instruction Manual](#)

## SANNCE N98PBM2-58EW

# SANNCE 5MP PoE Security System NVR (Model N98PBM2-58EW) - Instruction Manual

Your guide to setup, operation, and maintenance.

## 1. INTRODUCTION

This manual provides essential information for the installation, configuration, and operation of your SANNCE 5MP PoE Security System. This system includes an 8-channel 6MP Surveillance NVR and 8 units of 5MP HD Weatherproof Dome Cameras, along with a pre-installed 2TB HDD for storage. Please read these instructions carefully before use to ensure proper functionality and safety.



Figure 1: SANNCE 5MP PoE Security System components.

## 2. WHAT'S IN THE BOX

---

Verify that all items listed below are included in your package:

- NVR (Network Video Recorder) x 1
- 5MP Dome Camera x 8
- 2TB HDD (Pre-installed) x 1
- Power Adapter x 1
- USB Mouse x 1
- User Manual for NVR x 1
- User Manual for Camera x 4
- Drill Template x 4
- 24-Hour Video Surveillance Wall Sticker x 4
- Waterproof Lid x 4
- Mounting Screw Bags x 4
- 1.8M HDMI Cable x 1
- 1M Network Cable x 1
- 18M Network Cable x 2
- 30M Network Cable x 2

*Video 1: Unboxing and overview of the SANNCE 5MP PoE Security System components.*

## What's in the Box



1X NVR



4X Camera



1X Power Adapter



1X USB Mouse



1X User Manual for NVR



4X User Manual for Camera




4X Drill Template



4X Wall Sticker



4X Waterproof Lid



4X Mounting Screw Bags



1X 1.8M HDMI Cable



1X 1M Network Cable



2X 18M Network Cable



2X 30M Network Cable

Figure 2: All included accessories and main units.

### 3. SETUP INSTRUCTIONS

#### 3.1 Initial NVR Connections

1. Connect the USB mouse to an available USB port on the NVR.
2. Connect the NVR to a monitor using the provided HDMI cable.
3. Connect the NVR's LAN port to your router using an Ethernet cable to ensure Internet access.

4. Connect the power adapter to the NVR's DC 48V input and then to a power outlet.
5. Power on the NVR using the switch on the back panel.

### 3.2 Camera Connections (PoE)

The SANNCE PoE system simplifies installation by transmitting both power and data through a single Ethernet cable. Connect each 5MP Dome Camera to the PoE ports on the NVR using the provided network cables.



Figure 3: Simplified PoE connection for cameras.

### 3.3 NVR Activation and Initial Setup

Upon first boot, the NVR will guide you through a quick setup wizard. Follow the on-screen prompts to:

- Select your preferred language.
- Set a strong password for the administrator account.
- Configure network settings (DHCP is usually recommended for automatic setup).
- Format the pre-installed 2TB HDD if prompted.
- The NVR will automatically detect and configure the connected PoE cameras.

*Video 2: Step-by-step guide on connecting the PoE CCTV system and initial NVR setup.*

### **3.4 Mobile App Setup for Remote Access**

For remote viewing and control, download the SANNCE mobile application from your device's app store. Follow these steps:

1. Install the SANNCE app on your smartphone or tablet.
2. Create an account and log in.
3. Add your NVR device by scanning the QR code displayed on the NVR's monitor during setup, or by manually entering the device ID.
4. Once added, you can view live feeds, access playback, and configure settings remotely.

# Supports Multi-Device Login & View Simultaneously

(Smartphone, Tablet, Computer, etc.)



Figure 4: Multi-device login and viewing capabilities.

## 4. OPERATING INSTRUCTIONS

### 4.1 Live View and Playback

Access live video feeds from all connected cameras via the NVR's monitor, desktop client, or mobile app. The system supports smart playback, allowing you to easily review recorded footage based on events or specific timeframes.

**Remote Preview & Playback Anytime, Anywhere,  
Control Security Instantly.**



Figure 5: Remote preview and playback interface.

#### 4.2 Smart Human/Vehicle Detection

The system features an upgraded AI algorithm for accurate human and vehicle detection, significantly reducing false alarms caused by environmental factors. Motion Detection 2.0 ensures you are only alerted to relevant activities.



*Figure 6: AI-Powered Human/Vehicle Detection.*

#### 4.3 Night Vision

Equipped with Smart IR LED technology, the dome cameras provide clear night vision up to 100ft (30m). This ensures continuous monitoring even in low-light or complete darkness.

**The Image is Cleaner,  
The Night Vision is Clearer**



*Figure 7: Enhanced night vision clarity.*

#### **4.4 H.265 Video Compression**

The system utilizes S+265/H.265 video compression technology, which efficiently saves up to 75% of recording space compared to older standards. This allows for extended recording times on the 2TB HDD.



Figure 8: H.265 video compression for efficient storage.

## 5. MAINTENANCE

### 5.1 Hard Drive (HDD) Management

The NVR comes with a pre-installed 2TB HDD. For optimal performance, ensure the HDD is properly connected and formatted. Regularly check the HDD status through the NVR's system settings.

*Video 3: Instructions for troubleshooting 'HDD not found' issues.*

### 5.2 Camera Care

The 5MP Dome Cameras are IP67 weatherproof, designed to withstand various environmental conditions. Periodically clean the camera lenses to ensure clear image quality. Be aware that insects like spiders may build webs near the lens, which can obstruct the view; regular cleaning is recommended.



Figure 9: IP67 Weatherproof rating for outdoor use.

## 6. TROUBLESHOOTING

### 6.1 HDD Not Found

If the NVR displays an 'HDD not found' error, first ensure the NVR is powered off. Carefully open the NVR casing and check that the SATA data and power cables are securely connected to the HDD. Re-secure any loose connections. If the issue persists, the HDD may need replacement.

*Video 4: Detailed steps to troubleshoot 'HDD not found' issues.*

### 6.2 Camera Connectivity Issues / Resetting a Camera

If a camera is not displaying video or experiencing connectivity problems, ensure its PoE connection to the NVR is secure. If the problem continues, you may need to reset the camera. Locate the reset button (often on the camera's cable or inside a weatherproof cover) and press and hold it for 6-10 seconds while the camera is powered on.

## 6.3 Remote Access Problems

If you experience difficulty connecting to the system via the mobile app, ensure your NVR has a stable internet connection and that the app is updated to the latest version. Verify that the device ID and password entered in the app are correct.

## 7. SPECIFICATIONS

Feature	Detail
Brand	SANNCE
Model Number	N98PBM2-58EW
Connectivity Technology	PoE
Video Capture Resolution	6MP (NVR), 5MP (Cameras)
Number of Channels	8
Special Feature	PoE Support, Smart Human/Vehicle Detection, H.265 Video Compression, Smart IR LED, APP Push Alert, Remote Access
Storage	2TB HDD (Pre-installed)
Night Vision Range	100 Feet
Viewing Angle	110 Degrees
Weatherproof Rating	IP67
Frame Rate	30 fps
Item Dimensions L x W x H	10 x 2 x 2.7 inches
Item Weight	21 pounds

## 8. WARRANTY AND SUPPORT

For product support, technical assistance, or warranty inquiries, please contact SANNCE customer service. Refer to the contact information provided in your Quick Start Guide or visit the official SANNCE website.