

ANJANK KX213

ANJANK KX213 Extra Loud Alarm Clock with Wireless Vibration Manual

Model: KX213

1. INTRODUCTION

Thank you for choosing the ANJANK KX213 Extra Loud Alarm Clock. This device is designed to provide a reliable and customizable wake-up experience, especially for deep sleepers, teenagers, and individuals with hearing difficulties. It features a wireless vibration shaker, multiple alarm modes, a customizable time display, and a multi-color night light. Please read this manual thoroughly to understand the product's functions and ensure proper use.

2. PACKAGE CONTENTS

- Alarm Clock x 1
- Wireless Bed Shaker x 1
- Power Adapter with Cable x 1
- User Manual x 1
- Tip Card x 1

3. PRODUCT OVERVIEW

The ANJANK KX213 alarm clock combines several features to ensure an effective wake-up. Key components include the main alarm clock unit with a digital display, a wireless vibration shaker, and various control buttons for settings.

Powerful Wireless Vibrations

Effectively wake you up, no matter how deeply you sleep
3 Level Intensity: High/Mid/Low



Image: The ANJANK KX213 alarm clock and its wireless bed shaker, illustrating the product's design and components.

4. SETUP

1. **Power Connection:** Connect the provided power adapter to the alarm clock and plug it into a standard AC 100-240V outlet. The alarm clock requires continuous power to operate.
2. **Bed Shaker Charging:** The wireless bed shaker has a built-in 1500mAh battery. Charge it using the magnetic or Type-C port. A full charge typically lasts 2-3 months.
3. **Initial Time Setting:** Upon first power-up, the display will show a default time. Refer to the "Setting Time" section for instructions on adjusting the time.

112dB front facing super loud sound!

Custom 10-level volume



Chime



Birdsong



Buzzer Sound



2 Loud Sharp Sounds



Image: The wireless bed shaker being charged, highlighting its magnetic and Type-C charging options.

5. OPERATING INSTRUCTIONS

5.1 Setting Time

Detailed instructions for setting the current time will be provided in the full manual. Generally, a "Time Set" button or a combination of buttons is used to enter time setting mode, followed by adjustment buttons (e.g., +/-, Up/Down) to set hours and minutes.

5.2 Setting Alarms

The clock supports two separate alarms. To set an alarm:

1. Press the "Alarm 1" or "Alarm 2" button to enter alarm setting mode.
2. Use the adjustment buttons to set the desired alarm time.
3. Select the alarm tone from the 8 available options.
4. Adjust the alarm volume (10 levels available).
5. Choose the desired alarm mode (S01, S02, S03).
6. Confirm settings by pressing the alarm button again or waiting for it to exit setting mode automatically.

Vibrant mood lighting

Vivid and colorful night light and time display



Precise 6-Level Brightness

Image: Illustration of the alarm clock's speaker and various alarm tone options, including chime, birdsong, buzzer, and two loud sharp sounds.

5.3 Adjusting Display Brightness and Color

The time display brightness can be adjusted from 0% to 100%. Use the dedicated dimmer button or a combination of buttons to cycle through brightness levels. The display color can also be customized to white, red, blue, or an RGB gradient.

Practical Type-C Output Power Port

Your Bedside Helper, Say Goodbye to Charging Anxiety



Image: The alarm clock display at different brightness levels (0-100% dimmer), showing visibility in various lighting conditions.

5.4 Using the Night Light

Press the "Light" button to activate the night light. Cycle through the 9 available colors (orange, yellow, red, green, cyan, blue, purple, white, rainbow) and 6 brightness levels. The lowest setting can turn off the screen completely for complete darkness.

0-100% dimmer, see time your way

Soft glow for night, full brightness for day.



Image: Three alarm clocks displaying different vibrant mood lighting colors, illustrating the 9-color night light feature.

6. FEATURES

6.1 Wireless Vibration Shaker

The wireless bed shaker provides powerful vibrations to wake deep sleepers without disturbing others. Place it under your pillow. It has a 1500mAh battery lasting 2-3 months on a full charge and a reliable wireless range of 10 meters (32.8 ft). Adjust the vibration strength to high, medium, or low.

Rise with ease in 3 refined modes



Image: The ANJANK alarm clock on a bedside table with the wireless vibration shaker placed under a pillow, demonstrating its use for effective waking.

6.2 Alarm Modes

Choose from three distinct alarm modes:

- **S01 Mode:** Alarm tone + Bed shaker + Orange light for a comprehensive sensory wake-up.
- **S02 Mode:** Alarm sound + Bed shaker for a more intense wake-up.
- **S03 Mode:** Only alarm sound for a traditional alarm experience.

Power that lasts

Wireless shaker at its best

2-3 months of battery life

Magnetic or Type-C rechargeable



Image: A visual representation of the three alarm modes: Vibration, light, and sound; Vibration and sound; and Sound alone.

6.3 Dual Alarm Functionality

Set two independent alarms. Select from 8 progressive alarm sounds, including 2 shrill tones for hearing-impaired users, a bell, birdsong, or a buzzer. The volume is adjustable across 10 levels, with a maximum of 112 dB.

6.4 USB-C Charging Port

The alarm clock includes a built-in Type-C output port, allowing you to conveniently charge your smartphone or other devices overnight.



Image: The ANJANK alarm clock with a smartphone connected to its Type-C output port, demonstrating its charging capability.

6.5 Memory Function

A built-in CR2023 battery ensures that your settings (time, alarms, etc.) are saved during a power outage, eliminating the need for re-configuration.

7. MAINTENANCE

- Clean the alarm clock and shaker with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Keep the device away from water and high humidity.
- Ensure proper ventilation around the unit.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Alarm clock does not power on.	Not connected to power, or power adapter issue.	Ensure the power adapter is securely connected to the clock and a working power outlet.
Wireless shaker not vibrating.	Shaker battery is low or depleted; out of range.	Charge the bed shaker. Ensure it is within 10 meters of the alarm clock.

Problem	Possible Cause	Solution
Alarm sound is too low or too loud.	Volume setting is incorrect.	Adjust the alarm volume using the dedicated controls (10 levels available).
Display is too bright or too dim.	Brightness setting needs adjustment.	Use the dimmer function to adjust display brightness from 0-100%.

9. SPECIFICATIONS

- **Model:** KX213
- **Dimensions:** 17.5 cm (L) x 8.5 cm (W) x 14.5 cm (H)
- **Weight (with shaker):** 531.5g
- **Power Supply:** AC 100-240V, 5V/2A
- **Bed Shaker Battery:** 1500mAh (lasts 2-3 months on full charge)
- **Charging Port:** USB-C (for clock and bed shaker)
- **Alarm Volume:** Up to 112 dB (10 levels)
- **Night Light Colors:** 9 colors (Orange, Yellow, Red, Green, Cyan, Blue, Purple, White, Rainbow)
- **Display Dimmer:** 0-100%
- **Memory Backup:** CR2023 battery

10. WARRANTY AND SUPPORT

ANJANK products are manufactured to high-quality standards. For warranty information or technical support, please refer to the contact details provided on the tip card included in your package or visit the official ANJANK website. Keep your purchase receipt for warranty claims.