Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- WAVLINK /
- WAVLINK AXE5400 PCIe WiFi 6E Tri-Band Wireless Network Card with Bluetooth 5.3 User Manual

WAVLINK AXE5400

WAVLINK AXE5400 PCIe WiFi 6E Tri-Band Wireless Network Card with Bluetooth 5.3 User Manual

Model: AXE5400 (WN675X3-C)

1. Introduction

The WAVLINK AXE5400 PCIe WiFi 6E Tri-Band Wireless Network Card is designed to enhance your desktop computer's wireless connectivity and performance. Powered by the Intel AX210 chip, this adapter supports the latest Wi-Fi 6E standard, offering tri-band speeds across 2.4GHz, 5GHz, and the new 6GHz frequency bands. It also integrates Bluetooth 5.3 for seamless connection with compatible peripherals.

Key features include:

- Tri-Band Speeds: Up to 574Mbps (2.4GHz), 2400Mbps (5GHz), and 2400Mbps (6GHz) for a combined AX5400Mbps.
- Intel AX210 Chip: Ensures reliable and high-performance wireless connectivity.
- Bluetooth 5.3: Provides faster speeds and extended range for Bluetooth devices.
- Advanced Technologies: Supports OFDMA, MU-MIMO, and 1024-QAM for improved efficiency and reduced latency in crowded networks.
- Enhanced Security: Features WPA3 encryption for robust network protection.
- High-Gain Antennas: Dual 5dBi external antennas boost signal strength and coverage.
- Broad Compatibility: Works with Windows 10/11 (64-bit) and Linux operating systems, fitting PCle X1/X4/X8/X16 slots.

2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- 1x WiFi 6E Tri-Band AX5400 PCIe Adapter with Bluetooth 5.3
- 1x Bluetooth Cable
- 2x High-Gain Antennas
- 1x Low Profile Bracket
- 3x Screws
- 1x Drivers Download Card



Image: Contents of the WAVLINK AXE5400 package, including the PCIe card, antennas, cables, and documentation.

3. SPECIFICATIONS

| Brand | WAVLINK |
|--------------------|---|
| Model | AXE5400 (WN675X3-C) |
| Hardware Interface | PCIE x 1 (Compatible with PCIe X1/X4/X8/X16 slots, not PCI) |
| Data Link Protocol | Bluetooth, Gigabit Ethernet (Wireless) |
| Data Transfer Rate | 5400 Megabits Per Second (Combined) |
| Wi-Fi Bands | 2.4GHz (574Mbps), 5GHz (2400Mbps), 6GHz (2400Mbps) |
| Bluetooth Version | 5.3 |
| Antennas | 2x 5dBi High-Gain Antennas |

| Compatible Devices | Desktop, Game Console, Headphone, Keyboard, Mouse |
|--------------------|---|
| Operating Systems | Windows 10/11 (64-bit), Linux |
| Item Weight | 7 ounces |
| Package Dimensions | 8.78 x 5.43 x 1.02 inches |

4. SETUP GUIDE

Follow these steps to install your WAVLINK AXE5400 PCIe adapter:

- 1. Prepare Your PC: Power off your computer and unplug all cables. Open the PC case to access the motherboard.
- 2. **Install the PCle Card:** Locate an available PCle slot (X1, X4, X8, or X16). Carefully insert the WAVLINK AXE5400 adapter into the slot until it is firmly seated. Secure the card with a screw if your case requires it.



Image: Diagram showing compatible PCIe slots and the Bluetooth USB header connection.

- 3. **Connect Bluetooth Cable (Optional):** For Bluetooth functionality, connect the small end of the provided Bluetooth cable to the adapter's Bluetooth header. Connect the other end (9-pin USB connector) to an available F_USB header on your motherboard.
- 4. **Attach Antennas:** Connect the two high-gain antennas to the gold-plated connectors on the back of the PCIe card. You can adjust their angle for optimal signal reception.



Image: The WAVLINK AXE5400 PCIe card with its two high-gain antennas and Bluetooth cable.

5. Close PC Case: Once the card and cables are securely installed, close your PC case.

 Power On and Install Drivers: Reconnect all cables and power on your computer. Visit the official WAVLINK website (www.wavlink.com/en_us/drivers.html) to download the latest drivers for your specific model (WN675X3-C). Install both the Wi-Fi and Bluetooth drivers.

Installation Video Guide

Your browser does not support the video tag.

Video: A detailed guide on installing the WAVLINK WiFi 6E PCle AX5400M WiFi Card with Bluetooth 5.3 into a desktop computer, covering physical installation and driver setup.

Your browser does not support the video tag.

Video: An unboxing and installation overview of the WAVLINK PCIe WiFi 6E WiFi Card, demonstrating the physical setup process within a PC case.

5. OPERATING INSTRUCTIONS

5.1. Connecting to Wi-Fi

- 1. After successful driver installation, click on the Wi-Fi icon in your system tray (usually bottom-right corner of the screen).
- 2. A list of available wireless networks will appear. Select your desired network (2.4GHz, 5GHz, or 6GHz band).
- 3. Enter the network security key (password) if prompted, and click 'Connect'.
- 4. Your computer should now be connected to the Wi-Fi network.

5.2. Connecting Bluetooth Devices

- 1. Ensure the Bluetooth cable is connected to your motherboard's USB header and the adapter.
- 2. Go to your computer's 'Settings' (e.g., Windows: Start Menu > Settings > Bluetooth & devices).
- 3. Turn on Bluetooth.
- 4. Put your Bluetooth device (e.g., headphones, keyboard, mouse) into pairing mode.
- 5. On your computer, click 'Add device' or 'Add Bluetooth or other device' and select 'Bluetooth'.
- 6. Select your device from the list and follow any on-screen prompts to complete the pairing process.



Image: Diagram illustrating Bluetooth 5.3 connectivity with various devices like keyboards, mice, gamepads, and audio devices.

6. MAINTENANCE

- **Driver Updates:** Regularly check the WAVLINK website for updated drivers to ensure optimal performance and compatibility.
- **Physical Inspection:** Periodically check the antenna connections and the PCle card's seating within the slot to ensure they are secure.

• Cleaning: Keep your PC case and the adapter free from dust to maintain proper airflow and heat dissipation.

7. TROUBLESHOOTING

. No Wi-Fi or Bluetooth Detected:

- Ensure the PCIe card is correctly seated in its slot.
- Verify that the Bluetooth cable is securely connected to both the adapter and the motherboard's USB header.
- Check Device Manager (Windows) to see if the adapter is recognized and if there are any driver issues.
 Reinstall drivers if necessary.

• Poor Signal Strength or Slow Speeds:

- Adjust the position and angle of the external antennas for better reception.
- Ensure your Wi-Fi router supports Wi-Fi 6E and is configured for optimal performance.
- Minimize obstructions between your PC and the Wi-Fi router.
- · Update your Wi-Fi router's firmware.

• Bluetooth Device Not Pairing:

- Ensure the Bluetooth cable is properly connected.
- Verify your Bluetooth device is in pairing mode and within range.
- Remove and re-add the Bluetooth device in your computer's settings.

8. WARRANTY AND SUPPORT

The WAVLINK AXE5400 PCIe adapter comes with a **12-month warranty**. Registered users may receive an extended **18-month warranty**. Lifetime technical support is also provided.

For technical assistance or warranty claims, please contact WAVLINK support:

- Email: support@wavlink.com
- Live Chat Support: Visit www.wavlink.com
- Phone (US Local): +1(888)973-0883 (Mon-Fri 09:00 am 10:00 pm UTC-5)

Related Documents - AXE5400



Wavlink WiFi Adapter Troubleshooting Guide

A troubleshooting guide for common issues encountered with Wavlink WiFi adapters, including device detection, driver installation, and WiFi connectivity problems. Provides step-by-step solutions and configuration advice.

