

[Manuals.plus](#) /

› [e-vibra](#) /

› e-vibra W15 Potty Training & Medical Reminder Vibrating Alarm Watch User Manual

e-vibra W15

e-vibra W15 Vibrating Alarm Watch User Manual

Model: W15

INTRODUCTION

Thank you for choosing the e-vibra W15 Vibrating Alarm Watch. This device is designed to provide discreet, silent reminders through vibration, making it ideal for potty training, medical reminders, or as a gentle wake-up alarm. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.

PRODUCT OVERVIEW

The e-vibra W15 is a rechargeable wristband featuring a digital display and silent vibrating alarms. Its simple design allows for easy programming directly on the watch, without the need for a computer or mobile phone.



Image: The e-vibra W15 vibrating alarm watch in red, displaying the time 8:00.



Image: A person wearing the e-vibra W15 vibrating alarm watch, which displays the time and date.

FEATURES

- **Timer Function:** Preset repeat interval timers for 1, 5, 10, 15, 30, 45, 60, 90, 120, or 180 minutes. The auto-repeating vibration provides continuous reminders throughout the day.
- **Multiple Alarm Settings:** Set up to 15 distinct vibrating alarms per day at specific times. Alarms feature auto-repeating vibration and a strong 60-second silent wake-up.
- **Strong Vibrating Alarm:** Provides silent, powerful vibrations for discreet reminders without disturbing others. Ideal for potty training, medication schedules, homework, or waking up.
- **Comfortable Design:** Made with a soft silicone wristband, designed to fit wrists approximately 4 to 8.1 inches.
- **Simple Setup:** Easy programming directly on the watch. Supports 12/24 hour format.
- **Long Battery Life:** Provides 10-20 days of use on a single full charge.



Image: The e-vibra W15 watch functioning as a wake-up alarm.



Image: The e-vibra W15 watch used for water drinking and medical reminders.

SETUP

Charging the Device

Before initial use, fully charge your e-vibra W15 watch. The watch features a built-in USB charging port. Simply remove the watch module from the silicone band and plug it into any standard USB port (e.g., computer, wall adapter).



Image: The e-vibra W15 watch module connected to a USB charging cable for power.



Image: The e-vibra W15 watch module plugged into a USB port for charging.

OPERATING INSTRUCTIONS

The e-vibra W15 watch is operated using its two side buttons. A short press typically cycles through modes or displays information, while a long press enters setting modes.

Setting Current Time

To set the current time:

1. Press the button to display the current time.
2. Long press the button until the hour digits begin to flash.
3. Short press to adjust the hour.
4. Long press to switch to minute adjustment.
5. Short press to adjust the minutes.
6. Long press again to confirm and exit time setting.

Video: Instructions on how to set the current time and alarms on the e-vibra W15 vibrating watch.

Setting Alarms

The watch supports up to 15 daily alarms. To set an alarm:

1. From the time display, short press the button until "ALM" appears, then the alarm time.
2. Long press the button until the alarm hour digits flash.
3. Short press to adjust the alarm hour.
4. Long press to switch to alarm minute adjustment.
5. Short press to adjust the alarm minutes.
6. Long press again to confirm and activate the alarm. Repeat for additional alarms.

Setting the Timer Function

The timer function provides repeating vibrations at set intervals.

1. From the time display, short press the button until the timer setting (e.g., "00" for off, or a minute value) appears.
2. Long press the button until the timer value flashes.
3. Short press to cycle through available timer intervals: 1, 5, 10, 15, 30, 45, 60, 90, 120, 180 minutes. Select "00" to turn off the timer.

4. Long press again to confirm and activate the timer. The timer will begin counting down and repeat automatically.

Video: A demonstration of the e-vibra 15 alarm vibrating watch features and operation.



Image: The e-vibra W15 watch worn on a wrist, displaying the current time.



Image: A hand interacting with the e-vibra W15 watch, demonstrating its ease of use for programming.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the watch and band with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Water Resistance:** The watch is water-resistant, meaning it can withstand splashes or brief exposure to water. It is not suitable for swimming, showering, or prolonged submersion.
- **Battery:** The built-in rechargeable battery provides extended use. Recharge when the battery indicator is low. Avoid overcharging for prolonged periods.
- **Band Durability:** The silicone wristband is designed for comfort. While durable, excessive stretching or force may affect its integrity over time.

TROUBLESHOOTING

- **Watch Not Turning On/Charging:** Ensure the watch module is correctly inserted into a functioning USB port. Allow a few minutes for the charging indicator to appear. If the watch has been completely drained, it may take longer to respond.
- **Alarms Not Vibrating:** Verify that alarms are correctly set and activated. Check the battery level.
- **Incorrect Time Display:** Re-enter the time setting mode and adjust the hours and minutes as per the operating instructions.
- **Band Loosening:** If the silicone band stretches over time, ensure the watch module is securely fitted. Replacement bands may be available from the manufacturer.

SPECIFICATIONS

Model Number	W15
Display Type	Digital
Band Material	Silicone
Water Resistance Level	Water Resistant (Splashes only)
Power Source	Rechargeable Battery
Wrist Fit	Approx. 4" to 8.1"

WARRANTY INFORMATION

This e-vibra product comes with a limited warranty. Please refer to the product packaging or contact customer support for specific

warranty terms and conditions.

SUPPORT

For further assistance, technical support, or inquiries regarding your e-vibra W15 Vibrating Alarm Watch, please refer to the contact information provided with your product packaging or visit the official e-vibra website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question