

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Phomemo](#) /

› [Phomemo M834 Bluetooth Thermal Printer User Manual](#)

Phomemo M834

Phomemo M834 Bluetooth Thermal Printer User Manual

Model: M834

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Phomemo M834 Bluetooth Thermal Printer. The M834 is a portable, inkless thermal printer designed for high-clarity document printing, offering 300 dpi resolution and versatile paper compatibility. It supports both Bluetooth and USB connections for various devices.



Image 1.1: The Phomemo M834 thermal printer in use, connected to a smartphone, printing documents.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Phomemo M834 Thermal Printer
- USB Charging Cable
- 200 Sheets of Folded Thermal Printer Paper (8.5" x 11")
- User Manual (this document)




Image 2.1: A box containing 200 sheets of Phomemo M08F Letter-sized thermal paper.

3. INITIAL SETUP

3.1 Charging the Printer

Before first use, fully charge the printer. Connect the provided USB cable to the printer's charging port and a power adapter (not included) or a computer's USB port. The indicator light will show charging status.

3.2 Installing the Phomemo App


For mobile printing, download the 'Phomemo' app from your device's app store (available for iOS and Android). Follow the in-app instructions for initial setup and pairing.

3.3 Loading Thermal Paper

The Phomemo M834 supports various thermal paper types, including folded sheets. Ensure the paper is inserted correctly for optimal printing.

1. Open the paper cover of the printer.
2. Insert the thermal paper with the printable side facing up. For folded paper, ensure it feeds smoothly from the stack.
3. Adjust the paper guides to fit the width of the paper.
4. Close the paper cover securely.

Phomemo Continuous Folding Paper



Sheets



Thermal Paper



Clear Print



Inkless Printing

Image 3.1: Illustration of Phomemo continuous folding paper, showing 8.5" x 11" dimensions.




Image 3.2: A hand demonstrating how to easily tear thermal paper along its perforated edge after printing.

4. OPERATING THE PRINTER

4.1 Connecting via Bluetooth (Mobile Devices)

The M834 printer connects wirelessly to smartphones and tablets via Bluetooth.

1. Ensure the printer is powered on and within range of your mobile device.
2. Enable Bluetooth on your mobile device.
3. Open the Phomemo app. The app will guide you to discover and pair with the M834 printer.
4. Once paired, you can select documents or images within the app to print.

4.2 Connecting via USB (Computers)

For Windows, macOS, Linux, and ChromeOS computers, connect the printer using the provided USB cable.

1. Connect one end of the USB cable to the printer and the other end to your computer.
2. The computer should automatically detect the printer. If necessary, install the appropriate printer drivers from the Phomemo official website.
3. Once installed, the M834 will appear as an available printer in your system's print dialogue.



Image 4.1: Visual representation of the two connection methods: Bluetooth for mobile devices (Android, iOS, Tablets) and USB for computers (Windows, Mac OS, Chrome OS, Linux).

4.3 Printing Documents

After connecting, select the document or image you wish to print from your device. Adjust print settings such as paper size (US Letter, A4, 4.33", 3.14", 2.08") and orientation as needed before initiating the print job.




Image 4.2: A side-by-side comparison highlighting the enhanced clarity of 300dpi printing (Phomemo M834) compared to 203dpi.

5. MAINTENANCE

5.1 Cleaning the Print Head

To maintain print quality, periodically clean the print head. Use a cotton swab lightly dampened with isopropyl alcohol. Gently wipe the print head surface. Allow it to dry completely before use.

5.2 General Care

- Keep the printer in a clean, dry environment.
- Avoid exposing the printer to direct sunlight or extreme temperatures.
- Use only Phomemo-approved thermal paper for optimal results and to prevent damage.
- Do not attempt to disassemble the printer.



Image 5.1: Information highlighting the use of BPA-Free thermal paper, emphasizing its inkless and harmless properties.

6. TROUBLESHOOTING

6.1 No Print Output

- **Check Power:** Ensure the printer is powered on and has sufficient battery charge.
- **Paper Loading:** Verify that thermal paper is loaded correctly with the printable side facing up.
- **Connection:** Confirm that the printer is properly connected via Bluetooth or USB.

6.2 Poor Print Quality

- **Clean Print Head:** A dirty print head can cause streaks or faded prints. Refer to Section 5.1.
- **Paper Quality:** Ensure you are using high-quality thermal paper.
- **Paper Orientation:** Make sure the thermal paper is inserted with the correct side facing the print head.

6.3 Bluetooth Connection Issues

- **Restart Devices:** Turn off and on both the printer and your mobile device.
- **Forget Device:** In your device's Bluetooth settings, 'forget' or 'unpair' the M834 and then attempt to pair again through the Phomemo app.
- **App Permissions:** Ensure the Phomemo app has necessary Bluetooth permissions.

7. SPECIFICATIONS

Feature	Specification
Model	Phomemo M834
Print Resolution	300 dpi
Printing Technology	Thermal (Inkless)
Connectivity	Bluetooth, USB
Battery Capacity	2600mAh (up to 160+ pages continuous printing)
Supported Paper Sizes	US Letter, A4, 4.33", 3.14", 2.08"
Supported Paper Types	Roll, Fold, Ordinary Thermal Paper
Supported Operating Systems	Android, iOS, Windows 10/11, Linux, ChromeOS, macOS

8. WARRANTY AND SUPPORT

8.1 Warranty Information

For detailed warranty information, please refer to the warranty card included with your product or visit the official Phomemo website. Warranty terms and conditions may vary by region and purchase date.

8.2 Customer Support

If you encounter any issues or have questions not covered in this manual, please contact Phomemo customer support through their official website or the contact information provided in your product packaging. When contacting support, please have your product model (M834) and purchase details ready.

[illegible]

Comprehensive troubleshooting guide for the Phomemo T310 Desktop Barcode Printer, covering common issues such as printing errors, paper feed problems, print quality issues, and connectivity problems with solutions for both thermal and thermal transfer modes.

A comprehensive quick guide for the Phomemo M08F portable printer, covering setup, app installation, paper loading, connectivity, driver downloads, and warranty information. Learn how to operate and maintain your M08F thermal printer for optimal performance.

