

[Manuals.plus](#) /

› [OOTD](#) /

› OOTD T10 Electric Scooter User Manual

OOTD OOTD T10

OOTD T10 Electric Scooter User Manual

Brand: OOTD | Model: T10

INTRODUCTION

Welcome to the user manual for your new OOTD T10 Electric Scooter. This powerful and versatile electric scooter is designed for both urban commuting and outdoor adventures, offering a blend of performance, safety, and convenience. With its 500W brushless motor (900W peak), 11-inch all-terrain tires, dual suspension, and a 48V 13.5Ah lithium battery, the T10 provides a smooth and stable ride. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your scooter to ensure a safe and enjoyable experience.



The OOTD T10 Electric Scooter in use, demonstrating its suitability for urban environments and leisure.

SAFETY INFORMATION

Your safety is paramount. Please read and understand all safety warnings and instructions before operating the OOTD T10 Electric Scooter. Failure to follow these instructions may result in serious injury or damage to the scooter.

- **Always wear a helmet and appropriate protective gear**(knee pads, elbow pads, wrist guards) when riding.

- Ensure all bolts and fasteners are securely tightened before each ride. Regularly check the brakes and tires.
- Obey all local traffic laws and regulations. Ride defensively and be aware of your surroundings.
- Do not ride in wet conditions, on slippery surfaces, or in heavy rain.
- Avoid riding at night or in low visibility conditions unless the scooter's lights are fully functional and you are clearly visible.
- Do not perform stunts, jumps, or aggressive maneuvers.
- The maximum weight capacity for the OOTD T10 is **150 kg (330 lbs)**. Do not exceed this limit.
- This scooter is intended for adult use. Check local age restrictions for electric scooter operation.
- Maintain a safe distance from other vehicles and pedestrians.
- Do not operate the scooter under the influence of alcohol or drugs.

PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are included:

- OOTD T10 Electric Scooter x 1
- Instructions du produit (Product Instructions) x 1
- Outils d'installation (Installation Tools) x 1
- Clé pour tige de montage (Mounting Rod Wrench) x 1
- Chargeur (Charger) x 1

If any items are missing or damaged, please contact customer support immediately.

PRODUCT OVERVIEW

Familiarize yourself with the main components of your OOTD T10 Electric Scooter.



Overview of the OOTD T10 Electric Scooter, highlighting its dimensions and key features like the large deck and dual suspension.

- **Handlebar:** Controls for acceleration, braking, and display.
- **LED Display:** Shows speed, battery level, and riding mode.
- **Headlights & Taillights:** For visibility and safety.

- **Folding Mechanism:** Allows for compact storage and transport.
- **Deck:** The standing platform, designed for comfort and stability.
- **11-inch All-Terrain Tires:** Provide excellent grip and shock absorption.
- **Dual Suspension:** Enhances ride comfort on various terrains.
- **Disc Brakes:** Front and rear for responsive and powerful stopping.
- **Motor:** Integrated into the wheel for efficient power delivery.

SETUP

Assembly

Your OOTD T10 scooter comes mostly pre-assembled. Follow these steps to complete the setup:

1. **Unpack the Scooter:** Carefully remove the scooter and all accessories from the packaging.
2. **Raise the Handlebar Stem:** Lift the handlebar stem until it locks into the upright position. Ensure the folding mechanism is securely latched.
3. **Attach the Handlebars:** Connect the handlebars to the stem. Ensure all cables are properly routed and not pinched. Tighten any screws or clamps using the provided installation tools.
4. **Check Tire Pressure:** Inflate the 11-inch pneumatic tires to the recommended pressure (refer to the tire sidewall for details).
5. **Initial Charge:** Before your first ride, fully charge the scooter's battery. Refer to the "Charging the Battery" section for detailed instructions.
6. **Perform Safety Checks:** Before each use, ensure brakes are functional, tires are properly inflated, and all connections are secure.

OPERATING INSTRUCTIONS

Power On/Off

- To turn on the scooter, press and hold the power button on the display for a few seconds.
- To turn off the scooter, press and hold the power button again until the display shuts off.

Riding Modes

The OOTD T10 features 3 speed modes to suit different riding conditions and preferences. You can switch between modes using the mode button on the handlebar.

- **Mode 1 (Eco):** Lower speed for maximum range and beginner riders.
- **Mode 2 (Standard):** Balanced speed and power for everyday commuting.
- **Mode 3 (Sport):** Maximum speed and power for experienced riders and challenging terrains.

The maximum speed is 25 km/h (regulated), with a potential maximum of 55 km/h in Sport mode (where permitted by law).

Acceleration and Braking

- **Acceleration:** Use the thumb throttle on the right handlebar to accelerate. Gradually apply pressure for smooth acceleration.
- **Braking:** The scooter is equipped with front and rear disc brakes. Use the brake levers on the handlebars to slow down or stop. Apply both brakes simultaneously for optimal stopping power and control.

LED Display Functions

The large LED display provides real-time information about your ride:



The multi-function LED display provides essential riding data at a glance.

- **Speed Display:** Shows your current speed.
- **Battery Level:** Indicates the remaining battery charge.
- **Riding Mode Indicator:** Shows the currently selected speed mode.
- **Total Mileage (Odometer):** Tracks the total distance traveled.
- **Trip Mileage:** Displays the distance for the current ride.

CHARGING THE BATTERY

To ensure optimal battery life and performance, follow these charging guidelines:

1. Ensure the scooter is turned off before charging.
2. Locate the charging port on the scooter (usually covered by a rubber flap).
3. Connect the charger to the charging port, then plug the charger into a standard wall outlet.
4. The indicator light on the charger will typically turn red during charging and green when fully charged.
5. A full charge takes approximately **4-5 hours**. Do not overcharge the battery.
6. Disconnect the charger once charging is complete and securely close the charging port cover.



The high-capacity 48V 13.5Ah lithium battery provides a long range of 35-49 km.

FOLDING AND UNFOLDING

The OOTD T10 features a convenient one-touch folding mechanism for easy storage and transport.

Folding the Scooter

1. Ensure the scooter is powered off.
2. Locate the folding latch or lever at the base of the handlebar stem.
3. Engage the release mechanism (this may involve pulling a lever or pressing a button).
4. Carefully fold the handlebar stem downwards until it clicks into place, securing it to the rear fender or a designated latch on the deck.
5. The folded dimensions are approximately 126.5 x 30.5 x 57.5 cm, making it easy to store in a car trunk or carry on public transport.

Unfolding the Scooter

1. Release the latch that secures the folded stem.
2. Lift the handlebar stem upwards until it locks securely into the upright riding position. Ensure the folding mechanism is fully engaged and stable before riding.



The OOTD T10's one-touch folding design allows for convenient portability and storage.

MAINTENANCE

Regular maintenance will extend the life of your OOTD T10 Electric Scooter and ensure safe operation.

- **Cleaning:** Wipe down the scooter with a damp cloth after each use. Do not use high-pressure water or corrosive cleaners. Avoid getting water into electrical components.
- **Tires:** Regularly check tire pressure and inflate to the recommended PSI (found on the tire sidewall). Inspect tires for wear, punctures, or damage.
- **Brakes:** Periodically check the brake levers for proper tension and ensure the disc brakes are functioning effectively. Adjust if necessary.
- **Battery Care:** Store the scooter in a cool, dry place. If storing for extended periods, charge the battery to about 50-70% every 1-2 months to prevent deep discharge.
- **Fasteners:** Check all screws, bolts, and connections regularly to ensure they are tight and secure.
- **Suspension:** Inspect the dual suspension system for any signs of damage or excessive wear.

TROUBLESHOOTING

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Scooter does not turn on.	Low battery; loose connection; power button issue.	Charge the battery fully. Check all cable connections. Try pressing the power button firmly.
Reduced range/autonomy.	Under-inflated tires; riding uphill frequently; heavy load; cold weather; old battery.	Check and inflate tires to correct pressure. Ride in Eco mode. Reduce load. Battery performance can decrease in cold.
Brakes feel weak or noisy.	Brake pads worn; disc dirty; cable loose.	Inspect brake pads for wear and replace if necessary. Clean brake discs. Adjust brake cable tension.

Problem	Possible Cause	Solution
Unusual noises during ride.	Loose components; debris in wheels; motor issue.	Check all fasteners. Inspect wheels and motor area for foreign objects. If noise persists, contact support.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact OOTD customer support.

TECHNICAL SPECIFICATIONS

Detailed specifications for the OOTD T10 Electric Scooter:

Feature	Specification
Brand	OOTD
Model Name	OOTD T10
Motor Power	500W (900W Peak)
Battery	48V 13.5Ah Lithium
Max Speed	25 km/h (regulated), up to 55 km/h (unregulated)
Range (Autonomy)	35-49 km (depending on conditions)
Charge Time	4-5 Hours
Max Climbing Angle	35°
Tire Size	11 Inches (Pneumatic, All-Terrain)
Brake Type	Front and Rear Disc Brakes
Suspension	Dual Suspension (Front and Rear)
Max Weight Capacity	150 Kilograms (330 lbs)
Product Dimensions (Unfolded)	122 x 67 x 127 cm
Product Dimensions (Folded)	126.5 x 30.5 x 57.5 cm
Net Weight	31 Kilograms (68 lbs)
Frame Material	Aluminum
Special Features	Dual Braking System, Large Platform, Foldable, LED Lights, Speedometer

Descrizione del Prodotto



25km/h
Vitesse Maximale



35-49km
Kilométrage à
Moyenne Vitesse



500W
Moteur



Nouveau Grand Écran
Instrument LED



4-5 Heures
Temps de Charge



150kg
Charge Maximale



Freins à Disque
Frontale et Réelle



3
Mode Vitesse



48V 13.5Ah
Batterie Supre Large



Amortisseur
Font-Arm



35°
Angle



11 Pouces
Feu Sans Chambre à Air

Key performance and design specifications of the OOTD T10.

WARRANTY AND SUPPORT

OOTD is committed to providing high-quality products and excellent customer service. Your OOTD T10 Electric Scooter has undergone rigorous testing to ensure its quality and durability.

- **Warranty:** OOTD offers a **12-month warranty** on various parts of the scooter. Please refer to your purchase documentation for specific warranty terms and conditions.
- **Customer Support:** If you have any questions, concerns, or require technical assistance, please contact OOTD customer service. Our dedicated support team is ready to assist you.
- **Contact Information:** Please refer to the contact details provided on the OOTD official website or your purchase receipt for the most up-to-date support channels.

For warranty claims, please retain your proof of purchase.

© 2025 OOTD. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.