

[Manuals.plus](#) /

› [VILLCASE](#) /

› VILLCASE Portable DIY Spot Welder Instruction Manual - Model 57YR25310408F

VILLCASE 57YR25310408F

VILLCASE Portable DIY Spot Welder Instruction Manual

Model: 57YR25310408F

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your VILLCASE Portable DIY Spot Welder. Please read this manual thoroughly before operation and retain it for future reference. This device is designed for hobbyists and DIY enthusiasts for precise spot welding tasks, particularly suitable for PCB and battery tab welding.

2. PACKAGE CONTENTS

Verify that all the following components are included in your package:

- 1 x Spot Welder Circuit Board
- 4 x Copper Noses (Welding Pens)
- 4 x Screws
- 1 x Buzzer
- 1 x 1-meter Nickel Sheet
- 1 x Capacitance (Capacitor)
- 2 x Input Wires (Red and Black)
- 2 x Heat Shrink Tubing




Image 2.1: All components included in the VILLCASE Portable DIY Spot Welder kit. This includes the main circuit board, welding pens, wires, and accessories.

3. KEY FEATURES

- **Compact and Portable Design:** The small size provides convenience for storage and transport, making it ideal for DIY projects.
- **Optimized for DIY Use:** Specifically designed for various DIY spot welding applications, including PCB and battery tab welding.
- **Excellent Performance:** Features stable operation with small internal resistance, ensuring efficient welding.
- **Durable Construction:** Made from quality PCB, electronic components, and metal for long-lasting reliability.
- **Voltage Compatibility:** Operates within a voltage range of 12V-14.6V.



Image 3.1: Detailed view of the circuit board, illustrating its compact design and components contributing to its performance and low internal resistance.

4. TECHNICAL SPECIFICATIONS

Specification	Value
Manufacturer	VILLCASE
Model Number	57YR25310408F
Item Weight	3.52 ounces (100 grams)
Product Dimensions	3.15 x 1.57 x 0.39 inches (8 x 4 x 1 cm)
Material	PCB, Electronic component, Metal
Operating Voltage	12V-14.6V
Color	Black




Image 4.1: Visual representation of the circuit board's dimensions, measuring approximately 3.15 inches (8 cm) by 1.57 inches (4 cm).

5. SETUP AND ASSEMBLY

Follow these steps to assemble your spot welder:

1. **Identify Components:** Lay out all components from the package and familiarize yourself with each part as listed in Section 2.
2. **Connect Input Wires:** Connect the red and black input wires to your 12V-14.6V DC power source. Ensure correct polarity: the red wire connects to the positive (+) terminal, and the black wire connects to the negative (-) terminal. Secure connections tightly.
3. **Attach Welding Pens:** Securely attach the copper noses (welding pens) to the designated output terminals on the circuit board using the provided screws. Ensure a firm, stable connection.
4. **Install Buzzer:** Connect the buzzer to its designated port on the circuit board. This buzzer provides audible feedback during operation.
5. **Final Check:** Before applying power, double-check all connections to ensure they are tight and correctly oriented.




Image 5.1: An overview of the assembly process, demonstrating how to connect the input wires, welding pens, and buzzer to the main circuit board.

6. OPERATING INSTRUCTIONS

Safety Warning: Always wear appropriate personal protective equipment, including safety glasses, when operating the spot welder. Avoid direct contact with welding tips during operation. Ensure adequate ventilation in your workspace.

1. **Power On:** Connect the assembled spot welder to a compatible 12V-14.6V DC power source. The buzzer may emit a short sound, indicating the device is powered on and ready.
2. **Material Preparation:** Ensure the nickel sheet and the material to be welded (e.g., battery tabs, PCB pads) are clean, dry, and free of any oxidation or contaminants. Clean surfaces improve weld quality.
3. **Positioning:** Place the nickel sheet over the material to be welded. Position the tips of the two welding pens firmly and evenly onto the nickel sheet, ensuring good contact with both tips.
4. **Initiate Weld:** Apply firm, even pressure with both welding pens. The device will automatically detect contact and initiate the welding process. A successful weld will create a strong, secure bond.
5. **Adjustments:** If welds are weak, inconsistent, or burn through, check the stability of your power source,

the cleanliness of materials, and the amount of pressure applied. Experiment with slight variations in pressure for optimal results.

6. **Power Off:** Disconnect the power source from the spot welder when not in use.

7. CARE AND MAINTENANCE

- **Cleaning:** Keep the welding pens and circuit board clean and free of debris, dust, and metal particles. Use a dry, soft cloth for cleaning. Do not use liquids directly on the circuit board.
- **Storage:** Store the spot welder in a dry, cool place, away from direct sunlight, moisture, and corrosive substances.
- **Inspection:** Regularly inspect the input wires, welding pens, and the circuit board for any signs of damage, wear, or loose connections. Replace damaged components immediately to ensure safe operation.
- **Welding Tip Condition:** Ensure the tips of the welding pens are clean and sharp for optimal performance. If tips become dull or oxidized, lightly sand them with fine-grit sandpaper to restore their conductivity.

8. TROUBLESHOOTING

If you encounter issues with your spot welder, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
No power / Device not turning on	Incorrect power source voltage; loose connections; faulty power source	Verify power source is within 12V-14.6V; check all wire connections for tightness; test power source with another device
Weak or inconsistent welds	Insufficient contact pressure; dirty welding tips/materials; unstable power supply	Apply more firm and even pressure; clean welding tips and materials thoroughly; ensure a stable and sufficient power supply
Device overheating	Prolonged continuous use; inadequate ventilation	Allow the device to cool down between welding sessions; ensure proper airflow around the circuit board during operation
Buzzer not sounding	Buzzer incorrectly connected; faulty buzzer	Check the buzzer connection to the circuit board; if still not working, the buzzer may be faulty and require replacement

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your VILLCASE Portable DIY Spot Welder, please contact your retailer or visit the official VILLCASE website. When contacting support, please have your model number (57YR25310408F) and purchase details available to expedite assistance.