

## Tangkula NP1217-CF

# Tangkula 3-Person Outdoor Glider Bench Instruction Manual

Model: NP1217-CF

## 1. INTRODUCTION

---

Thank you for choosing the Tangkula 3-Person Outdoor Glider Bench. This manual provides essential information for the safe assembly, operation, and maintenance of your new glider bench. Please read all instructions carefully before assembly and use, and retain this manual for future reference.

This glider bench is designed for outdoor use, providing a comfortable and gentle gliding motion for relaxation. It features a robust metal frame, breathable fabric seat, and curved teak wood armrests.

## 2. SAFETY INFORMATION

---

- **Read All Instructions:** Ensure you understand all assembly and safety instructions before use.
- **Adult Assembly Required:** Assembly should be performed by adults. Keep children away during assembly.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 990 lbs (450 kg). This bench is designed to comfortably seat up to 3 individuals.
- **Stable Surface:** Always place the glider bench on a flat, stable, and level surface to prevent tipping. Adjustable foot pads are provided for minor adjustments on uneven ground.
- **Weather Protection:** While designed for outdoor use, prolonged exposure to heavy rain, snow, or extreme weather conditions may reduce the product's lifespan. Consider covering or storing the bench during inclement weather.

- **Regular Inspection:** Periodically check all bolts, nuts, and connections to ensure they are tight and secure. Retighten as necessary.
- **Avoid Misuse:** Do not stand on the bench, use it as a ladder, or allow children to play unsupervised on or around it.
- **Moving the Bench:** When moving the bench, lift it rather than dragging it to prevent damage to the frame or the surface it rests on.

### 3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts listed below are present. If any parts are missing or damaged, do not proceed with assembly. Contact customer service for assistance.

Part	Description	Quantity
Gliding Bench Frame Components	Metal frame sections for seat, back, and base.	1 Set
Fabric Seat/Back Material	Breathable fabric for seating surface.	1
Teak Wood Armrests	Curved wooden armrests.	2
Hardware Pack	Bolts, nuts, washers, adjustable foot pads, and assembly tools (e.g., wrench, Allen key).	1 Set
Instruction Manual	This document.	1

### 4. ASSEMBLY INSTRUCTIONS

Please follow these steps carefully. It is recommended to assemble the bench with at least two people.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches. Verify all parts against the "Package Contents" list.
2. **Assemble the Base Frame:** Connect the main base frame components using the provided bolts and nuts. Do not fully tighten bolts until all components are loosely assembled.
3. **Attach Rocker Arms:** Secure the robust rocker arms to the base frame. Ensure they are correctly oriented for smooth gliding motion.
4. **Install Seat and Back Frames:** Attach the seat and back metal frames to the rocker arms.
5. **Secure Fabric Seat:** Carefully attach the breathable fabric seat and back material to the corresponding frames. Ensure the fabric is taut and evenly distributed.
6. **Mount Armrests:** Attach the curved teak wood armrests to the side frames of the bench.
7. **Install Adjustable Foot Pads:** Screw the adjustable foot pads into the bottom of the base frame.

8. **Final Tightening:** Once all components are in place and aligned, gradually tighten all bolts and nuts using the provided tools. Ensure all connections are secure.
9. **Stability Check:** Gently rock the bench to ensure smooth gliding and check for any wobbling. Adjust foot pads if necessary to achieve a stable base.



*Image: Assembly diagram illustrating the connection points for the frame components. This image helps visualize the process of putting together the glider bench.*



## Unwind in Comfort



Ergonomic Back and Seat   Curved Teak Wood Armrests   Heavy-Duty Metal Frame

*Image: Detail of the robust rocker arms that enable the smooth gliding motion, and the adjustable foot pads for stability on uneven surfaces.*

### 5. OPERATION

---

The Tangkula 3-Person Outdoor Glider Bench is designed for simple and comfortable use.

- **Seating:** Gently sit on the bench. The design allows for comfortable seating for up to three people.
- **Gliding Motion:** To initiate the gliding motion, gently push off the ground with your feet or shift your weight slightly. The robust rocker arms will provide a smooth, gentle back-and-forth movement.
- **Stopping:** To stop the gliding motion, simply place your feet firmly on the ground.
- **Placement:** Ensure the bench is placed on a stable, level surface. Use the adjustable foot pads to compensate for minor unevenness.



*Image: The Tangula 3-Person Outdoor Glider Bench positioned on a patio, demonstrating its intended use in an outdoor environment.*



*Image: The glider bench situated on a porch, highlighting its suitability for various outdoor spaces.*

## 6. MAINTENANCE

---

Proper maintenance will extend the life and appearance of your glider bench.

- **Cleaning the Fabric:** The breathable fabric seat is easy to clean. Wipe with a damp cloth and mild soap. Rinse thoroughly and allow to air dry completely before use. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning the Frame:** Wipe the metal frame with a damp cloth. For stubborn dirt, use a mild detergent and rinse well. Dry thoroughly to prevent rust.
- **Teak Wood Armrests:** Teak wood is naturally durable. To maintain its appearance, you can periodically clean it with a soft brush and soapy water. For a deeper clean or to restore its original color, specialized teak cleaners and oils can be used (follow product instructions).
- **Hardware Check:** Periodically (e.g., monthly or seasonally) inspect all bolts, nuts, and connections. Tighten any loose hardware to ensure structural integrity and safety.

- **Weather Protection:** During periods of non-use or severe weather, it is recommended to cover the bench with a protective cover or store it indoors to prevent damage from UV rays, rain, and snow.
- **Lubrication:** If the gliding mechanism becomes stiff or noisy, apply a silicone-based lubricant to the moving parts of the rocker arms.

# Dimensions



Max Load

*Image: A detailed view of the breathable fabric seat, illustrating its texture and quick-drying properties, which simplify cleaning and maintenance.*

## 7. TROUBLESHOOTING

If you encounter any issues with your Tangkula Glider Bench, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Bench is wobbly or unstable.	Uneven surface; loose hardware.	Ensure the bench is on a level surface. Adjust the foot pads to stabilize. Check and tighten all bolts and nuts.
Gliding motion is stiff or noisy.	Lack of lubrication; debris in mechanism; loose connections.	Apply a silicone-based lubricant to the rocker arm pivot points. Clean any visible debris from the gliding mechanism. Check and tighten all relevant hardware.
Parts do not align during assembly.	Incorrect orientation of parts; bolts overtightened prematurely.	Review the assembly instructions and diagrams to ensure correct part orientation. Loosen all bolts, align parts, then gradually tighten.
Missing or damaged parts.	Manufacturing defect or shipping damage.	Do not proceed with assembly. Contact Tangkula customer service immediately for replacement parts.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	NP1217-CF
Overall Dimensions (L x W x H)	29" x 66.5" x 33" (74 x 169 x 84 cm)
Seat Height from Ground	18" (45 cm)
Seat Dimension (W x D)	64" x 18" (163 x 45 cm)
Weight Capacity	990 lbs (450 kg)
Net Weight	32 lbs (14.5 kg)
Color	Black + Brown
Materials	Metal, Fabric, Teak Wood
Seating Capacity	3 Person

# Gentle Gliding Motion



Anti-Rollover



Stable Base



Robust Rocker Arms



Adjustable Foot Pads

*Image: A visual representation of the glider bench with key dimensions labeled, including length, width, height, and seat height, along with the maximum load capacity.*

## 9. WARRANTY AND SUPPORT

For warranty information, missing parts, or any product-related inquiries, please contact Tangkula customer service directly. Refer to your purchase documentation for specific warranty terms and contact details.

**Manufacturer:** Tangkula

**ASIN:** B0F3XRLGG5

**Model Number:** NP1217-CF

For further assistance, please visit the [Tangkula Store on Amazon](#).

