

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Viamotion](#) /

› Viamotion Walking Pad with Handle Bar Instruction Manual

Viamotion Viamotion Walking Pad with Handle Bar

Viamotion Walking Pad with Handle Bar Instruction Manual

Model: Viamotion Walking Pad with Handle Bar

1. PRODUCT OVERVIEW

The Viamotion Walking Pad with Handle Bar is designed for convenient exercise in home and office environments. It features a powerful yet quiet motor, a compact folding design for easy storage, and an intuitive LED display to track your workout progress. The integrated handle bar provides additional support and safety during use.



Image: The Viamotion Walking Pad with Handle Bar, showcasing its sleek design and integrated display.

2. SAFETY INFORMATION

Please read all safety instructions carefully before operating the walking pad. Failure to follow these instructions may result in injury or damage to the product.

- Ensure the walking pad is placed on a flat, stable surface.
- Keep children and pets away from the device during operation.
- Do not use the walking pad if it is damaged or malfunctioning.
- Wear appropriate athletic footwear.
- Do not exceed the maximum weight recommendation of 250 pounds.
- Always hold onto the handle bar for stability, especially when starting or stopping.

3. SETUP INSTRUCTIONS

Follow these steps to set up your Viamotion Walking Pad:

1. **Unboxing and Placement:** Carefully remove the walking pad from its packaging. Place it on a level surface in your desired workout area.
2. **Raise the Handle Bar:** Gently pull the handle bar upwards until it locks into place. Ensure both sides are securely fastened.
3. **Install Incline Adjusters (Optional):** The walking pad includes manual incline adjusters. To install, remove the foot covers at the rear of the treadmill. Insert the provided M8*30 screws and M8 nuts to fix the folding foot pedals on the treadmill platform. You can choose between a high or low incline setting by adjusting the position of the red base.



Image: The walking pad with its handle bar raised, illustrating the manual incline adjustment feature at the rear.

4. **Attach Phone Mount:** Remove the screws on the top of the handle bar using the provided screwdriver. Secure the phone mount to the handle bar using these screws.
5. **Insert Remote Control Batteries:** The remote control requires 2 AAA batteries (not included). Open the battery compartment and insert the batteries, observing polarity.
6. **Connect Power:** Plug the power cord into a suitable electrical outlet. Turn on the main power switch located on the

front of the walking pad. The LED display will illuminate.

4. OPERATING INSTRUCTIONS

Your Viamotion Walking Pad offers multiple modes and speed settings for a customized workout.

4.1 Power On/Off

- To turn on, ensure the main power switch is on, then press the 'ON' button on the remote control. The display will show a countdown before starting.
- To turn off, press the 'OFF' button on the remote control. For complete power disconnection, turn off the main power switch.

4.2 Speed Adjustment

- Use the '+' button on the remote control to increase speed.
- Use the '-' button on the remote control to decrease speed.
- The speed range is from 0.6 to 3.8 miles per hour.

4.3 Workout Modes

The walking pad supports three modes:

- **Working Mode:** Ideal for low-speed walking while performing other tasks.
- **Walking Mode:** Suitable for moderate-paced walking.
- **Running Mode:** For higher intensity walking or light jogging.

4.4 LED Display

LED Display and Keypad Control



Image: Close-up of the LED display, showing real-time workout metrics.

The clear LED display continuously tracks and shows the following metrics:

- **Time:** Duration of your exercise session.
- **Distance:** Total distance walked.
- **Speed:** Current walking speed.
- **Calories:** Estimated calories burned.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your walking pad.

- **Cleaning:** Wipe down the walking pad with a damp cloth after each use to remove sweat and dust. Do not use abrasive cleaners.
- **Lubrication:** Periodically lubricate the running belt according to the instructions in the detailed user manual (not provided here). Proper lubrication helps maintain smooth belt operation and reduces wear.

- **Storage:** When not in use, fold the walking pad and store it in a dry, cool place away from direct sunlight.

6. TROUBLESHOOTING

If you encounter any issues with your Viamotion Walking Pad, please refer to the following common solutions:

- **Device not powering on:** Ensure the power cord is securely plugged into both the walking pad and the electrical outlet. Check that the main power switch is in the 'ON' position. Verify that the remote control batteries are correctly inserted and not depleted.
- **Belt not moving smoothly:** Check for any obstructions under the belt. Ensure the belt is properly lubricated. If the issue persists, the belt may need adjustment (refer to the full user manual for detailed instructions).
- **Unusual noises:** Stop using the device immediately. Inspect for loose parts or foreign objects. If the noise continues, contact customer support.

For issues not covered here, or if troubleshooting steps do not resolve the problem, please contact Viamotion customer service.

7. SPECIFICATIONS

Feature	Detail
Brand	Viamotion
Model Name	Viamotion Walking Pad with Handle Bar
Color	Black
Product Dimensions (D x W x H)	46.8" x 22.6" x 4.5"
Material	Metal
Maximum Speed	3.8 Miles per Hour
Special Feature	Manual Incline
Maximum Horsepower	2.5 Horsepower
Included Components	Remote Control
Maximum Weight Recommendation	250 Pounds
UPC	721545362094

8. WARRANTY AND SUPPORT

Viamotion is committed to providing quality products and excellent customer service.

- **Motor Warranty:** We offer a one-year motor warranty from the date of purchase.
- **Customer Service:** Our professional local customer service team is available to assist you with any questions or concerns.
- **Contact:** For support, please contact us through the Amazon backend. Our team aims to respond within 12 hours to provide a satisfactory solution.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F4K7V6TQ>

More documents and user manuals: <https://manuals.plus/>