

[Manuals.plus](#) /

› [Audecook](#) /

› Audecook Mini Rice Cooker AC1228 User Manual

Audecook AC1228

Audecook Mini Rice Cooker AC1228 User Manual

Model: AC1228 | Capacity: 1.2 Liters

1. INTRODUCTION

Thank you for purchasing the Audecook Mini Rice Cooker, Model AC1228. This appliance is designed for convenient and versatile cooking, perfect for individuals or small families. It features a 1.2L capacity, a non-stick inner pot, a stainless steel steamer, and multiple cooking functions including a low-carb option, delay timer, and automatic keep-warm function. Please read this manual thoroughly before first use to ensure safe and optimal operation.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- This appliance is for household use only.

3. PRODUCT COMPONENTS

The Audecook Mini Rice Cooker comes with the following components:

- Main Rice Cooker Unit
- Non-Stick Inner Pot
- Stainless Steel Steamer Basket
- Measuring Cup
- Rice Paddle
- Power Cord
- Instruction Manual (this document)



Image 3.1: The Audecook Mini Rice Cooker shown with its non-stick inner pot, stainless steel steamer, measuring cup, and rice paddle.

STRUCTURE DISPLAY



Image 3.2: A detailed view of the rice cooker's internal structure, highlighting the removable inner lid, LED display, 1.2L inner pot capacity, and the operation panel.

4. SETUP AND FIRST USE

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the inner pot, steamer basket, measuring cup, rice paddle, and removable inner lid with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the rice cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure adequate ventilation around the appliance.
4. **Power Connection:** Plug the power cord into the rice cooker, then into a suitable electrical outlet (110V).

5. OPERATION

5.1 General Cooking Steps

1. **Measure Ingredients:** Use the provided measuring cup to measure your desired amount of rice.
2. **Wash Rice:** Rinse the rice thoroughly under cold water until the water runs clear. You can use the steamer basket as a filter for washing.
3. **Add Water:** Place the washed rice into the non-stick inner pot. Add the appropriate amount of water according to the cooking guide (see Section 5.5).
4. **Insert Pot:** Place the inner pot into the main rice cooker unit. Ensure it is seated correctly.
5. **Close Lid:** Close the lid securely.
6. **Select Function:** Press the 'MOED' button to cycle through the available cooking functions (Rice, Low Sugar Rice, Oatmeal, Soup, Baby Porridge, Cake). The selected function will be indicated on the LED display.
7. **Start Cooking:** The cooker will automatically start cooking after a few seconds of selecting a function, or you may need to press 'DELAY/START' depending on the model variation.
8. **Completion:** Once cooking is complete, the cooker will typically switch to 'Keep Warm' mode automatically.

ENDLESS FLAVORS, SINGLE BUTTON

Suitable for 1-2 people, about 4 bowls of rice



Image 5.1: The Audecook Mini Rice Cooker in use, demonstrating its compact size and ease of serving.

5.2 Low Carb Function

This function is designed to reduce the starch and sugar content in rice. When selecting 'Low Sugar Rice', the cooker uses a specialized process where rice is cooked in the stainless steel steamer basket, allowing excess starch to drain away into the water below. This results in rice with reduced carbohydrates.

LOW CARB RICE

Reduces carbs and sugar up to **40%**



* Removing excess starch during cooking, separating sugar and rice

Image 5.2: Visual representation of the low carb function, showing how starch is separated from the rice during cooking.

5.3 Delay Timer Function

The 24-hour delay timer allows you to set the cooking to start at a later time. This is useful for having freshly cooked food ready when you need it.

1. Prepare ingredients and place them in the inner pot.
2. Select your desired cooking function using the 'MOED' button.
3. Press the 'DELAY/START' button. The display will show a default delay time.
4. Use the '+' and '-' buttons to adjust the delay time in 0.5-hour increments, up to 24 hours.

5. Once the desired delay time is set, the cooker will begin the countdown. Cooking will start automatically after the delay period.



Image 5.3: The rice cooker demonstrating its automatic Keep Warm function and the process of setting the Delay Timer.

5.4 Automatic Keep Warm Function

After most cooking cycles are complete, the Audecook Mini Rice Cooker will automatically switch to 'Keep Warm' mode. This function maintains the food at an optimal serving temperature without overcooking. The 'Keep Warm' indicator will illuminate. To cancel, press the 'KEEP WARM/CANCEL' button.

5.5 Cooking Guide (Approximate Ratios)

These ratios are general guidelines. Adjust water amounts to achieve desired texture.

Food Type	Rice (Measuring Cups)	Water (Measuring Cups)	Function
White Rice	1	1.5 - 2	Rice
White Rice	2	3 - 4	Rice
Low Sugar Rice	1	2 - 2.5	Low Sugar Rice
Low Sugar Rice	2	4 - 5	Low Sugar Rice
Oatmeal	0.5	2	Oatmeal
Soup	N/A	Varies	Soup
Baby Porridge	0.5	3	Baby Porridge

Note: The measuring cup provided is typically 180ml.

VERSATILE OPTIONS

One-touch cooking for a variety of dishes



Image 5.4: The rice cooker's versatility, showing different food types that can be prepared using its various functions.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your rice cooker.

1. **Unplug:** Always unplug the rice cooker from the power outlet and allow it to cool completely before cleaning.
2. **Inner Pot:** The non-stick inner pot is removable and can be washed with warm, soapy water using a soft sponge or cloth. Avoid abrasive cleaners or metal scouring pads, as these can damage the non-stick coating.
3. **Steamer Basket & Accessories:** The stainless steel steamer basket, measuring cup, and rice paddle can be washed with warm, soapy water.
4. **Removable Inner Lid:** The inner lid is removable for thorough cleaning. Gently detach it from the main lid and wash with warm, soapy water. Ensure it is completely dry before reattaching.
5. **Main Unit Exterior:** Wipe the exterior of the rice cooker with a damp cloth. Do not immerse the main unit in water or any other liquid.

6. **Storage:** Ensure all parts are dry before reassembling and storing the rice cooker in a cool, dry place.



Image 6.1: The removable inner lid and non-stick inner pot are designed for easy cleaning, ensuring hygiene and longevity of the appliance.

7. TROUBLESHOOTING

If you encounter any issues with your Audecook Mini Rice Cooker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice is too hard/undercooked	Not enough water; cooking cycle interrupted; lid not sealed properly.	Add slightly more water next time; ensure lid is closed; do not open lid during cooking.
Rice is too soft/mushy	Too much water.	Reduce water slightly next time.

Problem	Possible Cause	Solution
Cooker does not turn on	Not plugged in; power outage; faulty outlet.	Check power cord connection; test outlet with another appliance; ensure power is on.
Food sticks to inner pot	Non-stick coating damaged; insufficient water.	Ensure only soft utensils are used; add correct amount of water.
Steam leaking from lid	Lid not closed properly; seal damaged; food debris on seal.	Ensure lid is securely closed; clean lid and seal; check seal for damage.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Audecook
Model Name	Mini Rice Cooker
Item Model Number	AC1228
Capacity	1.2 Liters (2 cups uncooked rice)
Product Dimensions	8.27"D x 7.68"W x 9.25"H
Item Weight	2.97 pounds (1.35 Kilograms)
Power Source	Corded Electric
Voltage	110 Volts
Wattage	200 watts
Material	Metal, Plastic, Stainless Steel (Lid: 304 stainless steel and ABS plastic)
Special Features	Automatic Keep Warm, Locking Lid, Low Carb Function, Non-Stick, Timer
Included Components	Inner Pot, Instruction Manual, Measuring Cup, Rice Paddle, Steamer Basket
Product Care Instructions	Wipe with Damp Cloth
UPC	724584424204

9. WARRANTY AND SUPPORT

Audecook products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your product or contact Audecook customer support. If you have any questions, require assistance, or need to report an issue, please contact our customer service team through the retailer where you purchased the product or visit the official Audecook website for support contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F4PHP45H>

More documents and user manuals: <https://manuals.plus/>