

Ufesa 72808010

Ufesa Jacana 10L Air Fryer Oven Instruction Manual

Brand: Ufesa | Model: 72808010

1. PRODUCT OVERVIEW

The Ufesa Jacana 10L Air Fryer Oven is a versatile kitchen appliance designed for healthy cooking. It combines the functions of an air fryer and a tabletop electric oven, allowing you to fry, roast, bake, and grill with minimal oil. Its generous 10-liter capacity is suitable for preparing meals for 6 to 8 people, making it ideal for families and gatherings.

Equipped with **Air Pulse Ultra 360°C Technology** and dual heating elements, this appliance ensures faster and more uniform cooking, resulting in crispy exteriors and juicy interiors. The intuitive color touch screen and internal viewing window provide full control and visibility during the cooking process.

Tecnología Air Pulse Ultra 360°



6-8 | 10L

Image: Ufesa Jacana 10L Air Fryer Oven highlighting its 10L capacity and Air Pulse Ultra 360°C technology, suitable for 6-8 servings.

Key Features:

- **Large 10L Capacity:** Perfect for cooking for 6 to 8 individuals.
- **Air Pulse Ultra 360°C Technology with Dual Heating Elements:** Ensures even and rapid cooking.
- **Multi-functional:** Acts as an air fryer and a tabletop electric oven.
- **8 Preset Programs:** Simplifies cooking for various dishes.
- **Adjustable Temperature:** Ranges from 80°C to 230°C.
- **60-Minute Timer:** Provides precise cooking control.
- **28 cm Diameter:** Accommodates larger items like pizzas.
- **Color Touch Screen:** For easy and intuitive operation.
- **Viewing Window with Interior Light:** Monitor cooking progress without opening the appliance.
- **Non-stick Basket and Tray:** Easy to clean and dishwasher safe.
- **Included Grill Accessory:** Expands cooking possibilities.

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance for the first time and keep them for future reference.

General Safety:

- Always place the appliance on a stable, heat-resistant surface, away from walls or other appliances to ensure proper ventilation.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- Keep children and pets away from the appliance during operation.
- Do not touch hot surfaces. Use oven mitts or handles.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.

Electrical Safety:

- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Do not let the power cord hang over the edge of a table or counter, or touch hot surfaces.
- Avoid using extension cords unless absolutely necessary and ensure they are rated for the appliance's power consumption.

Cleaning Safety:

- Allow the appliance to cool completely before cleaning.
- Do not use abrasive cleaners or scouring pads, as these can damage the non-stick coating.

3. SETUP

Unpacking:

1. Carefully remove the appliance and all accessories from the packaging.
2. Remove any protective films or stickers.
3. Retain the packaging for future storage or transport.

Initial Cleaning:

1. Before first use, wipe the exterior of the appliance with a damp cloth.
2. Wash the non-stick basket, tray, and grill accessory with warm, soapy water. Rinse thoroughly and dry completely. These components are also dishwasher safe.

Placement:

- Place the air fryer oven on a flat, stable, and heat-resistant surface.
- Ensure there is adequate space (at least 10 cm) around the appliance for proper air circulation.
- Do not place the appliance near heat sources or on top of other heat-generating appliances.

4. OPERATING INSTRUCTIONS

Control Panel:

The Ufesa Jacana features an intuitive color touch screen located on the top of the appliance. This panel allows you to select preset programs, adjust temperature, and set the timer.



Image: Detailed view of the touch screen control panel with 8 preset cooking programs.

Using Preset Programs:

1. Place your food in the appropriate accessory (basket, tray, or grill).
2. Insert the accessory into the appliance.
3. Turn on the appliance using the power button on the touch screen.
4. Select one of the 8 preset programs by touching its icon. The appliance will automatically set the recommended temperature and time.
5. Press the Start button to begin cooking.

Manual Operation:

1. Place your food in the appropriate accessory and insert it into the appliance.
2. Turn on the appliance.
3. Use the temperature controls (usually '+' and '-' buttons) to set the desired temperature between 80°C and

230°C.

4. Use the timer controls (usually '+' and '-' buttons) to set the desired cooking time, up to 60 minutes.
5. Press the Start button to begin cooking.

Monitoring Cooking:

The appliance features a viewing window with an interior light, allowing you to monitor the cooking progress without opening the door. This helps maintain consistent temperature and cooking efficiency.

5. COOKING GUIDE

The Ufesa Jacana is designed for a wide range of cooking tasks, from air frying to baking and grilling. Its 10L capacity and 28cm diameter allow for versatile meal preparation.



Image: The Ufesa Jacana Air Fryer Oven demonstrating its capacity to fit a 28cm pizza.

Tips for Best Results:

- For crispy results, lightly coat food with oil before air frying.

- Shake the basket or flip food halfway through cooking for even browning.
- Do not overcrowd the basket or tray to ensure proper air circulation. Cook in batches if necessary.
- Use the included grill accessory for grilling meats and vegetables.



Image: The grill accessory in use, cooking various meats and vegetables.

Video Demonstration:

Your browser does not support the video tag.

Video: A demonstration of a 10L air fryer oven, showing how to use the rotisserie function for cooking a whole chicken. This video is from the brand OYZone and is relevant for understanding the functionality of a 10L air fryer oven.

6. MAINTENANCE

Cleaning:

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. Wipe the exterior of the appliance with a soft, damp cloth. Do not use abrasive cleaners.

3. The non-stick basket, tray, and grill accessory are dishwasher safe. For hand washing, use warm, soapy water and a non-abrasive sponge.
4. Ensure all parts are completely dry before reassembling or storing the appliance.

Storage:

Store the appliance in a cool, dry place when not in use. Ensure the power cord is neatly wrapped and secured.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in or power outlet issue.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Food is not cooking evenly.	Overcrowding or uneven food placement.	Do not overcrowd the basket/tray. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use or fatty food.	Clean the appliance thoroughly after each use. For fatty foods, place a small amount of water in the bottom of the tray to reduce smoke.
Food is not crispy.	Not enough oil or incorrect temperature/time.	Lightly coat food with oil. Adjust temperature and time as needed.

8. SPECIFICATIONS

- **Brand:** Ufesa
- **Model Number:** 72808010
- **Color:** Black
- **Dimensions:** 44.2 x 26 x 37.5 cm
- **Weight:** 10.99 kg
- **Capacity:** 10 Liters
- **Power:** 1700 Watts
- **Material:** Plastic, Glass, Ceramic
- **Special Features:** Automatic shut-off, Temperature control, Programmable, Timer
- **Control Method:** Touch
- **Temperature Range:** 80°C to 230°C
- **Timer:** Up to 60 minutes



Image: The Ufesa Jacana Air Fryer Oven with its key dimensions indicated.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Ufesa website. Keep your proof of purchase for any warranty claims.

You can also visit the [Ufesa Store on Amazon](#) for more product information and support resources.