

ZHRCLY SC15CL

ZHRCLY SECOP Compressor SC15CL AC115V Instruction Manual

Model: SC15CL AC115V

1. INTRODUCTION

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your ZHRCLY SECOP Compressor, model SC15CL AC115V. Please read this manual thoroughly before using the product and retain it for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: Failure to follow these safety instructions may result in electric shock, fire, serious injury, or death.

- Always disconnect power before servicing or installing the compressor.
- Ensure proper grounding to prevent electrical shock.
- Installation and maintenance should only be performed by qualified personnel.
- Do not operate the compressor in wet conditions or near flammable materials.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, during installation and maintenance.
- Verify that the power supply voltage matches the compressor's requirements (AC115V).
- Keep children and unauthorized persons away from the compressor during operation.

3. PRODUCT OVERVIEW AND COMPONENTS

The ZHRCLY SECOP Compressor SC15CL AC115V is a robust unit designed for various refrigeration applications. It is a hermetic compressor, meaning its motor and compressor are enclosed in a single welded steel shell.



Image 1: ZHRCLY SECOP Compressor SC15CL AC115V. This image displays the compact, black-colored compressor unit with its electrical connections and mounting feet visible.

Key components typically include:

- **Compressor Unit:** The main body containing the motor and compression mechanism.
- **Electrical Connections:** Terminals for power input and control signals.
- **Suction and Discharge Lines:** Ports for refrigerant intake and output.
- **Mounting Feet:** For secure installation.

4. SETUP AND INSTALLATION

1. **Unpacking:** Carefully remove the compressor from its packaging. Inspect for any shipping damage.
2. **Mounting:** Securely mount the compressor on a stable, level surface using appropriate fasteners. Ensure adequate ventilation around the unit.
3. **Refrigerant Line Connection:** Connect the suction and discharge lines to the refrigeration system. Ensure all connections are leak-free and properly brazed or sealed according to industry standards.
4. **Electrical Wiring:** Connect the compressor to a dedicated AC115V power supply. Follow all local electrical codes and the wiring diagram provided with your specific refrigeration system. Ensure proper grounding.
5. **Vacuum and Charge:** Evacuate the refrigeration system to remove all non-condensable gases and moisture. Then, charge the system with the correct type and amount of refrigerant as specified by the system manufacturer.
6. **Leak Check:** Perform a thorough leak check on all refrigerant connections.

5. OPERATING INSTRUCTIONS

Once properly installed and charged, the compressor will operate as part of your refrigeration system. Its operation is typically controlled by a thermostat or other system controls.

- **Initial Start-up:** After installation, apply power to the system. The compressor should start and begin circulating refrigerant. Monitor system pressures and temperatures to ensure proper operation.
- **Normal Operation:** The compressor will cycle on and off as needed to maintain the desired temperature set by the system's controls.
- **Monitoring:** Periodically check for unusual noises, vibrations, or leaks. Any abnormal behavior should be

investigated promptly.

6. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your compressor. Always disconnect power before performing any maintenance.

- **Cleaning:** Keep the compressor and surrounding area clean and free of dust and debris to ensure proper heat dissipation.
- **Inspection:** Periodically inspect electrical connections for tightness and signs of corrosion. Check refrigerant lines for leaks or damage.
- **System Checks:** Have a qualified technician periodically check the overall refrigeration system, including refrigerant levels, pressures, and electrical components.

7. TROUBLESHOOTING

This section outlines common issues and potential solutions. For complex problems, contact a qualified technician.

Problem	Possible Cause	Solution
Compressor does not start	No power, faulty wiring, thermostat issue, motor overload.	Check power supply, wiring connections, thermostat settings. Reset overload protector if tripped.
Compressor runs continuously	Low refrigerant charge, dirty condenser, thermostat set too low, system overload.	Check refrigerant level, clean condenser coils, adjust thermostat.
Insufficient cooling	Low refrigerant, dirty coils, restricted airflow, faulty expansion valve.	Check refrigerant, clean coils, ensure proper airflow. Consult technician for valve issues.
Unusual noise or vibration	Loose mounting, internal compressor issue, refrigerant slugging.	Check mounting bolts. If noise persists, contact a qualified technician.

8. TECHNICAL SPECIFICATIONS

Specification	Detail
Brand	ZHRCLY
Model Name	SC15CL
Item Model Number	SC15CL AC115V
Power Source	AC (115V)
Material	Alloy Steel
Item Weight	6.6 pounds
Package Dimensions	1 x 1 x 1 inches (Approximate)
Manufacturer	Original factory

Specification	Detail
Part Number	SC15CL

9. WARRANTY INFORMATION

Specific warranty details for the ZHRCLY SECOP Compressor SC15CL AC115V are typically provided at the point of purchase or with the product packaging. Please refer to your purchase documentation for the exact terms and conditions of the warranty. Keep your proof of purchase for any warranty claims.

10. CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact the retailer or manufacturer directly. Have your product model number (SC15CL AC115V) and purchase information ready when contacting support.