

[Manuals.plus](#) /

› [YQABLE](#) /

› YQABLE SP1610Z1MBK Swimming Pool Pump Motor Kit 1.0 HP Instruction Manual

YQABLE SP1610Z1MBK

YQABLE SP1610Z1MBK Swimming Pool Pump Motor Kit 1.0 HP Instruction Manual

Model: SP1610Z1MBK

INTRODUCTION

This manual provides essential information for the safe and effective installation, operation, and maintenance of your YQABLE SP1610Z1MBK Swimming Pool Pump Motor Kit. This motor is designed as an aftermarket replacement part compatible with specific Hayward pump series. Please read all instructions carefully before proceeding with installation or use.

This motor kit is compatible with:

- Hayward Pump SP4000 series
- Super II SP3000X series pump for MaxFlo series

IMPORTANT SAFETY INFORMATION

WARNING: Risk of Electric Shock or Electrocution. This product must be installed by a qualified professional in accordance with all applicable national and local electrical codes. Failure to do so can result in serious injury or death.

- Always disconnect power to the pump at the circuit breaker before attempting any installation, service, or maintenance.
- Ensure proper grounding of the motor.
- Do not operate the pump if the motor is wet or if there is standing water around the pump area.
- Keep children and unauthorized persons away from the pump and motor during operation and maintenance.
- Wear appropriate personal protective equipment (PPE) during installation and service.
- Refer to the original pump manufacturer's manual for additional safety guidelines specific to your pump model.

PRODUCT OVERVIEW

The YQABLE SP1610Z1MBK is a 1.0 HP replacement motor designed for specific swimming pool pumps. It features a durable construction and is engineered to meet the performance requirements of compatible

pump models.



Figure 1: Side view of the YQABLE SP1610Z1MBK pool pump motor, showing the motor body and the attached specification label. The label provides details such as voltage, amperage, and horsepower.





Figure 2: Angled view of the motor, illustrating the threaded motor shaft where the pump impeller attaches, and the four mounting holes on the motor face for securing it to the pump housing.

SETUP AND INSTALLATION

Installation of this motor kit requires electrical and plumbing knowledge. It is highly recommended that installation be performed by a certified pool technician or a qualified electrician.

1. **Verify Compatibility:** Before beginning, ensure the part number SP1610Z1MBK matches the motor you are replacing and is compatible with your specific Hayward pump series (SP4000, Super II SP3000X for MaxFlo).
2. **Disconnect Power:** Turn off all electrical power to the pool pump at the main circuit breaker. Verify power is off using a voltage tester.
3. **Drain Pump:** If necessary, drain the pump and disconnect any plumbing to allow access to the motor.
4. **Remove Old Motor:** Carefully disconnect the wiring from the old motor. Unbolt the old motor from the pump housing. Note the orientation of all components for reassembly.
5. **Inspect Pump Components:** Inspect the pump's wet end components (impeller, diffuser, seals) for wear or damage. Replace any worn parts as needed.
6. **Install New Motor:** Mount the new YQABLE SP1610Z1MBK motor to the pump housing, ensuring a secure fit.
7. **Connect Wiring:** Connect the electrical wiring to the new motor according to the wiring diagram provided with your original pump or the motor's label. Ensure all connections are tight and properly insulated.
8. **Reassemble Pump:** Reconnect any plumbing and fill the pump with water (prime) if required by your pump model.
9. **Test Operation:** Restore power to the pump. Carefully observe the motor and pump for proper operation, leaks, or unusual noises.

Please refer to your existing pump's instruction manual for detailed disassembly and reassembly

procedures specific to your pump model.



Figure 3: Side view of the motor, highlighting the cooling vents essential for heat dissipation and the threaded opening for electrical conduit connection.



Figure 4: Angled rear view of the motor, showing the sealed end cap and the overall compact design.

OPERATING INSTRUCTIONS

Once the YQABLE SP1610Z1MBK motor is correctly installed onto your pool pump, its operation is

governed by the pump's control system. This motor functions as the power unit for your pump.

- **Starting the Pump:** After installation and priming (if necessary), turn on the power to the pump at the circuit breaker. The motor should start and the pump should begin circulating water.
- **Monitoring:** Observe the pump and motor during initial operation for any unusual noises, vibrations, or signs of overheating.
- **Normal Operation:** The motor will run as long as power is supplied to the pump, typically controlled by a timer or manual switch.
- **Stopping the Pump:** To stop the pump, turn off the power at the designated switch or circuit breaker.

Always refer to your specific pool pump's operating manual for detailed instructions on starting, stopping, and programming your pump system.

MAINTENANCE

Regular maintenance helps ensure the longevity and efficient operation of your pool pump motor. Always disconnect power before performing any maintenance.

- **Keep Clean:** Periodically clean the exterior of the motor, especially the cooling vents, to prevent dust and debris buildup that can impede airflow and cause overheating.
- **Check for Obstructions:** Ensure that the motor's fan and vents are free from obstructions.
- **Inspect Wiring:** Annually inspect electrical connections for tightness and signs of corrosion or damage.
- **Listen for Unusual Noises:** Pay attention to any new or unusual noises coming from the motor, which could indicate a bearing issue or other internal problem.
- **Professional Inspection:** Consider having a qualified technician inspect your pump and motor system annually.



Figure 5: Side view of the motor, illustrating the fan end with its protective cover and cooling fins, which are crucial for maintaining optimal operating temperature.

TROUBLESHOOTING

This section addresses common issues you might encounter with your pool pump motor. For complex problems, always consult a qualified professional.

Problem	Possible Cause	Solution
Motor does not start	• No power supply • Tripped circuit breaker • Faulty wiring connection • Motor overload	• Check power supply to the pump. • Reset circuit breaker. • Inspect and secure wiring connections (power off). • Allow motor to cool; check for obstructions in pump.
Motor overheats and shuts off	• Insufficient ventilation • Low voltage • Pump obstruction/strain • Worn bearings	• Clear debris from motor vents. • Consult an electrician to check voltage. • Inspect pump impeller for clogs. • Contact a service professional.
Unusual noise or vibration	• Worn motor bearings • Loose mounting bolts • Pump cavitation (lack of water)	• Contact a service professional. • Tighten all mounting bolts. • Ensure pump is properly primed and has adequate water flow.

SPECIFICATIONS

Feature	Detail
Brand	YQABLE
Model Name	Swimming Pool Pump Motor Kit
Part Number	SP1610Z1MBK
Horsepower (HP)	1.0 HP
Item Weight	1 Kilograms
Manufacturer	YQABLE
Compatibility	Hayward Pump SP4000 series, Super II SP3000X series for MaxFlo series

SUPPORT

If you have any questions regarding the installation, operation, or compatibility of your YQABLE SP1610Z1MBK Swimming Pool Pump Motor Kit, please do not hesitate to contact us. Our support team is available to assist you.

For assistance, please refer to the contact information provided by your retailer or on the product packaging.

