

NORTHCLAN 1010

NORTHCLAN Model 1010 Countertop Ice Maker User Manual

Your guide to efficient ice production

[Safety](#)

[Overview](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before operating your NORTHCLAN Ice Maker. Retain this manual for future reference.

- Ensure the appliance is connected to a properly grounded 110-volt electrical outlet.
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Keep the ice maker away from heat sources and direct sunlight.
- Always unplug the appliance before cleaning or when not in use.
- Do not operate the appliance with a damaged cord or plug.
- This appliance is for household use only.
- Ensure proper ventilation around the unit. Maintain at least 5 inches of space on all sides.

2. PRODUCT OVERVIEW

The NORTHCLAN Model 1010 Countertop Ice Maker is designed for convenient and efficient ice production. Familiarize yourself with its components and features.

2.1 Components

- Ice Maker Unit
- Removable Ice Basket
- Ice Scoop
- User Manual (this document)

2.2 Key Features

- **One-Touch Control Panel:** Simplifies operation for ease of use.
- **Transparent Lid:** Allows monitoring of the ice-making process without interruption.
- **Built-In Infrared Sensor:** Automatically stops ice production when the ice basket is full or when the water level is low.
- **Indicator Light:** Provides visual notification for conditions such as 'ice full' or 'add water'.
- **Removable Ice Basket & Scoop:** Facilitates convenient transfer and serving of ice.

2.3 Product Views



Figure 1: The NORTHCLAN Model 1010 Ice Maker positioned on a kitchen countertop, demonstrating its compact size and stainless steel finish in a typical home environment.



Figure 2: The NORTHCLAN Model 1010 Ice Maker placed in a modern living room or office setting, highlighting its versatile design that blends with various interior styles.

3. SETUP

3.1 Unpacking

1. Carefully remove the ice maker from its packaging.
2. Remove all packaging materials, including any tape or protective films.
3. Check for any damage that may have occurred during shipping. If damaged, do not operate and contact customer support.

3.2 Placement

- Place the ice maker on a stable, level surface.
- Ensure there is at least 5 inches (12.7 cm) of clear space around the unit for proper ventilation.
- Avoid placing the unit near heat sources (e.g., ovens, radiators) or in direct sunlight.
- Do not place the unit in an enclosed cabinet.

3.3 Initial Cleaning

1. Before first use, clean the interior of the ice maker.
2. Remove the ice basket and wash it with warm water and a mild detergent. Rinse thoroughly.
3. Wipe the interior with a soft cloth dampened with warm water and a small amount of vinegar or mild detergent. Rinse with clean water.
4. Dry all parts thoroughly before reassembling.

4. OPERATING INSTRUCTIONS

4.1 Adding Water

1. Open the transparent lid.
2. Remove the ice basket.
3. Fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
4. Replace the ice basket and close the lid.

4.2 Starting Ice Production

1. Plug the ice maker into a grounded 110-volt outlet.
2. Press the 'ON/OFF' button on the control panel. The 'ICE' indicator light will illuminate.
3. The ice maker will begin its cycle. The first batch of ice may take approximately 5-10 minutes. Subsequent batches will be faster.

4.3 Monitoring and Collecting Ice

- The transparent lid allows you to observe the ice-making process.
- When the ice basket is full, the 'ICE FULL' indicator light will turn on, and the machine will pause production.
- When the water level is low, the 'ADD WATER' indicator light will turn on. Add more water to resume ice production.
- Use the provided ice scoop to remove ice from the basket.
- For best results, transfer ice to a freezer for storage as the ice maker is not a freezer and will not keep ice frozen for extended periods.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your ice maker.

5.1 Self-Clean Function

Your NORTHCLAN ice maker features a self-clean function:

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the 'CLEAN' button (if available, or refer to specific button on your model) for 3-5 seconds.

- 3. The machine will run a cleaning cycle, circulating water through its system.
- 4. Once the cycle is complete, drain the water from the reservoir and wipe dry.

5.2 Regular Cleaning

- **Exterior:** Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Interior:** Periodically clean the water reservoir and ice-making components with a solution of water and white vinegar (10:1 ratio) or a mild food-grade cleaning solution. Rinse thoroughly with clean water.
- **Ice Basket & Scoop:** Wash with warm, soapy water, rinse, and dry.

5.3 Storage

If the ice maker will not be used for an extended period:

- 1. Unplug the unit.
- 2. Drain all water from the reservoir.
- 3. Clean and dry the interior and exterior thoroughly.
- 4. Store in a cool, dry place, away from direct sunlight.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; 'ADD WATER' light on.	Fill the water reservoir to the MAX line.
	Ice basket full; 'ICE FULL' light on.	Remove ice from the basket.
	Ambient temperature too high.	Move the ice maker to a cooler location.
Ice cubes are small or clumpy.	Water temperature too high.	Use colder water.
	Mineral buildup.	Perform a thorough cleaning cycle. Use distilled water if tap water is hard.
Machine is noisy.	Unit not level.	Ensure the ice maker is on a stable, level surface.
	Normal compressor operation.	Some operational noise is normal.

7. SPECIFICATIONS

Feature	Detail
Brand	NORTHCLAN
Model Name	Ice Maker Machine (Model 1010)
Capacity	2 Liters (Water Reservoir)
Voltage	110 Volts
Material	Stainless Steel
Ice Production	Up to 30 lbs in 24 hours
Ice Ready Time	Approximately 5 minutes per batch
UPC	696168472690

8. WARRANTY AND SUPPORT

8.1 Product Warranty

Your NORTHCLAN Ice Maker is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact NORTHCLAN customer support. Contact information can typically be found on the product packaging, the official NORTHCLAN website, or your purchase receipt.

When contacting support, please have your model number (1010) and purchase date ready.