

[Manuals.plus](#) /

› [MIRASTON](#) /

› MIRASTON 8.5QT Air Fryer (Model MS-2806-BLT) Instruction Manual

MIRASTON MS-2806-BLT

MIRASTON 8.5QT Air Fryer Instruction Manual

Model: MS-2806-BLT

INTRODUCTION

Thank you for choosing the MIRASTON 8.5QT Air Fryer. This appliance is designed to provide a healthier alternative to traditional frying, utilizing hot air circulation for crispy results with significantly less oil. Its large capacity and versatile functions make it suitable for various cooking needs. Please read this manual thoroughly before operating the appliance to ensure safe and efficient use.

This 8.5-quart air fryer features a clear viewing window, allowing you to monitor your food's progress without opening the basket and releasing heat. It offers 10-in-1 versatility, including air frying, broiling, reheating, keeping warm, and dehydrating, along with one-touch settings for common dishes like fries, fish, wings, vegetables, and meat. The preheat function ensures optimal cooking temperatures, and the flip reminder prompts you to shake the basket for even browning. The square basket design maximizes cooking space and promotes better air circulation. Its tilted smart digital screen provides effortless control, and the dishwasher-safe, non-toxic nonstick coating simplifies cleanup.



Image: The MIRASTON 8.5QT Air Fryer, showcasing its sleek stainless steel design, digital control panel, and transparent viewing window on the basket.

SAFETY INSTRUCTIONS

- Always place the air fryer on a stable, heat-resistant surface, away from walls and other appliances to ensure proper ventilation.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Keep children and pets away from the appliance during operation.
- Do not block the air inlet or outlet vents.
- Never use accessories or parts not recommended by the manufacturer.
- Unplug the air fryer when not in use and before cleaning. Allow it to cool completely before handling.

- Do not overfill the basket.
- Exercise caution when removing the hot basket and crisper tray.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all packaging materials, stickers, and labels from the air fryer.
2. **Cleaning:** Wash the air fryer basket and crisper tray with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely. Wipe the interior and exterior of the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, heat-resistant surface. Ensure there is at least 5 inches (13 cm) of clear space around the back and sides of the appliance.
4. **Initial Run:** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 350°F (175°C) to eliminate any manufacturing odors. A slight smell or smoke is normal during this process.
5. **Assembly:** Insert the crisper tray into the air fryer basket, then slide the basket firmly into the main unit until it clicks into place.

From indoors to outdoors
**Perfect for Every Chef,
 Every Need, Every Scene!**



Image: The air fryer basket, with its square design and crisper tray, being pulled out from the main unit.

OPERATING INSTRUCTIONS

Digital Control Panel

The MIRAston Air Fryer features a tilted smart digital touchscreen for easy operation.



Image: A detailed view of the digital control panel, showing temperature, time, and various cooking presets.

Basic Operation

1. **Power On:** Plug the air fryer into a grounded electrical outlet. The display will illuminate.
2. **Select Function:** Choose from 10 preset functions by tapping the corresponding icon on the digital screen. These include:
 - Air Fry
 - Broil

- Reheat
- Keep Warm
- Dehydrate
- Fries
- Fish
- Wings
- Vegetables
- Meat

3. **Adjust Temperature and Time:** After selecting a preset, you can adjust the temperature (up to 400°F) and time using the '+' and '-' buttons.
4. **Preheat Function:** Activate the preheat function for optimal cooking results. The air fryer will indicate when preheating is complete.
5. **Start Cooking:** Press the 'Start' button to begin the cooking cycle.
6. **Flip Reminder:** The air fryer will provide a "Turn Reminder" during the cooking cycle to prompt you to shake or flip your food for even browning.
7. **Monitoring Food:** Use the clear viewing window to check on your food's progress without interrupting the cooking cycle.
8. **Stop/Cancel:** Press the 'Stop/Cancel' button to pause or end the cooking cycle at any time.



Image: The air fryer's digital display showing a selection of food presets for quick cooking.

Official Product Video: Operation Overview

Your browser does not support the video tag.

Video: An official product video from MIRASTON demonstrating the features and operation of the 8.5QT Air Fryer, including the digital control panel and viewing window.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and optimal performance of your MIRASTON Air Fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Dishwasher Safe Parts:** The air fryer basket and crisper tray are dishwasher-safe. For best results, place them on the top rack.
3. **Hand Washing:** If hand washing, use hot water, dish soap, and a non-abrasive sponge. Avoid metal scouring pads

or harsh detergents that can damage the non-stick coating.

- 4. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
- 5. **Interior:** Clean the interior of the air fryer with a damp cloth and mild detergent. For stubborn food residue, a soft brush can be used. Ensure the interior is completely dry before next use.



Image: Illustration of the air fryer basket and crisper tray being cleaned, highlighting their dishwasher-safe feature and ease of manual cleaning.

TROUBLESHOOTING

If you encounter any issues with your MIRAston Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; main unit not properly assembled.	Ensure the power cord is securely plugged into a working outlet. Check if the basket is fully inserted.
Food is not cooked evenly.	Basket is overcrowded; food not shaken/flipped; incorrect temperature/time.	Do not overcrowd the basket. Shake or flip food halfway through cooking. Adjust temperature and time as needed.
White smoke coming from the appliance.	Greasy food; oil residue from previous use.	Clean the basket and crisper tray thoroughly after each use. For very greasy foods, drain excess oil.
Food is not crispy.	Not enough oil (for certain foods); basket overcrowded; incorrect temperature/time.	Lightly spray or toss food with oil. Ensure proper air circulation by not overcrowding. Increase temperature or cooking time if necessary.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	MIRASTON
Model Name	MS-2806-BLT
Capacity	8.5 Quarts
Product Dimensions (D x W x H)	15.6"D x 12.4"W x 13"H
Item Weight	11.5 Pounds
Material	Stainless Steel
Color	Black
Output Wattage	1500 Watts
Control Method	Touch
Special Features	Automatic Shut-Off, Temperature Control, Timer, Viewing Window, 10-in-1 Presets
Air Frying Technology	Hot Air Circulation
Nonstick Coating	Yes
Dishwasher Safe Parts	Basket and Crisper Tray

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official MIRASTON website. Keep your purchase receipt as proof of purchase for any warranty claims. For further assistance, you may contact MIRASTON customer service through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F5HP1S7N>

More documents and user manuals: <https://manuals.plus/>