

[Manuals.plus](#) /

› [NUZEZCJG](#) /

› NUZEZCJG Crankshaft Rear Oil Seal Installation Manual for QD32, TD27T, TD25 Engines (OEM 12279-43G05 Series)

NUZEZCJG NUZEZCJG

NUZEZCJG Crankshaft Rear Oil Seal Installation Manual

For QD32, TD27T, TD25 Engines (OEM 12279-43G05 Series)

1. INTRODUCTION

This manual provides essential information and step-by-step instructions for the proper installation, maintenance, and troubleshooting of the NUZEZCJG Crankshaft Rear Oil Seal. This component is designed for specific engine models, ensuring a reliable seal to prevent oil leaks from the rear of the crankshaft. Adherence to these instructions is crucial for optimal performance and longevity of the seal and engine.

2. PRODUCT OVERVIEW

The NUZEZCJG Crankshaft Rear Oil Seal is a critical engine component manufactured from durable metal, designed to maintain the integrity of the engine's lubrication system by preventing oil leakage from the rear crankshaft. It is compatible with QD32, P27, TD27T, and TD25 engine types. This seal replaces OEM part numbers 12279-43G05, 12279-43G04, 12279-43G03, 1227943G05, and 122797F401.




Figure 2.1: Overall view of the NUZEZCJG Crankshaft Rear Oil Seal assembly, showing the metal housing and the integrated rubber sealing element. This image displays the complete unit ready for installation.



Figure 2.2: A detailed close-up of the sealing lip of the crankshaft rear oil seal. This view highlights the precision-engineered grooves and contours designed to effectively contain engine oil and prevent leaks.

3. SAFETY INFORMATION

Always prioritize safety when working on automotive components. Failure to follow safety precautions can result in serious injury or damage to the vehicle.

- Wear appropriate personal protective equipment (PPE), including safety glasses and gloves.
- Ensure the vehicle is securely supported on jack stands before working underneath it. Never rely solely on a jack.
- Disconnect the battery's negative terminal before starting any work to prevent accidental electrical discharge.
- Allow the engine to cool completely before beginning work to avoid burns from hot engine components or fluids.
- Keep a fire extinguisher nearby.
- Dispose of old oil and parts responsibly according to local regulations.

4. PRE-INSTALLATION STEPS

Before installing the new crankshaft rear oil seal, ensure you have all necessary tools and have prepared the engine area.

4.1 Tools and Materials Required

- Socket set and wrenches
- Torque wrench
- Crankshaft rear oil seal removal tool (if available) or pry tools
- Crankshaft rear oil seal installation tool (recommended) or appropriate size socket/driver
- Clean rags and degreaser
- New crankshaft rear oil seal (NUZEZCJG)
- Engine oil (for lubrication during installation)
- Gasket scraper or razor blade

4.2 Engine Preparation

1. Safely lift and support the vehicle.
2. Drain the engine oil.
3. Remove the transmission assembly to gain access to the flywheel and crankshaft rear area. Consult your vehicle's service manual for specific transmission removal procedures.
4. Remove the flywheel and any associated components to expose the old crankshaft rear oil seal.

5. INSTALLATION PROCEDURE

Follow these steps carefully for the correct installation of the NUZEZCJG Crankshaft Rear Oil Seal.

1. **Remove the Old Seal:** Carefully pry out the old crankshaft rear oil seal using a suitable removal tool or pry bar. Be extremely cautious not to scratch or damage the crankshaft sealing surface or the engine block.
2. **Clean the Sealing Surface:** Thoroughly clean the crankshaft and engine block sealing surfaces. Remove all traces of old oil, grease, and gasket material using a gasket scraper and degreaser. Ensure the surface is smooth and free of debris.
3. **Inspect Crankshaft:** Inspect the crankshaft for any grooves, nicks, or wear on the sealing surface. Significant damage may require crankshaft repair or replacement to ensure a proper seal.
4. **Lubricate the New Seal:** Apply a thin, even coat of clean engine oil to the inner lip of the new NUZEZCJG crankshaft rear oil seal. This lubrication aids in smooth installation and prevents damage to the seal.
5. **Install the New Seal:** Position the new seal squarely over the crankshaft. Using a specialized seal installation tool or an appropriately sized socket/driver, gently and evenly tap the seal into place until it is fully seated. Ensure the seal is installed straight and not cocked. Do not use excessive force.
6. **Reassemble Components:** Reinstall the flywheel, transmission, and any other components removed during the process. Refer to your vehicle's service manual for correct torque specifications for all fasteners.
7. **Refill Engine Oil:** Refill the engine with the correct type and amount of engine oil.
8. **Test for Leaks:** Start the engine and allow it to reach operating temperature. Carefully inspect the newly installed seal area for any signs of oil leakage.

6. MAINTENANCE

Proper maintenance helps ensure the longevity of your crankshaft rear oil seal and overall engine health.

- **Regular Oil Changes:** Adhere to the manufacturer's recommended oil change intervals using the specified engine oil. Clean oil helps prevent premature wear on seals.
- **Monitor for Leaks:** Periodically inspect the area around the crankshaft rear oil seal for any signs of oil leakage. Early detection can prevent more significant issues.
- **Maintain Proper Crankcase Ventilation:** Ensure the Positive Crankcase Ventilation (PCV) system is functioning correctly. A clogged PCV system can lead to excessive crankcase pressure, which can force oil past seals.

7. TROUBLESHOOTING

If you experience issues after installing the crankshaft rear oil seal, consider the following common problems and solutions.

Problem	Possible Cause	Solution
Oil leak from rear of engine	• Improper seal installation (cocked, damaged during install) • Damaged crankshaft sealing surface • Incorrect seal type • Excessive crankcase pressure	• Re-inspect and re-install seal correctly • Inspect crankshaft for damage; repair or replace if necessary • Verify correct seal for engine model • Check PCV system for blockages
Premature seal failure	• Contaminated engine oil • Overheating engine • Incorrect engine oil viscosity	• Ensure regular oil changes with correct oil • Address engine overheating issues • Use recommended engine oil viscosity

8. SPECIFICATIONS

Key specifications for the NUZEZCJG Crankshaft Rear Oil Seal.

- **Part Type:** Crankshaft Rear Oil Seal
- **Material:** Metal
- **Compatible Engines:** QD32, P27, TD27T, TD25
- **OEM Cross-Reference:** 12279-43G05, 12279-43G04, 12279-43G03, 1227943G05, 122797F401
- **Item Weight:** 1.76 ounces (approximately 50 grams)
- **Package Dimensions:** 0.39 x 0.39 x 0.39 inches (approximate)
- **Assembly Required:** No (component is pre-assembled)
- **Number of Pieces:** 1
- **Manufacturer:** NUZEZCJG
- **Model Number:** NUZEZCJG

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question