

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Fafeicy](#) /
- › [Fafeicy PM2118 Clamp Multimeter Instruction Manual](#)

Fafeicy PM2118

Fafeicy PM2118 Clamp Multimeter Instruction Manual

Model: PM2118

Brand: Fafeicy

1. INTRODUCTION

This manual provides essential instructions for the safe and effective operation of your Fafeicy PM2118 Clamp Multimeter. Please read this manual thoroughly before use and retain it for future reference. This device is designed for measuring AC/DC current, AC/DC voltage, frequency, impedance, capacitance, and temperature.

Safety Information

- Always ensure the multimeter is in the correct function mode before connecting to a circuit.
- Do not attempt to measure voltages or currents exceeding the specified maximum limits.
- Exercise extreme caution when working with live circuits. High voltages can cause severe injury or death.
- Inspect test leads for damage before each use. Do not use if insulation is compromised.
- Replace batteries promptly when the low battery indicator appears to ensure accurate readings.
- Do not operate the multimeter in wet environments or explosive atmospheres.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x Fafeicy PM2118 Clamp Multimeter
- 2 x Test Probes (Red and Black)
- 1 x Thermocouple (for temperature measurement)
- 1 x Black Storage Bag
- 1 x User Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your PM2118 Clamp Multimeter.



Figure 3.1: Labeled diagram of the PM2118 Clamp Multimeter, showing the clamp, clamp trigger, function knob, data hold/backlight button, surge/NCV measurement button, LCD screen, and probe ports.

- **Clamp:** Used for non-contact AC current measurement.
- **Clamp Trigger:** Opens and closes the clamp jaws.
- **Function Knob:** Selects the desired measurement function (e.g., ACV, DCV, Resistance, Frequency, Temperature).
- **Data Hold/Backlight Button:** Freezes the current reading on the display or activates the backlight.
- **NCV (Non-Contact Voltage) Button:** Activates the non-contact voltage detection feature.
- **LCD Screen:** Displays measurement readings and indicators.
- **Probe Ports:** Connect test leads for voltage, resistance, capacitance, and other measurements.



8 kinds of measurement functions, you can select according to your needs

Figure 3.2: Close-up view of the multimeter's function knob, highlighting the various measurement functions available for selection.

4. SETUP

4.1 Battery Installation

The PM2118 Clamp Multimeter requires two 1.5V AAA batteries (not included).

1. Ensure the multimeter is turned OFF.
2. Locate the battery compartment cover on the back of the device.
3. Use a screwdriver to loosen the screw securing the battery cover.
4. Remove the battery cover.
5. Insert two 1.5V AAA batteries, observing the correct polarity (+ and -) as indicated inside the compartment.
6. Replace the battery cover and tighten the screw securely.



Figure 4.1: View of the battery compartment on the back of the multimeter, illustrating the process of battery installation.

5. OPERATING INSTRUCTIONS

This section details how to perform various measurements with your PM2118 Clamp Multimeter.

5.1 AC/DC Voltage Measurement (V~)

1. Turn the function knob to the "V~" position for AC voltage or "V=" for DC voltage.
2. Insert the red test lead into the "VΩHz" input jack and the black test lead into the "COM" input jack.
3. Connect the test probes in parallel across the circuit or component you wish to measure.
4. Read the voltage value displayed on the LCD screen.



Figure 5.1: Example of measuring socket voltage using the test probes.

5.2 AC Current Measurement (A~)

The clamp function is used for non-contact AC current measurement.

1. Turn the function knob to the "A~" position.
2. Press the clamp trigger to open the jaws.
3. Enclose only one conductor of the circuit within the clamp jaws. Ensure the jaws are fully closed.
4. Read the AC current value displayed on the LCD screen.



Figure 5.2: Close-up of the clamp jaws, used for non-contact AC current measurement.

5.3 Resistance Measurement (Ω)

1. Turn the function knob to the " Ω " position.
2. Insert the red test lead into the "V Ω Hz" input jack and the black test lead into the "COM" input jack.
3. Ensure the circuit or component is de-energized before measuring resistance.
4. Connect the test probes across the component.
5. Read the resistance value displayed on the LCD screen.

1. Turn the function knob to the "°C/°F" position.
2. Connect the thermocouple to the appropriate input jacks (usually marked TEMP or similar, or use the VΩHz and COM ports if specified by the device).
3. Place the tip of the thermocouple on or in the object whose temperature you wish to measure.
4. Read the temperature value displayed on the LCD screen.



Figure 5.4: Example of temperature measurement using the provided thermocouple.

5.7 Non-Contact Voltage (NCV) Detection

1. Press the "NCV" button.
2. Move the top end of the multimeter near a live conductor.
3. The multimeter will emit an audible beep and/or flash an indicator light when AC voltage is detected, indicating the presence of a live wire without direct contact.

5.8 Continuity Test

1. Turn the function knob to the continuity symbol (usually a speaker icon).
2. Insert the red test lead into the "VΩHz" input jack and the black test lead into the "COM" input jack.

3. Connect the test probes across the component or circuit path.
4. If the circuit is continuous (low resistance), the multimeter will emit an audible beep.

5.9 Data Hold Function

Press the "HOLD" button (often combined with backlight) to freeze the current reading on the display. Press it again to release the hold function.

5.10 Backlight Function

Press and hold the "HOLD" button for a few seconds to activate the display backlight. Press and hold again to turn it off.

6. MAINTENANCE

6.1 Cleaning

Wipe the multimeter casing with a damp cloth and mild detergent. Do not use abrasive cleaners or solvents. Ensure the device is dry before storage or next use.

6.2 Battery Replacement

Refer to Section 4.1 for battery installation instructions. Replace batteries when the low battery indicator appears on the display to maintain measurement accuracy.

6.3 Storage

When not in use for extended periods, remove the batteries to prevent leakage. Store the multimeter in its protective bag in a cool, dry place, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No display or dim display	Dead or low batteries; incorrect battery polarity.	Replace batteries, ensuring correct polarity.
Inaccurate readings	Incorrect function selected; damaged test leads; low battery; external interference.	Verify function knob setting; check test leads for damage; replace batteries; move away from strong electromagnetic fields.
No continuity beep	Open circuit; high resistance; incorrect function.	Ensure circuit is closed; check for breaks; verify function knob is on continuity.
Clamp measurement not working	Incorrect function; jaws not fully closed; measuring DC current (clamp is for AC only).	Ensure function knob is on AC current; close jaws completely; use test leads for DC current if applicable.

8. SPECIFICATIONS

Parameter	Value
Model	PM2118
Power Supply	2 x 1.5V AAA batteries (not included)
Dimensions (L x W x H)	187 x 65 x 38 mm (7.3 x 2.5 x 1.5 inches)
Weight	Approx. 357g (12.6 ounces)
Measurement Functions	AC/DC Current, AC/DC Voltage, Frequency, Impedance, Capacitance, Temperature
Special Features	Non-Contact Voltage (NCV) Detection, Continuity Test, Data Hold, Auto Power Off, Backlight
Safety Rating	600V CAT III



Figure 8.1: Dimensions of the PM2118 Clamp Multimeter.

9. WARRANTY AND SUPPORT

Fafeicy products are designed for reliability and performance. For warranty information or technical support, please contact your retailer or the manufacturer directly. Please have your product model number (PM2118) and purchase date available when seeking support.

For further assistance, please visit the official Fafeicy store or contact their customer service department.

