

[Manuals.plus](#) /

> [CUCKOO](#) /

> CUCKOO CRP-JHT1012F Twin Pressure Multi-Cooker Instruction Manual

CUCKOO CRP-JHT1012F

CUCKOO CRP-JHT1012F Twin Pressure Multi-Cooker Instruction Manual

Model: CRP-JHT1012F

INTRODUCTION

Thank you for purchasing the CUCKOO CRP-JHT1012F Twin Pressure Multi-Cooker. This appliance is designed to provide versatile cooking options, combining both pressure and non-pressure cooking capabilities. Please read this manual thoroughly before operating the multi-cooker to ensure safe and efficient use. Keep this manual for future reference.

SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury. This multi-cooker is equipped with 22 safety features for secure operation.

- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the power voltage matches the rating label on the appliance.
- Keep out of reach of children. Close supervision is necessary when the appliance is used near children.
- Do not operate the appliance if the power cord or plug is damaged.
- Always ensure the lid is properly closed and locked before operating under pressure.
- Do not touch hot surfaces. Use handles or knobs.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not use attachments not recommended by the manufacturer.

PRODUCT OVERVIEW

The CUCKOO CRP-JHT1012F is a sophisticated multi-cooker designed for ease of use and culinary versatility. Key features include:

- **Twin Pressure Technology:** Offers both pressure and non-pressure cooking options.
- **14 Versatile Cooking Modes:** Includes GABA rice, porridge, slow cooking, and more.
- **Full Stainless-Steel Inner Pot:** Features X-Wall Black Shine coating for durability and easy cleaning.
- **User-Friendly Interface:** Direct touch menu display and multi-language voice navigation.
- **Enhanced Safety:** Equipped with 22 safety features for reliable operation.



Image: Front view of the CUCKOO CRP-JHT1012F Twin Pressure Multi-Cooker, displaying its control panel and digital clock.



Image: Side view of the CUCKOO CRP-JHT1012F Twin Pressure Multi-Cooker, showing its compact size suitable for kitchen counters.

SETUP

1. **Unpacking:** Carefully remove the multi-cooker and all accessories from the packaging. Retain packaging for future transport or storage.
2. **Initial Cleaning:** Before first use, wash the inner pot, inner lid packing, and all removable accessories (measuring cup, scoop) with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main body with a damp cloth.
3. **Placement:** Place the multi-cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure adequate ventilation around the appliance.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. The display will illuminate.

OPERATING INSTRUCTIONS

The CRP-JHT1012F offers various cooking modes. Refer to the direct touch menu display and multi-language voice navigation for guidance during operation.

General Cooking Steps:

- 1. Prepare Ingredients:** Measure and prepare your ingredients according to your recipe.
- 2. Add to Inner Pot:** Place the prepared ingredients into the stainless-steel inner pot.
- 3. Close Lid:** Ensure the inner pot is correctly seated. Close the outer lid securely until it locks into place.
- 4. Select Cooking Mode:** Use the direct touch menu to select your desired cooking mode (e.g., White Rice, GABA Rice, Porridge, Slow Cook). The voice navigation will guide you.
- 5. Adjust Settings (if necessary):** For some modes, you may need to adjust cooking time or pressure level.
- 6. Start Cooking:** Press the "Start" button. The multi-cooker will begin the cooking process.
- 7. Pressure Release (for pressure modes):** Once cooking is complete, the multi-cooker will automatically release pressure or indicate when it is safe to open. Follow the appliance's instructions for safe pressure release.
- 8. Serve:** Carefully open the lid and serve your cooked meal.

Specific Modes:

- **GABA Rice:** This mode is designed to sprout brown rice, enhancing its nutritional value. Follow specific instructions for soaking and cooking GABA rice.
- **Porridge:** Ideal for creamy porridges. Adjust water-to-grain ratio as per desired consistency.
- **Slow Cook:** Use for dishes requiring long, gentle cooking. Ensure the steam vent is set to the non-pressure position if applicable.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your multi-cooker.

- 1. Unplug:** Always unplug the appliance and allow it to cool completely before cleaning.
- 2. Inner Pot:** Wash the stainless-steel inner pot with warm, soapy water and a non-abrasive sponge. The X-Wall Black Shine coating is designed for easy cleaning.
- 3. Inner Lid Packing:** Remove the inner lid packing and wash it thoroughly. Ensure it is properly reinstalled before next use.
- 4. Steam Vent:** Clean the steam vent and pressure weight regularly to prevent blockages. Refer to the detailed instructions in the full manual for disassembly and reassembly.
- 5. Exterior:** Wipe the exterior of the multi-cooker with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- 6. Storage:** Store the clean and dry multi-cooker in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your CUCKOO CRP-JHT1012F, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Power cord not properly plugged in; no power at outlet.	Ensure power cord is securely plugged into a working outlet. Check household circuit breaker.

Problem	Possible Cause	Solution
Steam leaks from lid during cooking.	Lid not properly closed; inner lid packing not installed correctly or damaged; food debris on sealing surfaces.	Ensure lid is securely locked. Check and re-install inner lid packing. Clean any food debris from the lid and pot rim. Replace packing if damaged.
Rice is undercooked or overcooked.	Incorrect water-to-rice ratio; wrong cooking mode selected.	Adjust water and rice measurements according to the recipe. Select the appropriate cooking mode for the type of rice.
Voice navigation not working.	Volume set to minimum or muted; language setting incorrect.	Adjust the volume settings. Check and change the language setting via the control panel.

For further assistance, please contact CUCKOO customer support.

SPECIFICATIONS

Feature	Detail
Brand	CUCKOO
Model Number	CRP-JHT1012F
Capacity	5.5 Liters
Material	Stainless steel
Colour	Bronze & Silver
Product Dimensions (D x W x H)	42.3D x 30.5W x 30H centimetres
Wattage	1000 watts
Control Method	Touch, Voice
Operation Mode	Both Automatic and Manual
Special Features	Cool-Touch Exterior, Twin Pressure Technology, X-Wall Black Shine Coating
Included Components	Instruction Manual, Measuring Cup, Scoop

WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official CUCKOO website. For technical support, troubleshooting beyond this manual, or spare parts, please contact CUCKOO customer service.

CUCKOO Customer Service: Please refer to your regional CUCKOO website or product documentation for contact details.

