



Manuals.plus /

› Maxcom /

› Maxcom Comfort MM445 4G Mobile Phone User Manual

## Maxcom MM445

# Maxcom Comfort MM445 4G Mobile Phone User Manual

Model: MM445 | Brand: Maxcom

[Introduction](#)   [Safety Information](#)   [Device Overview](#)   [Setup](#)   [Operating](#)  
[Instructions](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

Welcome to the user manual for your Maxcom Comfort MM445 4G Mobile Phone. This device is designed for ease of use, reliability, and modern communication, making it an ideal choice for users who value simplicity and essential features. The MM445 4G combines intuitive operation with important safety features, ensuring a secure and connected experience.

Key features include a dedicated SOS button for quick emergency assistance, an ICE (In Case of Emergency) function to store vital medical and contact information, and 4G network support for fast and stable connections. Please read this manual thoroughly to understand all functions and ensure proper use of your new phone.

## 2. SAFETY INFORMATION

Before using your Maxcom MM445 4G, please read these safety guidelines carefully to prevent injury or damage to the device.

- **Battery Safety:** Use only Maxcom-approved batteries and chargers. Do not short-circuit, puncture, or expose the battery to extreme temperatures. Dispose of batteries properly.
- **Charging:** Ensure the charger is connected to a compatible power source. Do not use damaged chargers or cables.
- **Water Resistance:** This phone is not waterproof. Avoid exposure to liquids.
- **Hearing Protection:** Avoid prolonged listening at high volume levels to prevent hearing damage.
- **Driving Safety:** Do not use your phone while driving. Always prioritize road safety.
- **Medical Devices:** Maintain a safe distance between the phone and medical devices like pacemakers. Consult your physician and medical device manufacturer for specific guidelines.
- **Disposal:** Do not dispose of the phone or battery with household waste. Follow local regulations for electronic waste recycling.

### **3. PACKAGE CONTENTS**

---

Verify that your package contains the following items:

- Maxcom Comfort MM445 4G Mobile Phone
- Battery
- Charger
- User Manual (this document)
- Charging Dock (if included with your specific model)

### **4. DEVICE OVERVIEW**

---

Familiarize yourself with the physical components of your Maxcom MM445 4G phone.



**Figure 4.1: Front View of Maxcom MM445 4G.** This image displays the front of the Maxcom MM445 4G mobile phone, showing its screen, keypad with large buttons, and the Maxcom logo. The screen shows the time (12:00), date (27.02.2023 Tue), network signal, and battery indicator.



**Figure 4.2: Back View of Maxcom MM445 4G.** This image shows the rear of the Maxcom MM445 4G mobile phone, highlighting the camera lens and the prominent red SOS button. A speaker grille is also visible.



Figure 4.3: Maxcom MM445 4G with Charging Dock. This composite image provides various views of the Maxcom MM445 4G phone, including front, side, and back profiles. It also illustrates the phone placed in its dedicated charging dock, emphasizing its ease of charging.

## 4.1. Keypad Layout

- **Navigation Keys:** Up, Down, Left, Right, and OK/Confirm button for menu navigation.
- **Call/Green Button:** To make or answer calls, and to access call logs.
- **End/Red Button:** To end calls, reject incoming calls, or power the phone on/off (long press).
- **SOS Button:** Located on the back, for emergency calls (see Section 5.3).
- **Numeric Keypad:** For dialing numbers and text input.
- **Function Keys:** Context-sensitive keys below the screen (e.g., Menu, Contacts).

## 5. SETUP

### 5.1. Inserting the SIM Card

1. Power off the phone and remove the back cover.
2. Carefully remove the battery if it is already inserted.
3. Locate the SIM card slot(s). Insert your SIM card(s) with the gold contacts facing down, ensuring it clicks into place.
4. If applicable, insert a microSD card for additional storage (sold separately).

### 5.2. Inserting the Battery

1. Align the battery contacts with the terminals inside the battery compartment.
2. Gently press the battery down until it is securely seated.
3. Replace the back cover, ensuring it snaps firmly into place.

### 5.3. Charging the Phone

Before first use, fully charge the phone battery.

- **Using the Wall Charger:** Connect the charger cable to the phone's charging port and plug the charger into a power outlet.
- **Using the Charging Dock:** Place the phone into the charging dock, ensuring it is properly seated. Connect the charger cable to the dock and plug it into a power outlet. The charging indicator on the phone or dock will illuminate.

## 5.4. Powering On/Off

- **To Power On:** Press and hold the **End/Red Button** until the screen lights up.
- **To Power Off:** Press and hold the **End/Red Button** until the power off options appear, then select "Power off" or confirm.

## 6. OPERATING INSTRUCTIONS

---

### 6.1. Making and Receiving Calls

- **To Make a Call:** Enter the phone number using the keypad and press the **Call/Green Button**.
- **To Answer a Call:** Press the **Call/Green Button** when the phone rings.
- **To End/Reject a Call:** Press the **End/Red Button**.

### 6.2. Sending and Receiving Messages

1. From the main menu, navigate to "Messages".
2. Select "Write message" or "New SMS".
3. Enter your message using the keypad.
4. Enter the recipient's number or select from contacts.
5. Select "Send".

### 6.3. Using the SOS Button

The SOS button is a critical safety feature designed for emergencies.

1. **Setup:** Before using, configure emergency contacts in the phone's settings (usually under "SOS Settings" or "Emergency Contacts"). You can typically add up to 5 numbers.
2. **Activation:** In an emergency, press and hold the **SOS Button** on the back of the phone for a few seconds.
3. **Functionality:** The phone will automatically dial the pre-set emergency numbers in sequence until one is answered. It may also send an emergency SMS message to these contacts.

**Important:** Ensure your emergency contacts are aware they are listed and understand the function of the SOS button. Test the function periodically in a non-emergency situation to ensure it is working correctly.

### 6.4. ICE (In Case of Emergency) Function

The ICE function allows you to store vital personal and medical information that can be accessed by first responders in an emergency, even if the phone is locked.

1. **Setup:** Navigate to "ICE Settings" or "Emergency Info" in the phone's menu.
2. **Information to Store:** Enter details such as your name, emergency contacts (separate from SOS contacts), medical conditions, allergies, blood type, and any medications you are taking.
3. **Access:** This information is typically accessible from the lock screen or through a specific menu option without needing to unlock the phone.

### 6.5. Basic Internet Access (4G)

The Maxcom MM445 4G supports basic internet connectivity.

- Ensure your SIM card has an active data plan.
- Access the "Browser" or "Internet" application from the main menu.
- You can use this for basic web browsing or accessing simple online services.

## 7. MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the phone's screen and body. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the phone regularly. Do not leave the phone in direct sunlight or in hot environments.
- **Storage:** If storing the phone for an extended period, charge the battery to about 50% and store it in a cool, dry place.
- **Software Updates:** Check for available software updates periodically through the phone's settings menu to ensure optimal performance and security.

## 8. TROUBLESHOOTING

---

If you encounter issues with your phone, try the following solutions before seeking professional assistance.

Problem	Possible Cause	Solution
Phone does not power on.	Battery is discharged or not inserted correctly.	Charge the battery. Ensure the battery is correctly inserted.
Cannot make or receive calls.	No network signal, SIM card not inserted, or SIM card issue.	Check network signal strength. Reinsert SIM card. Contact your service provider.
Poor call quality.	Weak signal, interference.	Move to an area with better signal. Avoid obstructions.
SOS button not working.	Emergency contacts not set up, or numbers are invalid.	Verify SOS settings and ensure emergency contacts are correctly configured.
Phone freezes or becomes unresponsive.	Temporary software glitch.	Remove and reinsert the battery to perform a soft reset.

## 9. SPECIFICATIONS

---

Feature	Detail
Brand	Maxcom
Model Number	MM445 (5908235977911)
Manufacturer	MaxCom
ASIN	B0F7HMHBP5
Item Dimensions	10 x 140 x 90 millimeters
Network Support	4G
Keypad Type	Physical Keypad
Special Features	SOS Button, ICE Function
Spare Parts Availability	Information unavailable
Guaranteed Software Updates Until	Information not available

## 10. WARRANTY & SUPPORT

Your Maxcom Comfort MM445 4G Mobile Phone is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details. For technical support, service, or further inquiries, please contact your retailer or the official Maxcom customer service. Contact information can typically be found on the Maxcom website or in the documentation provided with your purchase. Please have your product model number (MM445) and ASIN (B0F7HMHBP5) ready when contacting support.

