

[Manuals.plus](#) /

› [SKMEI](#) /

› SKMEI 2499 Triple Time Zone Sports Watch User Manual

SKMEI 2499

SKMEI 2499 Triple Time Zone Sports Watch User Manual

Model: SKMEI 2499

INTRODUCTION

Thank you for choosing the SKMEI 2499 Triple Time Zone Sports Watch. This manual provides essential information for the proper setup, operation, and maintenance of your watch. Please read it carefully to ensure optimal performance and longevity of your device.



Image: The SKMEI 2499 watch displayed on a wrist, showcasing its design.

The SKMEI 2499 watch features a robust design with multiple functions accessible via its four buttons and a clear display. Understanding the layout is key to its operation.

Button Functions:

- **LIGHT Button:** Activates the LED backlight for improved visibility in low-light conditions.
- **MODE Button:** Cycles through different operational modes (Time, Alarm, Stopwatch, Dual Time).
- **START/STOP Button:** Used to start and stop functions like the stopwatch, or to adjust settings.
- **RESET Button:** Used to reset values (e.g., stopwatch) or confirm settings.



Image: A detailed diagram illustrating the watch's buttons (Light, Mode, Start/Stop, Reset) and display indicators (Time, Date, Week, Seconds).

Display Features:

- **Analog Display:** Traditional hour and minute hands.
- **Digital Display:** Shows time, date, day of the week, and other mode-specific information.

- **Triple Time Zone:** Allows tracking of three different time zones simultaneously.
- **Luminous Display:** Features an LED backlight for clear reading in the dark.

Luminous Display

LED light, clear reading time



Image: A close-up view of the watch face, demonstrating the luminous digital display and hands for easy readability.

Watch Components:



Watch Case



Watch Dial



Watch Band



Watch Mirror



Watch Clasp



Back Cover

Image: An exploded diagram showing the main components of the watch: Watch Case, Watch Dial, Watch Band, Watch Mirror, Watch Clasp, and Back Cover.

SETUP

Setting Digital Time and Date:

1. In normal time mode, press the **MODE** button repeatedly until the digital time display starts flashing.
2. Press the **START/STOP** button to adjust the flashing segment (seconds, minutes, hours, date, month, day of week).
3. Use the **RESET** button to change the value of the flashing segment.
4. Once all settings are correct, press the **MODE** button to exit setting mode.

Setting Analog Time:

The analog time is typically set independently. Pull out the crown (the knob on the side of the watch case) and rotate it to adjust the hour and minute hands. Push the crown back in to synchronize the analog time.

Setting Alarm:

1. From normal time mode, press the **MODE** button until the alarm time is displayed.
2. Press the **START/STOP** button to select the hour or minute to adjust.
3. Use the **RESET** button to change the value.
4. Press **MODE** to exit. To activate/deactivate the alarm, press **START/STOP** and **RESET** simultaneously in alarm mode.

Setting Triple Time Zone:

The watch allows for setting up to three distinct digital time zones. Navigate to the dual time mode using the **MODE** button. Follow similar steps as setting the main digital time to adjust the secondary and tertiary time displays.

OPERATING MODES

Chronograph (Stopwatch):

1. Press the **MODE** button until the stopwatch display appears (usually showing 00:00:00).
2. Press the **START/STOP** button to start the stopwatch.
3. Press **START/STOP** again to pause/resume.
4. Press the **RESET** button to reset the stopwatch to zero.

LED Backlight:

Press the **LIGHT** button to illuminate the display. The backlight will remain active for a few seconds.

WATER RESISTANCE GUIDELINES

The SKMEI 2499 watch is rated for 50 meters (5 ATM) of water resistance. This means it is suitable for daily use, hand washing, rain, and short periods of swimming in shallow water. It is **not** suitable for diving, snorkeling, or high-pressure water activities.

- Do not press any buttons while the watch is submerged in water.
- Avoid exposing the watch to hot water or steam, as this can compromise the seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.

50M WATERPROOF



Image: The watch being exposed to water, illustrating its 50-meter water resistance capability for activities like swimming and daily water exposure.

MAINTENANCE

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- **Storage:** Store the watch in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery:** When the display dims or functions become erratic, the battery may need replacement. It is recommended to have the battery replaced by a professional to maintain water resistance.
- **Avoid Chemicals:** Do not expose the watch to solvents, detergents, perfumes, or other chemical agents, as they can damage the case, strap, or seals.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Digital display is blank or dim.	Low battery.	Replace the battery.
Buttons are unresponsive.	Watch may be in a locked mode or water ingress.	Try resetting the watch (if applicable, refer to specific model reset instructions) or ensure it is dry. If issue persists, seek professional service.
Time is inaccurate.	Battery low or incorrect setting.	Check battery and reset time according to 'Setting Time' instructions.
Condensation inside the watch.	Temperature changes or compromised water resistance.	Avoid extreme temperature changes. If condensation persists, seek professional inspection immediately to prevent damage.

SPECIFICATIONS

Detailed technical specifications for the SKMEI 2499 watch:

- **Model Number:** SKMEI-9169
- **Display Type:** Analog - Digital
- **Movement:** Automatic (Digital component is quartz)
- **Water Resistance Depth:** 50 Meters (5 ATM)
- **Case Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Band Material:** Silicone (TPU)
- **Dial Window Material:** Glass
- **Clasp Type:** Buckle
- **Special Features:** Triple Time Zone, Alarm, Stopwatch, Date, Week, LED Light, 12/24 hour clock, Countdown.
- **Power Source:** Battery Powered
- **Case Width:** 54.7mm / 2.15in
- **Case Thickness:** 18.0mm / 0.7in
- **Band Width:** 30.2mm / 1.19in
- **Watch Length:** 280mm / 11.02in
- **Weight:** 66.2g

PRODUCT PARAMETER



BRAND: SKMEI

WEIGHT: 66.2g

MOV' T: DIGITAL

CRYSTAL: RESIN

CASE: ABS

BAND: TPU

BUCKLE: STAINLESS STEEL

W / P : 50M

FUNCTION: 3Time, Chrono, Date, Week, LED Light, 12/24 hour clock, Countdown.



Case width: 54.7mm/2.15in



Case thickness: 18mm/0.7in



Band Width: 30.2mm/1.19in



Watch length: 280mm/11.02in

Image: A visual representation of the watch's dimensions and key product parameters, including materials and functions.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact the retailer. Standard return policies typically apply, such as a 30-day return window from the purchase date. Keep your proof of purchase for any warranty claims or service requests.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question