

[manuals.plus](#) /› [SUNPOW](#) /› [SUNPOW MD13 Metal Detector User Manual](#)

SUNPOW MD13-US

SUNPOW MD13 Metal Detector User Manual

Model: MD13-US

1. INTRODUCTION

Thank you for choosing the SUNPOW MD13 Metal Detector. This manual provides essential information for the proper setup, operation, and maintenance of your device. Please read it thoroughly before use to ensure optimal performance and longevity of your metal detector.

The SUNPOW MD13 is designed for both adults and kids, offering stable anti-interference capabilities, higher accuracy, and a large LCD display for clear information. Its IP68 waterproof search coil allows for versatile use in various environments.

2. SETUP AND ASSEMBLY

Follow these steps to assemble your SUNPOW MD13 Metal Detector:

- 1. Unpack Components:** Carefully remove all components from the packaging. Ensure you have the main control unit, adjustable stem, search coil, armrest, headphones, foldable shovel, and two 9V batteries.
- 2. Install Batteries:** Open the battery compartment on the main control unit and insert the two 9V batteries, ensuring correct polarity. Close the compartment securely.
- 3. Attach Search Coil:** Connect the search coil to the lower stem using the provided bolt and washers. Ensure the washers are properly seated in the slots to prevent wobbling.
- 4. Assemble Stem:** Connect the lower stem (with the search coil) to the middle stem, and then connect the middle stem to the upper stem. The stem is adjustable to suit different user heights.
- 5. Mount Control Unit:** Slide the main control unit onto the top of the upper stem. Secure it in place.
- 6. Connect Search Coil Cable:** Wrap the search coil cable neatly around the stem and plug the connector into the port on the main control unit. Ensure a snug fit.
- 7. Attach Armrest:** Secure the armrest to the upper stem. Adjust its position for comfortable use.
- 8. Connect Headphones:** Plug the headphones into the designated audio jack on the control unit.




Figure 1: Assembled SUNPOW MD13 Metal Detector with included accessories (headphones, foldable shovel, batteries).

DISCOVER WITH CONFIDENCE

8" Waterproof Search Coil

Anti-interference Material

Headset Support

Ergonomic Design

Adjustable Stem

Professional LCD Display



Suitable for beginners



Stable & High accuracy



Lightweight & easy to carry



IP68 Waterproof

Figure 2: Detailed view of the metal detector's components, including the 8-inch waterproof search coil, adjustable stem, and professional LCD display.

3. OPERATING INSTRUCTIONS

The SUNPOW MD13 features a large LCD display and intuitive controls for easy operation.

3.1 Control Panel Overview

SIMPLE & INTUITIVE & CLEAR



Figure 3: The clear and intuitive LCD display shows target ID, depth, sensitivity, volume, and mode indicators. Buttons for Power On/Off, Pinpoint, Mode Select, and Sensitivity/Volume Adjust are clearly visible.

3.2 Detection Modes

The MD13 offers four distinct detection modes:

- **All Metal Mode:** Detects all types of metals. Ideal for general treasure hunting when you want to find everything.
- **Notch Mode:** Allows you to eliminate unwanted metals. You can selectively ignore certain metal types (e.g., iron, pull tabs) to focus on more valuable targets.
- **Pinpoint Mode (PP):** Used to precisely locate the target once a general area has been identified. This helps in minimizing digging and quickly retrieving the item.

- **Memory Mode:** Detects only the memorized metal type. This is useful for repeatedly searching for a specific type of target.




Figure 4: Visual representation of the four detection modes and their primary functions.

3.3 Target Identification and Depth

The large LCD screen provides clear information about detected targets:

- **Target ID:** A numerical value (0-99) indicates the probable type of metal. Different ranges correspond to different metals (e.g., iron, 5-cent coins, 1-cent coins, 10-cent coins, 25-cent coins, 50-cent coins).
- **Depth Indicator:** Shows the approximate depth of the detected object, helping you determine how deep to dig.

- **Audio Tones:** The detector emits distinct audio tones for different metal types, allowing for identification without constantly looking at the screen.



Figure 5: The LCD screen displaying target identification values and corresponding metal types.

3.4 Search Coil Usage

The 8-inch search coil is IP68 waterproof, allowing for detection in shallow water. **Note: The control box is not waterproof and should not be submerged.**

IP68 WATERPROOF SEARCH COIL

Finding Underwater Treasures



Figure 6: The IP68 waterproof search coil in use near water. Remember to keep the control box dry.

4. MAINTENANCE

Proper maintenance ensures the longevity and performance of your metal detector:

- **Cleaning:** After each use, especially in sandy or wet conditions, wipe down the search coil and stem with a damp cloth. Avoid using abrasive cleaners.
- **Battery Care:** Remove batteries if the detector will not be used for an extended period to prevent leakage and damage. Store batteries in a cool, dry place.
- **Storage:** Store the metal detector in a dry, cool environment, away from direct sunlight and extreme temperatures. The included carry bag is ideal for protection during storage and transport.

- **Cable Inspection:** Periodically check the search coil cable for any signs of wear or damage. Ensure connections are secure.

5. TROUBLESHOOTING

If you encounter issues with your metal detector, refer to the following common problems and solutions:

- **No Power:**

- Check if batteries are correctly installed.
- Ensure batteries have sufficient charge. Replace if necessary.
- Verify all cable connections are secure.

- **False Signals/Erratic Behavior:**

- Reduce sensitivity settings. High sensitivity can pick up more ground mineralization or electrical interference.
- Move away from power lines, other electronic devices, or large metal structures.
- Perform a ground balance if available (refer to specific instructions in the full user guide for advanced models, though MD13 is generally automatic).

- **No Detection:**

- Increase sensitivity settings.
- Ensure the search coil is properly connected.
- Verify you are in the correct detection mode (e.g., All Metal mode for general searching).

For persistent issues not covered here, please contact customer support.

6. SPECIFICATIONS

Feature	Specification
Brand	SUNPOW
Model Number	MD13-US
Color	Black
Power Source	Battery Powered (2 x 9V batteries)
Material	Acrylonitrile Butadiene Styrene
Item Weight	1.4 Pounds
Product Dimensions	7" L x 4" W x 14" H
Adjustable Length	Yes
Display Type	LCD
Search Coil Size	8 Inches
Waterproof Rating	IP68 (Search Coil Only)

7. WARRANTY AND SUPPORT

Limited Warranty: SUNPOW products are backed by a limited warranty against defects in materials and workmanship. Please retain your proof of purchase for warranty claims. Specific warranty duration and terms may vary by region. Refer to the product packaging or the official SUNPOW website for detailed warranty information.

Customer Support: For technical assistance, troubleshooting, or warranty inquiries, please contact SUNPOW customer support through the following channels:

- **Online:** Visit the official SUNPOW Store on Amazon:[SUNPOW Store](#)
- **Email:** Refer to the contact information provided in your product packaging.

Please have your model number (MD13-US) and purchase date ready when contacting support.

© 2025 SUNPOW. All rights reserved.

Related Documents - MD13-US


	<p>SUNPOW OT-MD03 Metal Detector User Manual for Adults & Kids</p> <p>Comprehensive user manual for the SUNPOW OT-MD03 Metal Detector. Learn how to use this high-accuracy device, featuring an LCD display, pinpoint function, DISC mode, and a waterproof search coil, for metal detecting adventures.</p>
	




TABLE OF CONTENTS

-01-

FEATURES

- LCD Display** notifies the possible type of metal, the depth of the target, range of DSD, NOTCH, the level of SENS, VOLUME and other conditions. Also, digital display for target ID.
- Backlight** makes the LCD display easier to read in the dark.
- Five Control Buttons** are used for the following functions:
 - POWER button turns on or off the power.
 - “MENU” Press it to select desired operation mode and the setting of the detector.
 - “INCREASE (+)”: Increases the level of sensitivity or volume and the range of DSD and NOTCH.
 - “DECREASE (-)”: Decreases the level of sensitivity or volume and the range of DSD and NOTCH.
 - “PINDPOINT” Reports the location of the target accurately.
- Three Tone Audio Discrimination** provides three distinctive tones to identify the type of metal and the depth of the target.
- Headphone Jack** lets you connect headphones of 3.5mm and 6.3mm.
- 10 Inch Waterproof Search coil** lets you use the detector even in water.
- Adjustable Shaft** lets you adjust the length of shaft for comfortable use.




EASY ASSEMBLY

Assembling your metal detector is easy and requires no special tools. Just follow these steps:

- 1 Press the button on the upper end of the lower stem and slide the search coil to the lower stem. Then using the supplied bolt and lock, attach the search coil to the lower stem.



- 2 Press the button on the upper end of the lower stem and slide the lower stem into the middle stem. Then tighten the lock nut on the middle stem.



- 3 Press the button on the middle stem and slide the middle stem into the S stem. Then tighten the lock nut on the S stem.



- 4 Press the button on the top stem, and slide it to align into the S stem. Adjust the stem to a length that lets you maintain a comfortable upright posture, with your arm relaxed at your side.



- 5 Fix the control box on the S stem and tighten the fixing screw properly.



- 6 Wind the search coil cable around the stem. Insert the cable plug into the jack at the back of the control box.

Caution:
• Do not over-tighten the search coil or use tools to tighten it.
• Do not force the plug in. Excess force will cause damage to the cable.
• To disconnect the cable, pull out the plug. Do not pull on the cable.

-04-

INSTALLING THE BATTERIES

IMPORTANT:
• Always use ALKALINE batteries for optimal performance.
• Always remove the batteries for prolonged storage.
• Do not mix old and new batteries.
• Check the batteries if your detector exhibits any of the following symptoms:

- The unit does not turn on.
- The unit does not beep.
- Unit beeps continuously at low sensitivity setting.

Follow these steps to install the batteries:

- Turn the detector over.
- Open the battery cover.
- Insert the batteries into the battery compartment matching the polarity symbols (+ and -) marked inside.



Warning:
• Dispose of old batteries properly. Never bury or burn them.

USING HEADPHONES

1 Connect the headphones to the headphones with volume control.
2 Insert the headphones 3.5mm plug into the headphone jack at the bottom of the control box. At this time the internal speaker doesn't work.

-05-

LAYOUT OF THE CONTROL PANEL





Thank you for choosing MD-620 metal detector. Please read the owner's manual carefully before operating the metal detector. If you have any questions or problems with the product, please contact us. We will offer you the best service.

-01-

TABLE OF CONTENTS

-02-

FEATURES

With your MD-620 metal detector, you can hunt for coins, jewelry, and other valuables anywhere. The detector comes with high sensitivity and strong ability of discrimination. It is versatile and suitable for all kinds of environments.

- LCD Display:** Shows the probable type of metal, the signal intensity, and the battery level. It also shows the current mode and volume, and battery condition. It also shows numeric display for target depth.
- Three Tone Audio Discrimination:** Sounds three distinctive tones to identify the type of metal detected.
- Notch/gross:** Look metal and finds valuable items by setting the threshold.
- DISC:** Discriminates the unearthened targets by setting the DISC curve. It can identify the metal type and its depth.
- Pinpoint:** Reports the location of the target accurately.
- Search coil:** Detects the presence of metal and provides a slow sweep of the search coil to discriminate different types of metal.
- Headphone Jack:** Connect headphones of 3.5mm and control the volume.
- Waterproof Search:** Reduces the detector noise if you must put it into water.
- Adjustable Shaft:** Adjust the length of shaft for comfortable use.
- Power:** Your metal detector requires two 9-volt alkaline batteries.

-03-

PREPARATION



STEP 1. Your MD-620 detector requires no assembly or tools. Simply unbox the detector from the box.



-04-

STEP 2. Turn the detector 180 degrees as shown in the figure.



STEP 3. Press down the UNLOCK button to release the handle.



-05-

STEP 4. Pull out the armrest to the desired length (typically just under your elbow) and then adjust the handle shaft to the desired angle for your height.



-06-

MATERIALS

Please use two 9V alkaline batteries.
•Open the battery cover and install the battery according to the polarity markings (+ and -).
•Warning! Dispose of old batteries promptly and properly. Never mix old and new batteries.

Caution: Do not mix the old and new batteries or different types of batteries.

•Use only fresh batteries of required size.

•Do not use batteries that are leaking or damaged.

•If the battery indicator on the LCD lights up, replace the battery.

-07-

USING HEADPHONES

•It is recommended to choose the headphones with volume control.

•Insert the headphones 3.5mm plug into the PHONE jack. At this time, the volume is controlled by the headphones.

Listening Safety

•When listening, set the volume to the lowest setting.


•Before you begin listening, adjust the volume to a comfortable level.

•Do not wear headphones while driving a vehicle or operating machinery.

•Do not wear headphones while operating your detector.

•Hearing damage can occur if you listen at high volume for long periods of time.

INSTRUCTIONS FOR CONTROL PANEL



1. POWER SWITCH
Press the power switch to turn on/off the detector.

-07-



2. LCD DISPLAY
The LCD display shows the following information:
•Target numeric indicator
•Low BATT indicator
•DISC numeric indicator
•Depth numeric indicator
•Volume numeric indicator
•Metal numeric indicator
•Metal color indicator
•Metal content indicator

3. CONTROL BUTTONS

•MINI: Press MINI to select VOL/LINE, DISC, DISC-NOTCH.

•VOLUME: Press VOLUME to select VOLUME. Then press twice to adjust the level. (0-4) of VOLUME. The level will be displayed on the LCD.

•DISC: Press DISC to select DISC. Then press twice to adjust the level (0-5) of sensitivity. The level will be displayed on the LCD.

•NOTCH: Press NOTCH to select NOTCH. Then press twice to adjust the level (0-5) of sensitivity. The level will be displayed on the LCD.

•MOTOR: Eliminates the target you don't want. Press MENU to select NOTCH. Then press twice to select the target to be removed. The target name mode is current and the target will disappear.

-08-

4. BACKLIGHT SWITCH
Press the back light switch to turn on/off the backlight of the LCD.

5. MEMORY
The detector will memorize all the settings before power is off.

TARGET IDENTIFICATION

1. Number of targets:

-ON	00-10
-10A	11-20
-20A	21-30
-10B	31-40
-20B	41-50

Note: There are a wide variety of metals and no target can be identified with 100% certainty until under test. The table is for general reference only.

SUNPOW Foldable Metal Detector User Manual

This document provides instructions and specifications for the SUNPOW Foldable Metal Detector for Adults, a professional, waterproof, and adjustable metal detector with an LCD display, 11-inch search coil, and 5 modes.



[SUNPOW OT-MD02 Metal Detector User Manual](#)

Comprehensive user manual for the SUNPOW OT-MD02 metal detector, detailing its features, operation, specifications, and troubleshooting tips for hobbyists and enthusiasts.



[SUNPOW HP1172 Electric Pressure Washer User Manual](#)

This user manual provides comprehensive instructions for the SUNPOW HP1172 Electric Pressure Washer, detailing safety precautions, product features, assembly, operation, maintenance, and troubleshooting for optimal use.

English
SUNPOW

Thank you for choosing the SUNPOW SP-JS01 16000mAh Lithium Jump Starter. Read this manual carefully before using the product. Please keep the manual for future reference. If you have any questions, please contact us. Email: SUNPOW.Services@hotmail.com

[SUNPOW SP-JS01 16000mAh Lithium Jump Starter User Manual](#)

User guide for the SUNPOW SP-JS01 16000mAh Lithium Jump Starter, covering safety warnings, technical specifications, product description, what's in the box, LED indicators, charging instructions, jump starting procedures, and troubleshooting.