

B0F8NFZCBD

Generic 6.5L 1350W Digital Air Fryer User Manual

Model: B0F8NFZCBD

INTRODUCTION

Thank you for purchasing the Generic 6.5L 1350W Digital Air Fryer. This appliance is designed to provide a healthier and more convenient way to cook your favorite meals, utilizing rapid hot air circulation for thorough and even cooking with minimal oil. Please read this manual carefully before use to ensure safe and optimal operation.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

PRODUCT OVERVIEW

The Generic 6.5L Air Fryer features a large capacity and 1350W power for efficient cooking. It incorporates a stirring function to ensure food is evenly cooked and a digital touch display for easy control. The design includes a transparent

visible window to monitor cooking progress without opening the unit.



Figure 1: Front view of the Generic 6.5L Air Fryer.

Key Features:

- **Healthy Frying:** 1350W power with rapid hot air circulation for cooking with little to no added oil, reducing fat content significantly.
- **Multifunctionality:** Capable of frying, grilling, roasting, steaming, and baking.
- **Large Capacity:** 6.5L ultra-large capacity, suitable for family meals.
- **Stirring Function:** Automatic stirring ensures even cooking.
- **Digital Touch Control:** Easy-to-use digital display with preset cooking modes, independent temperature control, and intuitive timers.
- **Easy to Clean:** Non-stick basket design for hassle-free cleaning.

01

Transparent visible window



02

Fine hole filter holder

03

One-button opening



Figure 2: Key components including the transparent visible window, fine hole filter holder, and one-button opening mechanism.

SETUP AND FIRST USE

- Unpacking:** Carefully remove the air fryer and all accessories from the packaging. Retain packaging for future storage or transport.

- Initial Cleaning:** Before first use, wipe the exterior of the appliance with a damp cloth. Wash the frying basket and any removable accessories with warm, soapy water. Rinse thoroughly and dry completely.
- Placement:** Place the air fryer on a stable, level, heat-resistant surface, away from walls and other appliances to allow for proper air circulation. Ensure there is at least 10 cm (4 inches) of free space on the back and sides, and 10 cm (4 inches) above the appliance.
- Power Connection:** Ensure the voltage indicated on the appliance matches your local power supply before plugging in. Plug the power cord into a grounded wall outlet.
- Pre-heating (Optional):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) to eliminate any manufacturing odors. Ensure the room is well-ventilated during this process.

OPERATING INSTRUCTIONS

Digital Touch Display:

The air fryer features an intuitive digital touch display for easy control of cooking settings. The display allows you to select preset programs, adjust temperature, and set cooking time.



 French fries	 Chicken leg	 Sea shrimp
200°C (3-5min)	200°C (8-13min)	180°C (8min)
 Cake	 Steak	 Fish
160°C (18-22min)	180°C (8-12min)	180°C (8-12min)
 Meat		

Figure 3: Digital touch display with various preset cooking options and manual controls.

The display shows recommended cooking times and temperatures for common foods such as French fries, chicken legs, sea shrimp, cake, steak, fish, and meat. These are general guidelines and may need adjustment based on food quantity and desired crispness.

Basic Operation:

- 1. Prepare Food:** Place your ingredients into the frying basket. Do not overfill the basket to ensure even cooking.
- 2. Insert Basket:** Slide the frying basket firmly back into the air fryer until it clicks into place.

3. **Power On:** Plug the air fryer into a grounded electrical outlet. The display will illuminate.

4. **Select Cooking Mode:**

- **Preset Programs:** Touch the desired food icon on the digital display to select a preset cooking program. The air fryer will automatically set the recommended time and temperature.
- **Manual Setting:** Alternatively, use the temperature and time adjustment buttons to set your desired cooking temperature and time manually.

5. **Start Cooking:** Press the Start/Pause button to begin the cooking process.

6. **Stirring Function:** This air fryer features an automatic stirring function. To activate or deactivate, press the dedicated stir button on the control panel. This ensures food is evenly cooked without manual shaking.

Automatically stir by pressing the stir button



Figure 4: The automatic stirring function ensures even cooking.

6. **Monitoring:** The transparent window allows you to monitor cooking progress without interrupting the process.

7. **Completion:** The air fryer will beep when the cooking time is complete. Carefully remove the basket using the handle.

8. **Serve:** Transfer the cooked food to a serving dish. Be cautious of hot oil or food.

CARE AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your air fryer and ensure optimal performance.

- 1. Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
- 2. Cleaning the Basket and Accessories:** The frying basket and any removable accessories are non-stick. Wash them with warm, soapy water using a non-abrasive sponge. For stubborn food residue, soak them in warm water for a few minutes before cleaning. Rinse thoroughly and dry completely.
- 3. Cleaning the Interior:** Wipe the interior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads.
- 4. Cleaning the Exterior:** Wipe the exterior of the appliance with a soft, damp cloth. Do not immerse the main unit in water or any other liquid.
- 5. Storage:** Ensure all parts are clean and dry before storing the air fryer. Store it in a cool, dry place.

Easy to clean



Figure 5: The non-stick basket is designed for easy cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Power outlet is not working. Basket is not inserted correctly.	Plug the power cord into a grounded wall outlet. Check if the power outlet is working by plugging in another appliance. Push the frying basket firmly into the appliance until it clicks.
Food is not cooked evenly.	Basket is overfilled. Stirring function is not activated.	Reduce the amount of food in the basket. Ensure the stirring function is active for even cooking. Manually shake the basket halfway through cooking if needed.
White smoke comes from the appliance.	Fat residues from previous use. Too much oil used.	Clean the basket and interior thoroughly after each use. Use less oil for cooking.
Food is not crispy.	Not enough oil used (for certain foods). Temperature too low or cooking time too short.	Lightly brush or spray food with oil for crispier results. Increase temperature or cooking time.

SPECIFICATIONS

Model:	B0F8NFZCBD
Brand:	Generic
Rated Power:	1350W
Rated Voltage/Frequency:	110-240V~50Hz
Capacity:	6.5 Liters
Product Dimensions (L x W x H):	320mm x 385mm x 320mm (approx. 12.6" x 15.2" x 12.6")
Net Weight:	5.7 kg (approx. 12.5 lbs)
Control Type:	Digital Touch Display
Food Contact Material:	Cold rolled plate sprayed food grade Teflon



Figure 6: Approximate dimensions of the air fryer and its basket.

WARRANTY AND SUPPORT

This product comes with a **3-month warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accident, alteration, neglect, or unauthorized repair.

For warranty claims, technical support, or any questions regarding your Generic 6.5L Air Fryer, please contact your retailer or the manufacturer's customer service. Please have your model number (B0F8NFZCBD) and proof of purchase ready.

We are committed to providing high-quality products and customer satisfaction.

Generic 6.5L 1350W Digital Air Fryer User Manual | Model: B0F8NFZCBD

© 2026 All rights reserved.