

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Acer](#) /
- › [Acer Aspire Go 15 Laptop User Manual \(Model: B0F8VG23XV\)](#)

Acer Aspire Go 15

Acer Aspire Go 15 Laptop User Manual

Model: Aspire Go 15 (B0F8VG23XV)

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Acer Aspire Go 15 laptop. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your device.



Image: The Acer Aspire Go 15 laptop, showcasing its display and keyboard.

SETUP

1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that all items are present:

- Acer Aspire Go 15 Laptop
- Power Adapter
- USB LED Light
- 7-in-1 USB Type C Hub



Image: The included USB LED Light and 7-in-1 USB Type C Hub.

2. Connecting Power

1. Connect the power adapter to the laptop's power input port.
2. Plug the power cord into a wall outlet.
3. Allow the laptop to charge for at least 30 minutes before initial use, or until the battery indicator shows sufficient charge.

3. First Boot and Windows 11 Setup

1. Press the power button to turn on the laptop.
2. Follow the on-screen instructions to complete the Windows 11 Home setup process. This includes selecting your region, language, connecting to a Wi-Fi network, and creating a user account.

4. Connecting Accessories

The included USB LED Light and 7-in-1 USB Type C Hub can be connected to the available USB ports on your laptop. The USB Type C Hub expands connectivity options, providing additional ports for HDMI, TF/SD Cards, USB 3.0, PD 100W, and RJ45 Ethernet.

OPERATING INSTRUCTIONS

1. Power On/Off

- **To Power On:** Press the power button located on the keyboard.
- **To Shut Down:** Click the Start button, then Power > Shut down.
- **To Restart:** Click the Start button, then Power > Restart.
- **To Sleep:** Close the laptop lid or click the Start button, then Power > Sleep.

2. Using the Keyboard and Touchpad

The laptop features a full-sized keyboard and a precision touchpad for navigation. Refer to the image below for the keyboard layout.



Image: Top-down view of the Acer Aspire Go 15 keyboard and touchpad.

- **Function Keys (Fn):** Press the 'Fn' key in combination with the F1-F12 keys to access special functions like volume control, screen brightness, and Wi-Fi toggle.
- **Touchpad Gestures:** The touchpad supports multi-touch gestures for scrolling, zooming, and switching applications. Consult Windows 11 settings for customization.

3. Connectivity (Wi-Fi and Bluetooth)

- **Wi-Fi:** Click the network icon in the taskbar, select your desired Wi-Fi network, enter the password, and click Connect.
- **Bluetooth:** Go to Settings > Bluetooth & devices to pair Bluetooth accessories such as headphones or mice.

4. External Ports

The Acer Aspire Go 15 is equipped with various ports for connecting external devices.



Image: Left side ports including Headset jack, USB 3.2, and Kensington lock slot.



Image: Right side ports including USB Type-C (full function), HDMI, and USB 3.2.

- **USB-A 3.2 Ports (x2):** For connecting standard USB devices like mice, keyboards, and external drives.
- **USB-C 3.2 Ports (x2):** Versatile ports for data transfer, power delivery (with compatible chargers), and display output (with compatible adapters).
- **HDMI Port (x1):** Connects to external displays or projectors.
- **Headset Jack:** For connecting headphones or a headset with a microphone.
- **Kensington Lock Slot:** For securing your laptop with a compatible security cable.

MAINTENANCE

1. Cleaning the Laptop

- **Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner. Do not spray liquid directly onto the screen.
- **Keyboard and Chassis:** Use a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap solution can be used, ensuring no liquid enters openings.
- **Vents:** Use compressed air to clear dust from the ventilation grilles to prevent overheating.

2. Battery Care

- Avoid extreme temperatures.
- Do not fully discharge the battery frequently.
- If storing the laptop for an extended period, ensure the battery is charged to approximately 50-70%.

3. Software Updates

Regularly check for and install Windows updates and driver updates from Acer's official website to ensure optimal performance and security.

TROUBLESHOOTING

Common Issues and Solutions

• Laptop Not Powering On:

- Ensure the power adapter is securely connected to both the laptop and a working power outlet.
- Check if the power adapter's indicator light is on.
- Try a different power outlet.

• Display Issues (No image, flickering):

- Adjust screen brightness using the function keys.
- If an external monitor is connected, ensure the correct display output mode is selected (Fn + F5 or similar).
- Restart the laptop.

• Wi-Fi/Bluetooth Connectivity Problems:

- Ensure Wi-Fi/Bluetooth is enabled in Windows settings.
- Restart your router/modem for Wi-Fi issues.
- Forget and reconnect to the network/device.
- Update network adapter drivers.

• Slow Performance:

- Close unnecessary applications.
- Check for and remove malware.
- Ensure sufficient free space on the SSD.
- Update Windows and drivers.

SPECIFICATIONS

Feature	Detail
Model Name	Aspire Go 15
Processor	Intel Core i5-1334U (1.3 GHz, up to 4.60 GHz, 10-core)
Display	15.3-inch WUXGA (1920 x 1200) IPS, 16:10 aspect ratio
RAM	8GB DDR5
Storage	1TB PCIe NVMe SSD
Graphics	Intel UHD Graphics (Integrated)
Operating System	Windows 11 Home
Wireless Connectivity	Wi-Fi (802.11a/b/g/n), Bluetooth
Ports	2 x USB-A 3.2, 2 x USB-C 3.2, 1 x HDMI, 1 x Headset Jack
Color	Steel Gray
Dimensions (WxLxH)	2.56 x 12.2 x 19.6 inches

Feature	Detail
Weight	3.7 pounds
Special Features	Webcam, Wifi

WARRANTY INFORMATION

Your Acer Aspire Go 15 laptop is covered by a manufacturer's limited warranty. The specific terms and duration of the warranty may vary by region and purchase date. Please refer to the warranty card included with your product or visit the official Acer support website for detailed information regarding warranty coverage, terms, and conditions.

SUPPORT

For further assistance, technical support, or to download the latest drivers and manuals, please visit the official Acer support website:

Acer Support Website: <https://www.acer.com/support>

When contacting support, please have your laptop's serial number and model name (Aspire Go 15, B0F8VG23XV) readily available.