

FRIC-PL-APP-TP-22052025-028385

Kenmore 11069722800 Dryer Door Switch Replacement Part User Manual

Model: FRIC-PL-APP-TP-22052025-028385

INTRODUCTION

This manual provides instructions for the installation, operation, maintenance, and troubleshooting of the Generic replacement dryer door switch, compatible with Kenmore model 11069722800. This component is crucial for the safe and proper functioning of your dryer by ensuring the door is closed before operation.

Before proceeding with any installation or repair, please read all instructions carefully and ensure you have the correct replacement part for your appliance.

SAFETY INFORMATION

- **Always disconnect power** to the dryer before attempting any repairs or installations. Failure to do so can result in serious injury or electrical shock.
- Wear appropriate personal protective equipment, such as gloves, to prevent injury.
- If you are unsure about any step, consult a qualified appliance repair technician.
- Keep children and pets away from the work area.

SETUP AND INSTALLATION

The dryer door switch is a safety mechanism that prevents the dryer from operating when the door is open. Replacing it typically involves accessing the front panel or top of the dryer.

1. **Disconnect Power:** Unplug the dryer from the electrical outlet or turn off the circuit breaker supplying power to the dryer.
2. **Access the Switch:** Depending on your dryer model, you may need to remove the top panel, front panel, or kick plate to access the door switch. Refer to your specific dryer's service manual for exact access procedures.
3. **Locate the Old Switch:** The door switch is usually located near the dryer door opening, often mounted to the front bulkhead or cabinet.
4. **Disconnect Wires:** Carefully disconnect the electrical wires from the old door switch. Note their positions or take a photo for reassembly.
5. **Remove Old Switch:** Unmount the old switch. This may involve unscrewing it or releasing retaining clips.
6. **Install New Switch:** Mount the new Generic replacement door switch in the same location and orientation as the old one.
7. **Connect Wires:** Reconnect the electrical wires to the new switch, ensuring they are securely attached.
8. **Reassemble Dryer:** Reattach any panels or components that were removed to access the switch.
9. **Restore Power:** Plug the dryer back into the electrical outlet or turn on the circuit breaker.

10. **Test Operation:** Close the dryer door and attempt to start a cycle. The dryer should operate normally. If it does not, refer to the troubleshooting section.



Image 1: The Generic replacement dryer door switch. This white plastic component features a black lever and a white wire harness terminating in a three-pin connector, designed for compatibility with Kenmore 11069722800 dryers.

OPERATING PRINCIPLES

The dryer door switch functions as a critical safety interlock. When the dryer door is closed, the switch is activated, completing an electrical circuit that allows the dryer to start and operate. If the door is open, the switch circuit is interrupted, preventing the dryer from starting or immediately stopping it if it is already running. This mechanism is designed to prevent accidents and ensure user safety during dryer operation.

MAINTENANCE

The dryer door switch is a sealed component and does not require routine maintenance. However, it is advisable to:

- Periodically inspect the dryer door and its latch mechanism to ensure proper alignment and closure.
- Keep the area around the dryer door clean and free of lint buildup, which could potentially interfere with the switch's operation.
- If the switch appears physically damaged or worn, consider replacement to maintain safety and functionality.

TROUBLESHOOTING

If your dryer is experiencing issues related to the door switch, consider the following:

- **Dryer Not Starting:** Ensure the dryer door is fully closed and latched. A faulty door switch is a common reason for a dryer not starting even when the door appears closed.
- **Dryer Stops Mid-Cycle:** If the dryer stops unexpectedly, check if the door has accidentally opened or if the door switch is intermittently failing.
- **No Tumbling Action:** The door switch must be engaged for the motor to operate. If the motor hums but the drum doesn't tumble, and the door is closed, the switch might be defective.
- **Visual Inspection:** With the power disconnected, visually inspect the switch for any signs of damage, such as a broken lever or loose wiring.

- **Continuity Test (Advanced):** A multimeter can be used to test the continuity of the switch. With the door open, there should be no continuity. With the door closed (or switch depressed), there should be continuity. If the switch fails this test, it needs replacement.

If troubleshooting steps do not resolve the issue, it is recommended to consult a qualified appliance repair technician.

SPECIFICATIONS

| | |
|-----------------------|--------------------------------|
| Part Number | FRIC-PL-APP-TP-22052025-028385 |
| ASIN | B0F9TSCP7Q |
| Manufacturer | Fricparts |
| Compatible Model | Kenmore 11069722800 |
| Item Package Quantity | 1 |
| Number Of Pieces | 1 |
| Color | Black/White |

WARRANTY INFORMATION

Specific warranty details for this replacement part are typically provided by the seller or manufacturer at the time of purchase. Please refer to your purchase documentation or contact the seller directly for information regarding warranty coverage, terms, and conditions.

SUPPORT

For further assistance, technical support, or if you encounter issues not covered in this manual, please contact the retailer or manufacturer from whom you purchased this product. Always provide your product's model number and purchase details when seeking support.