Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > DEKALA /
- > DEKALA 10.1-inch Digital Alarm Clock with Bed Shaker (Model DC01) User Manual

DEKALA DC01

DEKALA 10.1-inch Digital Alarm Clock with Bed Shaker (Model DC01) - User Manual

INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your DEKALA 10.1-inch Digital Alarm Clock with Bed Shaker, Model DC01. Please read this manual thoroughly before using the product to ensure proper function and longevity.

PRODUCT OVERVIEW

The DEKALA DC01 is a versatile digital alarm clock designed with a large 10.1-inch HD display, suitable for various users, including seniors and heavy sleepers. It integrates time, date, day of week, weather, temperature, and humidity display, along with advanced alarm and reminder functionalities.

Key Features:

- 10.1-inch HD Display with Extra-Large Font
- Integrated Digital Planner for Schedules, Tasks, and Reminders
- · Real-time Weather Updates with Built-in Sensors
- Multiple Alarm Settings (over 30 options)
- Medication Reminder Function
- · Vibration Alarm (Bed Shaker)
- IPS HD Touch Screen for Intuitive Operation
- Automatic Dimming (Day/Night Mode)
- Wi-Fi Synchronization for Time and Weather
- · Flexible Installation: Desktop or Wall-Mounted

Package Contents:

- DEKALA 10.1-inch Digital Alarm Clock (Model DC01)
- · Bed Shaker Unit
- Power Adapter
- User Manual (this document)



Image: The DEKALA DC01 Digital Alarm Clock with its bed shaker unit. The screen displays time, date, weather, and a list of reminders.

SETUP

Follow these steps to set up your DEKALA Digital Alarm Clock:

- 1. Unpacking: Carefully remove all components from the packaging.
- 2. **Power Connection:** Connect the power adapter to the clock and plug it into a standard electrical outlet. The device will power on automatically.
- 3. Initial Configuration (3-Minute Setup):
 - Language Selection: Select your preferred language.
 - **Time Zone and Location:** Enter your region to enable accurate time synchronization and weather updates via Wi-Fi.
 - **Wi-Fi Connection:** Connect the device to your 2.4 GHz Wi-Fi network. This is essential for time synchronization and weather data.
- 4. Bed Shaker Placement: Place the bed shaker unit under your pillow or mattress for effective vibration alarms.



Image: The clock's Wi-Fi connection interface and its display of time and weather on a table.

OPERATING INSTRUCTIONS

The DEKALA DC01 features an intuitive touch screen interface for easy navigation and setting adjustments.

1. Time and Date Display:

- The main screen displays the current time, date, and day of the week.
- Time is automatically synchronized via Wi-Fi once connected.
- You can customize the display format (e.g., 12-hour/24-hour, date format) in the settings menu.

2. Weather Information:

- The clock displays real-time weather conditions, temperature, and humidity for your configured location.
- Weather data is updated via Wi-Fi.
- Internal sensors monitor ambient temperature and humidity.

3. Alarm Settings:

The device supports over 30 alarm settings, including standard alarms and specialized reminders.

1. Accessing Alarm Settings: Tap the "Alarm" icon or navigate to the alarm section from the main menu.

2. Adding a New Alarm:

- Tap the "+" icon to add a new alarm.
- Set the desired time and repetition (e.g., daily, weekdays, specific days).
- Choose an alarm type: audible, vibration (bed shaker), or both.
- Select an alarm sound (if audible).
- Add a custom label for the alarm (e.g., "Wake Up," "Medication").

3. Editing/Deleting Alarms: Select an existing alarm to modify its settings or delete it.



Image: The clock displaying a "Medication Time" reminder, with the bed shaker unit visible.

4. Reminder Function (Digital Planner):

The integrated digital planner allows you to manage schedules and tasks.

- **Creating Reminders:** Similar to alarms, you can set specific reminders for daily activities like medication, meals, exercise, or appointments.
- Customization: Each reminder can have a custom message and an associated alarm type (audible/vibration).
- **Display Modes:** The clock offers 36 display modes, allowing you to choose how your schedule and reminders are presented.



Image: The clock illustrating various reminder categories such as medication, hydration, safety checks, and appointments.

5. Display Customization:

- Font and Color: Adjust font styles and colors for improved readability.
- Automatic Dimming: The clock automatically adjusts screen brightness based on ambient light conditions (Day/Night Mode) to prevent eye strain and ensure comfortable viewing. This feature can be manually adjusted in settings.



Image: A user interacting with the touch screen to customize the display, showing different font and color options.



Image: The clock on a bedside table, illustrating its automatic dimming feature for day and night modes.

6. Installation Options:

The DEKALA DC01 can be placed on a desktop or mounted on a wall.

- **Desktop Placement:** Use the integrated stand to place the clock on any flat surface.
- **Wall Mounting:** The device supports wall mounting for flexible placement. (Mounting hardware not included, refer to product packaging for details).



Image: The clock shown in both wall-mounted and desktop configurations, demonstrating flexible installation.

MAINTENANCE

To ensure the longevity and optimal performance of your DEKALA Digital Alarm Clock, follow these maintenance guidelines:

- Cleaning: Use a soft, dry cloth to clean the screen and exterior. Avoid abrasive cleaners or solvents.
- Power: Ensure the device is connected to a stable power source.
- **Software Updates:** Periodically check for software updates through the device settings or companion application (if available) to ensure the latest features and bug fixes.
- Environment: Keep the device in a dry environment, away from direct sunlight, extreme temperatures, and high humidity.

Troubleshooting

If you encounter issues with your DEKALA Digital Alarm Clock, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Clock not powering on.	No power supply or faulty adapter.	Ensure the power adapter is securely connected to the clock and a working electrical outlet. Try a different outlet.
Incorrect time or date.	No Wi-Fi connection or incorrect time zone setting.	Verify Wi-Fi connectivity in settings. Check and correct the time zone. Ensure the device is connected to a 2.4 GHz network.

Problem	Possible Cause	Solution
Weather information not updating.	No Wi-Fi connection or location not set.	Confirm Wi-Fi connection. Ensure your location is correctly set in the device settings.
Alarms not sounding/vibrating.	Alarm volume too low, alarm disabled, or bed shaker not connected/functional.	Check alarm settings to ensure it is enabled and the volume is adequate. Verify the bed shaker is properly connected and selected as an alarm output.
Screen too bright/dim.	Automatic dimming settings or manual brightness adjustment.	Adjust the brightness settings in the menu. If automatic dimming is enabled, ensure it is functioning correctly or disable it for manual control.
Touch screen unresponsive.	Temporary software glitch or screen obstruction.	Restart the device by unplugging and replugging the power. Ensure the screen is clean and free from debris.

SPECIFICATIONS

Brand	DEKALA
Model Number	DC01
Display Size	10.1 inches
Display Type	Digital, IPS HD Touch Screen
Material	Glass, Plastic
Color	Black
Product Dimensions	Approx. 30 cm (Width) x 25 cm (Height)
Product Weight	Approx. 500 grams
Power Source	Battery Powered (Lithium Metal, internal)
Special Features	Calendar Display, Reminder Function, Large Display, Automatic Dimming, Bed Shaker, Wi-Fi Connectivity, Weather Display, Touch Operation
Room Type	Office, Bedroom, Living Room, Senior Facilities
Indoor/Outdoor Use	Indoor

WARRANTY AND SUPPORT

DEKALA provides a **1-year product warranty** from the date of purchase.

For any questions, technical assistance, or warranty claims, please contact DEKALA customer service. Our support team is available **24 hours a day, 365 days a year**.

You can reach us via the Amazon messaging system for prompt assistance.



Image: The clock shown in different household environments, highlighting its versatility for all family members.

Related Documents - DC01



