

## TRIGKEY Key i13 13900HK

# TRIGKEY Key i13 Mini PC User Manual

Model: Key i13 13900HK

## 1. PRODUCT OVERVIEW

---

The TRIGKEY Key i13 Mini PC is a compact and powerful computing solution designed for various applications, from gaming and content creation to business and educational use. It features a 13th Gen Intel Core i9-13900HK processor, high-speed DDR5 RAM, and PCIe 4.0 SSD storage, offering robust performance in a small form factor.



Figure 1: The TRIGKEY Key i13 Mini PC, showcasing its compact design and various ports on the front and rear.

## Key Features:

- **Processor:** 13th Gen Intel Core i9-13900HK (14 Cores/20 Threads, up to 5.4 GHz)
- **Memory:** 32GB DDR5 RAM (expandable)
- **Storage:** 1TB PCIe 4.0 SSD (expandable with dual M.2 2280 slots)
- **Graphics:** Intel Iris Xe Graphics (96EU)
- **Display Output:** Triple display support via HDMI (4K 60Hz), DisplayPort 1.4 (4K 144Hz), and Thunderbolt 4 (40Gbps/DP1.4)
- **Connectivity:** WiFi 6 (Intel AX200), Bluetooth 5.2, 2.5G LAN
- **Ports:** Thunderbolt 4, USB-C 3.2, USB-A 3.2, DP1.4, HDMI, 2.5G LAN, 3.5mm audio jacks




Figure 2: An illustration of the Intel Core i9-13900HK processor, emphasizing its core count, threads, and turbo frequency.

## 2. SETUP GUIDE

### 2.1 What's in the Box

Before proceeding with the setup, please ensure all components are present:

- 1 x TRIGKEY Key i13 Mini PC
- 1 x HDMI Cable (100CM)
- 1 x User Manual
- 1 x Power Adapter (19V/5.26A)

### 2.2 Connecting Your Mini PC

Follow these steps to connect your TRIGKEY Key i13 Mini PC:

1. **Connect Display:** Use the provided HDMI cable or a DisplayPort/Thunderbolt cable to connect your monitor(s) to the corresponding ports on the mini PC. The device supports up to three independent displays.
2. **Connect Peripherals:** Plug in your USB keyboard, mouse, and any other USB devices into the available USB-A or USB-C ports.
3. **Connect Network:** For a wired connection, connect an Ethernet cable from your router or modem to the 2.5G LAN port on the mini PC. For wireless, ensure the WiFi antennas are properly positioned (if external) or that the internal antenna has clear signal access.
4. **Connect Power:** Insert the power adapter into the DC IN port on the mini PC, then plug the adapter into a power outlet.

# Dual-Channel DDR5 5200MHz

Supports up to 96GB (2x48GB) DDR5 5200MHz RAM

**Optional: 32GB (2x16GB)**



Figure 3: A diagram illustrating the various ports on the TRIGKEY Key i13 Mini PC, including Thunderbolt 4, USB-C, USB-A, DP1.4, HDMI, LAN, and audio jacks.

## 2.3 Initial Power On

After connecting all necessary cables, press the power button located on the front of the mini PC. The system will boot up,

and you should see the operating system loading on your connected display.

## 3. OPERATING INSTRUCTIONS

---

### 3.1 Power Management

- **Power On:** Press the power button once.
- **Shut Down:** Access the operating system's power options to perform a proper shutdown.
- **Restart:** Access the operating system's power options to restart the system.
- **Sleep Mode:** Access the operating system's power options to put the system into sleep mode.

### 3.2 Display Configuration

The TRIGKEY Key i13 supports up to three independent displays. To configure multiple displays:

1. Connect your monitors to the HDMI, DisplayPort, and Thunderbolt 4 ports.
2. Once connected, the operating system (e.g., Windows) should automatically detect the displays.
3. Navigate to your display settings (e.g., right-click on desktop > Display settings) to arrange, extend, or duplicate your displays as needed.

### 3.3 Network and Wireless Connectivity

The mini PC offers advanced connectivity options:

- **Wired Network (2.5G LAN):** For optimal speed and stability, use the 2.5G Ethernet port. Ensure your router and network infrastructure support 2.5G speeds for full performance.
- **Wireless Network (WiFi 6):** The integrated WiFi 6 (Intel AX200) module provides high-speed wireless connectivity. To connect, open your operating system's network settings, select your desired WiFi network, and enter the password.
- **Bluetooth (BT 5.2):** Use Bluetooth 5.2 to connect wireless peripherals such as keyboards, mice, headphones, or speakers. Access your operating system's Bluetooth settings to pair devices.

# Large-capacity storage expansion with dual M.2 PCIe4.0 slots

Equipped with two M.2 2280 PCIe 4.0 x4 slots, each supporting up to 4TB – for a total of 8TB storage!

Optional: 1TB (single module)



Figure 4: An overview of the mini PC's connectivity options, including WiFi 6, Bluetooth 5.2, and 2.5G LAN.

## 3.4 Storage and Memory Expansion

The TRIGKEY Key i13 Mini PC is designed for easy upgrades:

- **RAM:** The device comes with 32GB DDR5 RAM (2x16GB) and supports up to 96GB (2x48GB) DDR5 5200MHz SO-DIMM memory. To upgrade, carefully open the chassis and replace the existing SO-DIMM modules.
- **SSD:** It includes a 1TB PCIe 4.0 SSD. The mini PC features dual M.2 2280 PCIe 4.0 slots, each supporting up to 4TB, for a total of 8TB storage. To add or upgrade SSDs, open the chassis and install M.2 2280 NVMe SSDs into the available slots.



# Ideal for Content Creators



## WiFi 6

Seamless Signal Reception with speeds of up to 2.4 Gbps, enjoy congestion-free, low-latency connectivity that's faster and more stable.



## Dual Audio Jacks

Front and rear audio jacks help maintain neat cable management. When both jacks are in use, the front jack takes priority for audio output, while the rear jack is automatically disabled.



## 2.5Gbps Ethernet Port

The network port supports speeds of up to 2.5Gbps—2.5 times as fast as traditional 1.0Gbps Ethernet.



## 4K 144Hz Display Support

Supports up to 4K resolution at 144Hz refresh rate, delivering smoother performance for media content creation.

Figure 5: An internal view of the mini PC, displaying the dual DDR5 SO-DIMM slots for memory installation.

# Technical Assurance

## Thunderbolt 4 Port

**40Gbps**

High-speed data transfer

**DP1.4**

Display connectivity



Figure 6: An internal view of the mini PC, illustrating the dual M.2 2280 PCIe 4.0 slots for storage expansion.

## 4. MAINTENANCE

### 4.1 Cleaning

To ensure optimal performance and longevity, regularly clean your mini PC:

- Use a soft, dry cloth to wipe the exterior of the device.
- For dust accumulation in vents, use compressed air. Ensure the device is powered off and unplugged before cleaning.
- Avoid using liquid cleaners directly on the device.

### 4.2 Software Updates

Keep your operating system and drivers updated to ensure system stability, security, and performance. Regularly check for updates through your operating system's settings.



### 4.3 Cooling System

The TRIGKEY Key i13 features a dual-fan cooling system to manage internal temperatures. Ensure the vents are not obstructed to allow for proper airflow. If you notice excessive fan noise or overheating, ensure the device is in a well-ventilated area.



Figure 7: A diagram demonstrating the airflow and cooling mechanism within the TRIGKEY Key i13 Mini PC, highlighting the system fan and SSD heatsink.

## 5. TROUBLESHOOTING

This section addresses common issues you might encounter with your TRIGKEY Key i13 Mini PC.

### 5.1 No Power

- Ensure the power adapter is securely connected to both the mini PC and a working power outlet.
- Verify the power outlet is functional by plugging in another device.

- Check the power adapter for any visible damage.

### 5.2 No Display Output

- Confirm that the display cable (HDMI, DP, Thunderbolt) is securely connected to both the mini PC and the monitor.
- Ensure the monitor is powered on and set to the correct input source.
- Try connecting to a different display or using a different cable to rule out display or cable issues.

### 5.3 Network Connectivity Issues

- **Wired:** Check if the Ethernet cable is properly connected. Verify your router/modem is working correctly.
- **Wireless:** Ensure WiFi is enabled in your operating system settings. Confirm you are connected to the correct network and have entered the password accurately. Restart your router/modem if necessary.
- Update network drivers if issues persist.

### 5.4 System Performance Issues

- Close unnecessary applications running in the background.
- Check for and install any pending operating system or driver updates.
- Ensure the mini PC has adequate ventilation and is not overheating.
- Run a system diagnostic or antivirus scan to check for software conflicts or malware.

If you encounter issues not covered here or require further assistance, please contact TRIGKEY customer support.

## 6. SPECIFICATIONS

Feature	Specification
Processor	Intel Core i9-13900HK (14C/20T, up to 5.4 GHz)
RAM	32GB DDR5 5200MHz (2x16GB), Max 96GB
Storage	1TB PCIe 4.0 SSD (Dual M.2 2280 slots, Max 8TB)
Graphics	Intel Iris Xe Graphics (96EU)
Max Screen Resolution	3840x2160 (4K)
Operating System	OS (Pre-installed, typically Windows 11 Pro)
Wireless Connectivity	WiFi 6 (Intel AX200), Bluetooth 5.2
Wired Network	2.5G LAN
Ports	1x Thunderbolt 4 (40Gbps/DP1.4), 1x USB-C 3.2 (10Gbps), 3x USB-A 3.2 (10Gbps), 1x DP1.4 (4K 144Hz), 1x HDMI (4K 60Hz), 1x 2.5G LAN, 2x 3.5mm audio jack, 1x DC IN
Item Weight	2.38 pounds

Feature	Specification
Package Dimensions	5.67 x 5.51 x 4.29 inches
Design Type	Mini PC

## 7. WARRANTY AND SUPPORT

### 7.1 Warranty Information

The TRIGKEY Key i13 Mini PC comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and hardware malfunctions under normal use conditions. Please retain your proof of purchase for warranty claims.

### 7.2 Customer Support

TRIGKEY is committed to providing excellent customer service. For any technical assistance, troubleshooting, or warranty inquiries, please utilize the following support options:



- **Online Support:** Visit the official TRIGKEY store on Amazon for FAQs and product information:[TRIGKEY Amazon Store](#)
- **Technical Support:** We offer 24/7 one-to-one customer service and lifelong technical support. Refer to the contact information provided with your product packaging or on the official TRIGKEY website for direct support channels.



#### Related Documents - Key i13 13900HK

--	--

	<p><a href="#">TRIGKEY Green G5 Mini PC User Manual</a></p> <p>User manual for the TRIGKEY Green G5 Mini PC featuring Intel 12th Gen Alder Lake-N100 CPU, 16GB DDR5 RAM, 500GB NVMe SSD, Dual 2.5G LAN, Wi-Fi 6, and Bluetooth 5.2.</p>
	<p><a href="#">TRIGKEY G2 GREEN Mini PC User Manual - Setup, Operation, and Support</a></p> <p>Comprehensive user manual for the TRIGKEY G2 GREEN Mini PC, covering basic operation, VESA mount installation, component installation (RAM, SSD), connection steps, audio device configuration, troubleshooting, and after-service information.</p>
	<p><a href="#">TRIGKEY S3 USB Flash Drive User Manual - 2A4J2-S3</a></p> <p>Official user manual for the TRIGKEY S3 USB flash drive (model 2A4J2-S3) by ShenZhen AZW Technology CO.,LTD. Provides product details and usage information.</p>
	<p><a href="#">GEEKOM IT Series Mini PC Installation and Safety Guide</a></p> <p>A comprehensive guide for setting up and safely operating the GEEKOM IT Series Mini PC, including installation steps for M.2 SSD and RAM, VESA mounting, and essential safety warnings.</p>

	<p><a href="#">GMKtec Mini PC User Manual &amp; Specifications: NUCBOX G9, K10, M6 Series</a></p> <p>Comprehensive user manual and technical specifications for GMKtec Mini PCs, including models like NUCBOX G9, K10, and M6. Covers setup, hardware details, safety guidelines, and compliance information.</p>
	<p><a href="#">TRIGKEY Green G5 Mini PC User Manual</a></p> <p>User manual for the TRIGKEY Green G5 Mini PC featuring Intel 12th Gen Alder Lake-N100 CPU, 16GB DDR5 RAM, 500GB NVMe SSD, Dual 2.5G LAN, Wi-Fi 6, and Bluetooth 5.2.</p>