

HOMCOM 800-261V90BK

HOMCOM 8L Air Fryer (Model 800-261V90BK) User Manual

Efficient and Healthy Cooking

1. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before operating this appliance.

- **Do not immerse** the main unit housing, which contains electrical components and heating elements, in water or rinse under the tap.
- Ensure the voltage indicated on the appliance matches your local main voltage before connecting the appliance.
- Do not use the appliance if the plug, the main cord, or the appliance itself is damaged.
- Always unplug the appliance after use and before cleaning. Allow it to cool down completely before handling.
- Keep the appliance and its cord out of reach of children.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Place the appliance on a stable, horizontal, and heat-resistant surface. Do not place it on or near hot gas or electric burners, or in a heated oven.
- Do not block the air intake and air outlet openings.
- The appliance is equipped with an **overheat protection** system. If the internal temperature becomes too high, the protection system will activate, and the appliance will automatically shut off. Unplug the appliance and allow it to cool down before restarting.
- This appliance is intended for household use only.

2. PRODUCT OVERVIEW

The HOMCOM 8L Air Fryer is designed for healthy cooking with minimal to no oil. It features 360° hot air circulation for fast and even results, an intuitive LED touch screen, and multiple preset programs.



Image: The HOMCOM 8L Air Fryer, a black square-shaped appliance with a digital display and a pull-out basket handle, shown in a modern kitchen environment.

Components:

- Main Unit Housing
- Control Panel (LED Touch Screen)
- Air Intake Vent
- Air Outlet Vent
- Frying Basket
- Basket Handle

Dimensions:



Image: A diagram illustrating the dimensions of the air fryer: 32.5 cm (width), 41 cm (depth), and 32 cm (height).

3. BEFORE FIRST USE

Before using your new air fryer for the first time, follow these steps:

1. **Unpack:** Remove all packaging materials, stickers, and labels from the appliance.
2. **Clean Components:** Wash the frying basket and pan thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry completely.
3. **Wipe Main Unit:** Wipe the inside and outside of the appliance with a moist cloth.
4. **Initial Burn-in (Optional but Recommended):** To eliminate any manufacturing odors, place the empty basket and pan back into the air fryer. Plug in the appliance and set it to 200°C (390°F) for about 10-15 minutes. A slight odor may be present during this process; this is normal. Ensure good ventilation.

4. SETUP

The HOMCOM 8L Air Fryer requires no assembly. Follow these steps for initial setup:

1. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space on the back and sides, and above the appliance, to allow for proper air circulation.
2. **Power Connection:** Plug the power cord into a grounded wall outlet.
3. Ensure the frying basket and pan are correctly inserted into the main unit.

5. OPERATING INSTRUCTIONS

Control Panel:

The air fryer features an intuitive LED touch screen for easy operation.



Température
réglable



Minuterie de
60 minutes



Affichage
numérique LED

Image: Close-up of the air fryer's control panel highlighting adjustable temperature (80-200°C), 60-minute timer, and LED digital display.

- **Power Button:** Turns the appliance on/off and starts/pauses cooking.
- **Temperature Control:** Use '+' and '-' buttons to adjust temperature from 80°C to 200°C.
- **Timer Control:** Use '+' and '-' buttons to adjust cooking time from 1 to 60 minutes.
- **Preset Programs:** Icons for various food types (Fries, Chicken, Steak, Fish, Baking, Pizza, Vegetables, DIY).

Basic Operation:

1. **Prepare Food:** Place ingredients into the frying basket. Do not overfill the basket.
2. **Insert Basket:** Slide the frying basket back into the main unit until it clicks into place.
3. **Power On:** Press the Power button to turn on the display.
4. **Set Time and Temperature:** Manually adjust the desired cooking time and temperature using the respective '+' and '-' buttons.
5. **Start Cooking:** Press the Power button again to start the cooking process.
6. **Shake Basket (Optional):** For some foods, shaking the basket halfway through cooking ensures even browning. Pull out the basket, shake it, and reinsert. The air fryer will resume cooking automatically.
7. **Completion:** The air fryer will beep when the set cooking time has elapsed and automatically shut off.
8. **Remove Food:** Carefully pull out the basket using the handle. Use tongs to remove cooked food.



Image: The HOMCOM Air Fryer with its cooking basket partially pulled out, revealing crispy food inside, surrounded by other prepared dishes.

Using Preset Programs:

The air fryer comes with 8 convenient preset programs for common dishes:

8 PRESETS



Chips



Poulet



Steak



Poisson



Cuisson



Pizza



Légumes



DIY



Image: A visual representation of the 8 preset programs available on the air fryer: Chips (Fries), Poulet (Chicken), Steak, Poisson (Fish), Cuisson (Baking), Pizza, Légumes (Vegetables), and DIY.

1. **Select Program:** After powering on, tap the desired preset icon on the control panel. The display will show the default time and temperature for that program.
2. **Adjust (Optional):** You can adjust the time and temperature of a preset program if needed.
3. **Start Cooking:** Press the Power button to begin.

Cooking with 360° Hot Air Circulation:

The air fryer utilizes 360° hot air circulation technology to cook food evenly and efficiently, resulting in crispy textures with significantly less oil.

CIRCULATION D'AIR À 360°



Chauffage rapide
et homogène



Gain de temps



Des aliments
savoureux et
croustillants



Image: A diagram illustrating the 360-degree hot air circulation inside the air fryer, showing rapid and homogeneous heating for crispy food, with a chicken cooking inside.

6. MAINTENANCE AND CLEANING

Regular cleaning will extend the life of your air fryer and ensure optimal performance.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Clean Basket and Pan:** The frying basket and pan have a non-stick coating. Clean them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak the basket and pan in hot water with dish soap for about 10 minutes.
3. **Wipe Exterior:** Wipe the exterior of the appliance with a damp cloth. Do not use harsh abrasive cleaners or scouring pads, as they can damage the surface.
4. **Clean Interior:** Clean the inside of the appliance with hot water and a non-abrasive sponge.
5. **Heating Element:** Use a cleaning brush to remove any food residue from the heating element.
6. **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in. Power outlet not working.	Ensure the power cord is securely plugged into a grounded outlet. Check the outlet with another appliance.
Food not cooked evenly.	Basket is overfilled. Food not shaken.	Do not overfill the basket. Shake the basket halfway through cooking for even results.
White smoke coming from the appliance.	Grease residue from previous use. Fatty ingredients being cooked.	Clean the basket and pan thoroughly after each use. For fatty foods, absorb excess oil with a paper towel.
Food not crispy.	Not enough cooking time or too low temperature. Too much moisture in food.	Increase cooking time or temperature. Pat food dry before air frying. A small amount of oil can help achieve crispiness.

8. SPECIFICATIONS

Feature	Specification
Brand	HOMCOM
Model Number	800-261V90BK
Color	Black
Product Dimensions (L x W x H)	32.5 x 41 x 32 cm
Capacity	8 Liters
Power	1700 Watts
Voltage	220 Volts
Material	Steel, Plastic
Item Weight	6.6 Kilograms
Special Features	Automatic Shut-off, 360° Hot Air Circulation, Temperature Control, Timer, LED Touch Screen
Country of Origin	China

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact your retailer. For technical support or inquiries regarding your HOMCOM 8L Air Fryer, please contact HOMCOM customer service through their official website or the contact details provided in your purchase information.