Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Getac /
- Getac S410 G4 Rugged Laptop User Manual

Getac S410

Getac S410 G4 Rugged Laptop User Manual

Model: S410 G4



Front view of the Getac S410 G4 Rugged Laptop, showcasing its robust design and the Windows 11 operating system on its 14-inch display.

1. Introduction

This user manual provides essential information for the safe and efficient operation of your Getac S410 G4 Rugged

Laptop. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize its lifespan. Keep this manual for future reference.

2. PRODUCT OVERVIEW

Key Features

- **Processor:** Intel Core i5-1145G7 with Max Turbo Frequency 4.40GHz, Quad-core, 8MB Smart Cache, and Intel Iris Xe Graphics.
- Memory & Storage: 16GB DDR4 RAM and 512GB PCIe NVMe SSD.
- **Display:** 14-inch IPS TFT LCD FHD (1920 x 1080) LumiBond display with 1,000 nits brightness and Getac sunlight readable technology.
- **Durability:** MIL-STD-810H and IP53 certified rugged design, resistant to vibration, 3ft (0.9m) drops, and splash-resistant keyboard.
- Keyboard: LED Backlit membrane Keyboard.
- Ports: 2x USB 3.2, Thunderbolt 4, USB 2.0, HDMI, LAN, Audio In/Out Jack, Docking Connector.
- **Security & Input:** FHD webcam with Windows Hello face-authentication, Contactless Smart Card Reader, Barcode Reader, Capacitive stylus with tether.
- **Dimensions & Weight:** (WxDxH) 13.8" x 11.5" x 1.5", approximately 5.25 lbs.
- Operating System: Windows 11 Pro.

Component Identification



This image highlights key components of the Getac S410 G4, including the FHD webcam with Windows Hello face-authentication, sunlight readable display, barcode reader, and contactless smart card reader.



Side view of the Getac S410 G4 Rugged Laptop, showing its robust casing and port layout.



Bottom view of the Getac S410 G4 Rugged Laptop, illustrating the battery compartment and other access panels.

3. SETUP

3.1 Initial Power On

- 1. Connect the provided AC adapter to the DC JACK port on the laptop and then to a power outlet.
- 2. Press the power button located on the keyboard to turn on the laptop.
- 3. Follow the on-screen instructions to complete the initial Windows 11 Pro setup.

3.2 Battery Installation/Replacement

The Getac S410 G4 features a removable battery. To install or replace the battery:

- 1. Ensure the laptop is powered off and disconnected from the AC adapter.
- 2. Flip the laptop over to access the bottom panel.
- 3. Locate the battery compartment. Slide the release latches to unlock the battery.
- 4. Carefully remove the old battery (if replacing) or insert the new battery into the compartment.
- 5. Push the battery firmly until it clicks into place and the latches secure it.

3.3 SIM Card Installation

To install a SIM card for mobile data connectivity:

- 1. Ensure the laptop is powered off and disconnected from the AC adapter.
- 2. Flip the laptop over to access the bottom panel.
- 3. Unscrew the back cover to reveal the internal components.
- 4. Locate the SIM card slot, often near the SSD or other modules.
- 5. Carefully insert the SIM card into the designated slot until it is securely seated.
- 6. Replace the back cover and secure it with screws.
- 7. Upon powering on, the system should detect the SIM card and allow for mobile network configuration.

4. OPERATING INSTRUCTIONS

4.1 Display Features

- Sunlight Readable Display: The 1,000 nits LumiBond display is designed for optimal visibility in direct sunlight. Adjust brightness settings in Windows for best performance.
- **Touchscreen & Stylus:** Use the touchscreen for intuitive navigation or the included capacitive stylus for precise input, especially useful in outdoor or gloved environments.

4.2 Input Devices

- Keyboard: The LED backlit membrane keyboard allows for comfortable typing in various lighting conditions.
 Adjust backlight intensity as needed.
- Webcam: The FHD webcam supports Windows Hello face-authentication for secure and convenient login.

4.3 Connectivity

- Wireless: Connect to Wi-Fi networks (802.11ax) and Bluetooth devices.
- Wired Ports: Utilize the various USB ports (3.2, Thunderbolt 4, 2.0), HDMI for external displays, and LAN for wired network connections.

4.4 Specialized Readers

- Contactless Smart Card Reader: For secure authentication and data access using compatible smart cards.
- Barcode Reader: Integrated for efficient scanning of barcodes in various applications.

5. MAINTENANCE

5.1 Cleaning

- Use a soft, lint-free cloth dampened with water or a mild screen cleaner to clean the display.
- For the casing and keyboard, use a soft cloth. Avoid harsh chemicals or abrasive materials.
- Ensure all port covers are securely closed to maintain IP53 rating against dust and splashes.

5.2 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place when not in use for extended periods.

5.3 Ruggedness Guidelines

While designed for rugged environments, proper handling is still recommended:

- Avoid intentional drops or impacts beyond the specified 3ft (0.9m) drop resistance.
- Ensure all port covers are sealed when operating in dusty or wet conditions to maintain IP53 protection.
- Do not expose the device to extreme temperatures outside its operating range.

6. TROUBLESHOOTING

If you encounter issues with your Getac S410 G4, consider the following basic troubleshooting steps:

- **No Power:** Ensure the AC adapter is securely connected and the power outlet is functional. Check battery charge level.
- **Display Issues:** Adjust screen brightness. If the screen remains blank, try connecting to an external monitor to diagnose.
- **Connectivity Problems:** For Wi-Fi, ensure the wireless adapter is enabled and you are within range of a known network. For SIM card issues, verify correct installation and network settings.
- System Unresponsive: Perform a hard reset by holding down the power button until the device shuts off, then restart.

For more complex issues, refer to the official Getac support resources or contact customer service.

7. SPECIFICATIONS

Feature	Detail
Processor	Intel Core i5-1145G7 (up to 4.4GHz)
RAM	16GB DDR4 (3200 MHz)
Storage	512GB PCIe NVMe SSD

Feature	Detail
Display Size	14 Inches
Screen Resolution	1920 x 1080 pixels (FHD)
Brightness	1,000 nits (LumiBond, Sunlight Readable)
Graphics	Intel Iris Xe Graphics (Integrated)
Operating System	Windows 11 Pro
Durability Rating	MIL-STD-810H, IP53 Certified
Drop Resistance	3ft (0.9m)
Wireless Connectivity	802.11ax, Bluetooth
Ports	2x USB 3.2, 1x Thunderbolt 4, 1x USB 2.0, HDMI, LAN, Audio In/Out, Docking Connector
Webcam	FHD with Windows Hello face-authentication
Special Features	Backlit Keyboard, Spill Resistant, Touchscreen, Stylus, Contactless Smart Card Reader, Barcode Reader
Dimensions (LxWxH)	13.8 x 11.5 x 1.5 inches
Weight	7.63 pounds
Battery	1 Lithium Ion battery (included)
Included Accessories	AC Adapter, Capacitive Stylus with Tether

8. WARRANTY AND SUPPORT

This Getac S410 G4 Rugged Laptop is an Amazon Renewed product. For details regarding warranty, returns, and customer support, please refer to the Amazon Renewed Guarantee information provided at the time of purchase or visit the Amazon Renewed program page. The product is eligible for replacement or refund under the Amazon Renewed Guarantee.

Related Documents - S410

