



Manuals.plus /

› Gourmia /

› Gourmia Air Fryer Toaster Oven Combo User Manual

Gourmia GAF1230A

Gourmia Air Fryer Toaster Oven Combo User Manual

Model: GAF1230A

Brand: Gourmia

INTRODUCTION

This user manual provides essential information for the safe and efficient operation of your Gourmia Air Fryer Toaster Oven Combo. This all-in-one 14-quart digital appliance offers multiple cooking functions including air frying, rotisserie, dehydrating, baking, and broiling. Please read these instructions thoroughly before first use and retain them for future reference.

Important Safety Information

- Always place the appliance on a stable, heat-resistant surface.
- Ensure adequate ventilation around the appliance during operation.
- Do not immerse the main unit in water or other liquids.
- Keep children and pets away from the appliance during use.
- Unplug the appliance when not in use and before cleaning.
- Refer to the troubleshooting section for common issues before contacting support.

PRODUCT OVERVIEW

The Gourmia Air Fryer Toaster Oven Combo is designed for versatile cooking with its multi-functional capabilities and user-friendly digital interface.



Front view of the Gourmia Air Fryer Toaster Oven Combo, showcasing its digital display and the interior with food baskets.



Detailed view of the intuitive touchscreen control panel with various one-touch presets.



Included accessories: two fry baskets, a mess-free drip tray, rotisserie spit, rotisserie forks, and a rotisserie lift tool.



The spacious 14-quart interior, capable of fitting a 4 lb whole chicken or a 12-inch pizza.

Key Features:

- **4-in-1 Functionality:** Air fry, rotisserie, dehydrate, and bake/broil.
- **12 One-Touch Cooking Presets:** Air Fry, Fries, Wings, Bacon, Seafood, Vegetables, Bake, Roast, Broil, Dehydrate, Reheat, and Keep Warm.
- **Smart Guided Cooking:** Built-in prompts for preheating and turning food mid-cycle.
- **Spacious 14-Quart Capacity:** Accommodates a 4 lb whole chicken or a 12-inch pizza.
- **Easy Cleanup:** Stainless steel interior and dishwasher-safe accessories.

SETUP

1. **Unpacking:** Carefully remove all packaging materials, stickers, and labels from the appliance and its

accessories.

2. **Initial Cleaning:** Wash all removable parts (fry baskets, drip tray, rotisserie accessories) with warm, soapy water. Wipe the interior and exterior of the main unit with a damp cloth. Dry thoroughly.
3. **Placement:** Place the air fryer on a stable, level, heat-resistant surface, ensuring at least 6 inches of clearance from walls or other appliances to allow for proper air circulation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. The digital display will illuminate.
5. **First Use (Burn-in):** Before cooking food, it is recommended to run the appliance empty for approximately 10-15 minutes at 400°F (200°C) to eliminate any manufacturing odors. Ensure the area is well-ventilated during this process.

OPERATING INSTRUCTIONS

Your Gourmia Air Fryer Toaster Oven Combo features an intuitive touchscreen control panel for easy operation.

Control Panel Overview:

- **Power Button:** Turns the appliance on/off.
- **Temperature/Time Controls:** Up/Down arrows to adjust temperature and cooking time.
- **Preset Icons:** Select from 12 pre-programmed cooking functions (Air Fry, Fries, Wings, Bacon, Seafood, Vegetables, Bake, Roast, Broil, Dehydrate, Reheat, Keep Warm).
- **PREHEAT:** Initiates a preheating cycle.
- **TURN REMINDER:** Activates an audible reminder to turn or shake food during cooking.
- **STOP/CANCEL:** Stops the current cooking cycle.
- **START:** Begins the selected cooking cycle.
- **ROTATE:** Activates the rotisserie function (for use with rotisserie accessories).
- **LIGHT:** Turns the interior light on/off to monitor cooking progress.

Using One-Touch Presets:

1. Place food inside the appropriate accessory (fry basket, rotisserie spit, etc.).
2. Close the oven door securely.
3. Press the Power button to turn on the display.
4. Select the desired preset icon (e.g., "Air Fry", "Fries"). The display will show default time and temperature settings.
5. Adjust time and temperature using the Up/Down arrows if needed.
6. Press START to begin cooking.
7. The appliance will automatically preheat if the preset requires it.
8. Follow any "TURN REMINDER" prompts if activated.
9. Once cooking is complete, the appliance will beep and turn off. Carefully remove food using heat-resistant mitts.

Manual Operation:

1. Press the Power button.
2. Adjust the desired temperature using the temperature Up/Down arrows.
3. Adjust the desired cooking time using the time Up/Down arrows.

4. Press START to begin cooking.

Rotisserie Function:

To use the rotisserie function, ensure the rotisserie spit and forks are properly assembled with your food. Insert the spit into the rotisserie sockets inside the oven. Select a relevant preset (e.g., "Roast") or set manual time/temperature, then press the ROTATE button to activate the rotation.

Official Product Videos:

No official product videos from the seller are available for embedding at this time. Please refer to the written instructions for detailed guidance.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your Gourmia Air Fryer Toaster Oven Combo.

- **Before Cleaning:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
- **Accessories:** The fry baskets, drip tray, rotisserie spit, and forks are dishwasher-safe for convenient cleaning. For stubborn food residue, soak in warm, soapy water before washing.
- **Interior:** Wipe the stainless steel interior with a damp cloth and mild detergent. For baked-on food, a non-abrasive sponge or brush can be used. Avoid abrasive cleaners or metal scouring pads.
- **Exterior:** Clean the exterior with a damp cloth. Do not use harsh chemicals or abrasive materials.
- **Door:** Wipe the tempered-glass window with a soft cloth and glass cleaner if necessary.
- **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your appliance, please consult the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure power cord is securely plugged in. Check circuit breaker. Try a different outlet.
Food is not cooking evenly.	Overcrowding; insufficient turning/shaking.	Cook in smaller batches. Use the "TURN REMINDER" function or manually turn/shake food halfway through cooking.
White smoke coming from appliance.	Grease/oil residue; high-fat food.	Clean the drip tray and interior thoroughly. For high-fat foods, use a small amount of water in the drip tray to reduce smoke.
Appliance emits unusual noise.	Fan obstruction; loose component.	Unplug and inspect for any obstructions. If noise persists, contact customer support.

SPECIFICATIONS

Attribute	Detail
Model Name	Air Fryer Toaster Oven Combo
Item Model Number	GAF1230A
Brand	Gourmia
Capacity	14 Quarts
Product Dimensions	15"D x 15"W x 16"H
Color	Black
Material	Stainless Steel
Output Wattage	1750 Watts
Voltage	120 Volts
Control Method	Touch
Air Frying Technology	Air Fry Technology
Is Dishwasher Safe	Yes (Accessories)
UPC	810190210093

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product packaging or visit the official Gourmia website. If you require technical assistance or have questions not covered in this manual, please contact Gourmia customer support.

Gourmia Official Website: www.gourmia.com