



Manuals.plus /

- › **Beelicious Pro** /
- › Beelicious 8-in-1 Smart Compact 4QT Air Fryer BAF806 User Manual

Beelicious Pro BAF806

Beelicious 8-in-1 Smart Compact 4QT Air Fryer User Manual

Model: BAF806

1. INTRODUCTION

Thank you for choosing the Beelicious 8-in-1 Smart Compact 4QT Air Fryer. This appliance is designed to provide a healthier and more efficient way to cook your favorite meals. By utilizing rapid air circulation and precise temperature control, it delivers crispy and tender results with significantly less oil. Please read this manual thoroughly before first use to ensure safe operation and optimal performance.



Image: Beelicious 4QT Smart Air Fryer in Avo Green, shown with a recipe book.

2. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause

injuries.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the air fryer basket is properly inserted before operating.
- A short power-supply cord is provided to reduce the risks resulting from entanglement or tripping over a longer cord.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Beelicious Air Fryer:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Digital display with touch controls for settings.
- **Air Fryer Basket:** Removable, non-stick cooking basket.
- **Crisper Plate:** Sits inside the basket for optimal air circulation.
- **Handle:** For safely removing and inserting the basket.
- **Viewing Window:** Allows monitoring of cooking progress without opening the basket.
- **Internal Light:** Illuminates the cooking chamber for clear viewing.

Easy Cooking Window With Light

Check Cooking Progress Anytime without Pulling Out The Basket



Viewing Window



Heat Resistant



Built-in Light

Image: Close-up of the Beelicious air fryer highlighting the viewing window, heat-resistant design, and built-in light.

4. SETUP AND FIRST USE

Before using your air fryer for the first time, follow these steps:

1. **Unpack:** Remove all packaging materials, stickers, and labels from the appliance.
2. **Clean Components:** Wash the air fryer basket and crisper plate with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely. The main unit can be wiped with a damp cloth.
3. **Initial Run (Optional):** To eliminate any manufacturing odors, place the crisper plate in the basket, insert the basket into the air fryer, and run the appliance for 10-15 minutes at 350°F (175°C) without food. Ensure the area is well-ventilated.
4. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface, away from walls or other appliances to allow for proper airflow.

5. OPERATING INSTRUCTIONS

5.1 Control Panel Overview

The Beelicious Air Fryer features an intuitive digital touch control panel.

8+ Functions All in One

Wide Customizable Temp Range : 100-450°F



Image: The digital control panel showing various cooking presets and temperature display.

- **Power Button:** Turns the unit on/off.
- **Menu Button:** Cycles through preset cooking functions.
- **Temperature/Time Adjustment (+/-):** Increases or decreases temperature and time.
- **Temperature/Time Toggle (A/C):** Switches between temperature and time settings.
- **Shake Reminder:** Activates or deactivates the shake reminder for certain presets.
- **Light Button:** Turns the internal light on/off to view food.
- **Display:** Shows current temperature, time, and selected preset.

5.2 Using Preset Functions (8-in-1)

Your air fryer comes with 8 convenient preset cooking functions:

- Air Fry
- Roast
- Bake

- Broil
- Fries
- Steak
- Reheat
- Dehydrate

1. Place food in the air fryer basket, ensuring it does not exceed the MAX fill line.
2. Insert the basket firmly into the main unit.
3. Press the Power button to turn on the display.
4. Press the Menu button repeatedly to cycle through the preset functions until your desired function is selected. The display will show the default time and temperature for that preset.
5. You can adjust the time and temperature using the +/- buttons if needed. Press the A/C button to switch between adjusting time and temperature.
6. Press the Power button again to start cooking.

5.3 Manual Cooking

For custom recipes or specific cooking needs:

1. Place food in the air fryer basket and insert it into the unit.
2. Press the Power button.
3. Use the A/C button to select either temperature or time.
4. Use the +/- buttons to set your desired temperature (100°F - 450°F).
5. Use the A/C button again to switch to time.
6. Use the +/- buttons to set your desired cooking time (1-60 minutes).
7. Press the Power button to start cooking.

5.4 Shake Reminder

For certain foods like fries or chicken wings, shaking or flipping halfway through cooking ensures even crisping.



Image: Illustration of the Shake Reminder feature, demonstrating how shaking food leads to even cooking.

- When a preset function that benefits from shaking is selected, the 'Shake' icon may illuminate.
- If the Shake Reminder is active, the air fryer will beep and display 'SHAKE' halfway through the

cooking cycle.

- Carefully remove the basket, shake or flip the food, and reinsert the basket to resume cooking.
- You can manually activate or deactivate the Shake Reminder for any cooking cycle by pressing the 'Shake' button on the control panel.

5.5 Viewing Window and Light

The integrated viewing window and internal light allow you to monitor your food without interrupting the cooking process.

- During cooking, press the 'Light' button on the control panel to turn the internal light on or off.
- This feature helps prevent heat loss and ensures consistent cooking results.

6. COOKING TIPS

- **Preheating:** For best results, preheat the air fryer for 3-5 minutes before adding food.
- **Oil Usage:** While air frying requires significantly less oil, a light spray or toss with oil can enhance crispiness, especially for fresh ingredients.
- **Single Layer:** Arrange food in a single layer in the basket to allow hot air to circulate evenly. Overcrowding can lead to uneven cooking.
- **Shake/Flip:** For smaller items like fries or nuggets, shake the basket halfway through cooking. For larger items, flip them.
- **Doneness:** Cooking times may vary based on food type, quantity, and desired crispiness. Always use a food thermometer to ensure meat and poultry are cooked to safe internal temperatures.
- **Frozen Foods:** Most frozen foods can be cooked directly in the air fryer. Follow package instructions or adjust cooking time and temperature as needed.

7. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your air fryer.

Unique Metal Chamber Design

Our Brand ✓

- Metal Material
- Reduce Plastic Smell
- Efficient Heating and Insulation

VS

Other Brands ✗

- Plastic Material
- Strong Plastic Smell
- Heat Transfer Inefficiency

Image: The air fryer basket and crisper plate are shown being cleaned, highlighting their dishwasher-safe and easy-to-clean properties.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Basket and Crisper Plate:** The air fryer basket and crisper plate are dishwasher-safe. Alternatively,

wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak in warm soapy water for 10-15 minutes.

3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water or any other liquid.
4. **Heating Element:** If necessary, gently clean the heating element inside the air fryer with a soft brush to remove any food debris.
5. **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.

Care for Non-stick Coating: To prolong the life of the non-stick coating, avoid using metal utensils or abrasive cleaning materials.

8. TROUBLESHOOTING

If you encounter any issues with your Beelicious Air Fryer, refer to the following table for common problems and solutions:

| Problem | Possible Cause | Solution |
|------------------------------------|--|--|
| Air fryer does not turn on. | Not plugged in; power outlet malfunction; basket not fully inserted. | Ensure power cord is securely plugged in. Check power outlet. Push basket firmly into the unit until it clicks. |
| Food is not cooked evenly. | Basket overcrowded; food not shaken/flipped; incorrect temperature/time. | Cook food in smaller batches. Shake or flip food halfway through cooking. Adjust temperature and time as needed. |
| Food is not crispy. | Too much moisture; not enough oil; basket overcrowded. | Pat food dry before cooking. Lightly spray or toss with oil. Do not overcrowd the basket. Increase cooking time or temperature slightly. |
| White smoke coming from appliance. | Grease residue from previous use; high-fat food cooking. | Clean the basket and crisper plate thoroughly. For high-fat foods, drain excess fat during cooking or place a small amount of water under the crisper plate. |
| Appliance smells like plastic. | First few uses; new appliance odor. | This is normal for new appliances. Run the air fryer empty for 10-15 minutes in a well-ventilated area. The smell should dissipate after a few uses. |

9. PRODUCT SPECIFICATIONS

| Feature | Specification |
|-------------------------|--|
| Model Name | BAF806 |
| Capacity | 4 Quarts |
| Product Dimensions | 11.61"D x 8.86"W x 12.4"H |
| Item Weight | 9.46 Pounds |
| Output Wattage | 1550 Watts |
| Voltage | 120 Volts (AC) |
| Control Method | Touch |
| Min Temperature Setting | 100 Degrees Fahrenheit |
| Max Temperature Setting | 450 Degrees Fahrenheit |
| Special Features | Glass Display, Metal Chamber, Nonstick Basket, Programmable, Quiet Operation |
| Dishwasher Safe Parts | Yes (Basket and Crisper Plate) |
| Certifications | ETL Certified |

10. WARRANTY AND SUPPORT

Beelicious Pro offers a **1-year warranty** for this product. For technical consultation or any issues, please contact us via Amazon or our consumer hotline. Problems will be addressed within 2 working days. Registering your product within the first 7 days of purchase may extend your warranty. Please refer to the product registration information provided with your purchase for details. For further assistance, please visit the [Beelicious Pro Store on Amazon](#).