

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [MSI](#) /

› [MSI PRO MP245PG E14 24-inch Monitor Instruction Manual](#)

## MSI PRO MP245PG E14

# MSI PRO MP245PG E14 24-inch Monitor Instruction Manual

Model: PRO MP245PG E14

## INTRODUCTION

---

This manual provides essential information for the setup, operation, and maintenance of your MSI PRO MP245PG E14 24-inch IPS monitor. Please read this guide thoroughly before using the product to ensure proper functionality and safety. The MSI PRO MP245PG E14 is a 24-inch Full HD (1920x1080) monitor featuring a 140Hz refresh rate, Adaptive-Sync technology, HDR readiness, and multiple connectivity options including HDMI, DisplayPort, and VGA. It also incorporates MSI EyesErgo technology for user comfort.

## SAFETY INFORMATION

---

Observe the following safety precautions to prevent damage to the monitor and ensure personal safety:

- Always disconnect the power cable from the electrical outlet before cleaning the monitor.
- Do not expose the monitor to rain or moisture to avoid fire or shock hazards.
- Do not open the monitor casing. There are no user-serviceable parts inside. Refer all servicing to qualified service personnel.
- Place the monitor on a stable, flat surface to prevent it from falling.
- Ensure proper ventilation around the monitor. Do not block ventilation openings.
- Use only the power adapter and cables supplied with the monitor.

## PACKAGE CONTENTS

---

Verify that all items are present in your package. If any items are missing or damaged, contact your retailer.

- MSI PRO MP245PG E14 Monitor
- Monitor Stand (Base and Neck)
- Power Cable
- HDMI Cable
- Documentation (Quick Start Guide, Warranty Card)

### 1. Assembling the Stand

1. Carefully remove the monitor and stand components from the packaging.
2. Attach the stand neck to the monitor panel. Ensure it clicks securely into place or is fastened with screws as indicated in the quick start guide.
3. Attach the stand base to the stand neck, securing it with the thumb screw or screws provided.



Figure 1: MSI PRO MP245PG E14 monitor fully assembled on its stand.

### 2. Connecting Cables

Connect the necessary cables to the monitor and your computer or other devices.

1. **Power Connection:** Connect the power cable to the monitor's power input and then to a power outlet.
2. **Video Connection:** Choose one of the following video input options:
  - **HDMI:** Connect an HDMI cable from your computer's HDMI output to the monitor's HDMI input.
  - **DisplayPort:** Connect a DisplayPort cable from your computer's DisplayPort output to the monitor's DisplayPort input.
  - **VGA (D-Sub):** Connect a VGA cable from your computer's VGA output to the monitor's VGA input.
3. **Audio Connection (Optional):** If using external speakers or headphones, connect them to the monitor's audio

output jack.



Figure 2: Rear view of the monitor showing available input ports.

### 3. Initial Power-On

After connecting all cables, press the power button on the monitor to turn it on. The monitor will automatically detect the active input source. If not, you may need to manually select the input source using the On-Screen Display (OSD) menu.

## OPERATING THE MONITOR

---

### 1. Power On/Off

Press the power button, typically located on the back or bottom right of the monitor, to turn the monitor on or off. The power indicator light will show the monitor's status.

### 2. On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various monitor settings. Access the OSD menu by pressing the OSD navigation button or joystick, usually located on the back of the monitor. Navigate through the menu options using the joystick or directional buttons and confirm selections by pressing the center button or a dedicated 'Enter' button.

### 3. Adjusting Display Settings

Within the OSD menu, you can modify settings such as:

- **Brightness/Contrast:** Adjust the overall luminance and contrast ratio of the display.
- **Color Settings:** Fine-tune color temperature, gamma, and individual RGB levels.
- **Input Source:** Manually select between HDMI, DisplayPort, or VGA inputs.
- **Refresh Rate:** The monitor supports up to 140Hz refresh rate. Ensure your graphics card settings are configured to utilize this refresh rate for smoother visuals.

- **Adaptive-Sync:** Enable or disable Adaptive-Sync for tear-free gaming experiences.
- **MSI EyesErgo Technology:** This feature includes Anti-Flicker and Less Blue Light modes to reduce eye strain during prolonged use. These settings can be adjusted in the OSD.

#### 4. Ergonomic Adjustments

The monitor stand offers multiple ergonomic adjustments to optimize your viewing comfort:

- **Tilt:** Adjust the screen's vertical angle (-5° to 20°).
- **Swivel:** Rotate the screen horizontally (-45° to 45°).
- **Height Adjustment:** Raise or lower the screen (up to 130mm).
- **Pivot:** Rotate the screen 90° for portrait mode (-90° to 90°).



Figure 3: Illustration of the monitor's adjustable stand capabilities.





Figure 4: Side view highlighting the height adjustment feature.

## 5. VESA Mount Compatibility

The monitor is VESA mount compatible (75x75mm), allowing you to attach it to a wall mount or an alternative monitor arm. To do this, remove the stand and attach the VESA-compatible mounting bracket to the back of the monitor.



Figure 5: Monitor with a mini PC attached via VESA mount.

## MAINTENANCE

---

### 1. Cleaning the Monitor

- Always unplug the monitor from the power outlet before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a non-abrasive screen cleaner.
- Do not spray cleaner directly onto the screen. Apply it to the cloth first.
- Avoid using benzene, thinner, ammonia-based cleaners, or abrasive cleaning agents, as these can damage the screen or casing.

### 2. Storage

If storing the monitor for an extended period, ensure it is clean, dry, and stored in a cool, well-ventilated area. Use the original packaging if available to protect it from dust and physical damage.

## TROUBLESHOOTING

---

If you encounter issues with your monitor, refer to the following common troubleshooting steps:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
No image on screen	<p>Ensure the power cable is securely connected and the monitor is turned on.</p> <p>Check that the video cable (HDMI, DisplayPort, VGA) is properly connected to both the monitor and the computer.</p> <p>Verify that the correct input source is selected in the OSD menu.</p> <p>Test with another video cable or device if possible.</p>
Image is blurry or distorted	<p>Adjust the resolution and refresh rate settings on your computer to match the monitor's native resolution (1920x1080) and desired refresh rate (up to 140Hz).</p> <p>Check the video cable for damage or loose connections.</p> <p>Perform an 'Auto Adjust' function in the OSD menu if available (primarily for VGA connections).</p>
Screen flickering	<p>Ensure the video cable is securely connected.</p> <p>Disable or enable Adaptive-Sync in the OSD menu or graphics card settings.</p> <p>Check for external interference from other electronic devices.</p> <p>Enable Anti-Flicker mode in the OSD menu.</p>
No sound from built-in speakers	<p>Ensure the audio cable (if used) is connected, or that audio is being transmitted via HDMI/DisplayPort.</p> <p>Check the volume settings in the OSD menu and on your computer.</p> <p>Verify that the monitor is selected as the default audio output device in your computer's sound settings.</p>

For more complex issues or if the problem persists, please refer to the official MSI support website or contact customer service.

## SPECIFICATIONS

Feature	Specification
Model Name	PRO MP245PG E14
Screen Size	24 Inches
Panel Type	IPS
Resolution	1920 x 1080 (FHD)
Refresh Rate	140Hz
Response Time	1ms (MPRT)
Aspect Ratio	16:9
Connectivity	1x HDMI, 1x DisplayPort, 1x VGA (D-Sub)
VESA Mounting	75 x 75 mm
Ergonomics	Tilt, Swivel, Height Adjustment, Pivot

Feature	Specification
Built-in Speakers	Yes
Dimensions (W x D x H)	53.92 x 31.47 x 51.92 cm (with stand)
Weight	7.26 kg (with stand)
Color	Black

## WARRANTY INFORMATION

---

MSI provides a limited warranty for this product. The specific terms and conditions of the warranty may vary by region and purchase date. Please refer to the warranty card included in your product packaging or visit the official MSI website for detailed warranty information and registration procedures. Keep your proof of purchase for warranty claims.

## SUPPORT

---

For technical assistance, driver downloads, FAQs, or further product information, please visit the official MSI support website:

[www.msi.com/support](http://www.msi.com/support)

You may also contact MSI customer service directly through the contact information provided on their website or in your product documentation.