

[Manuals.plus](#) /

> [Karlsson](#) /

> Karlsson Funky Vibes Alarm Clock with Bluetooth Speaker KA6060PU User Manual

## Karlsson KA6060PU

# Karlsson Funky Vibes Alarm Clock with Bluetooth Speaker KA6060PU User Manual

Model: KA6060PU

## INTRODUCTION

---

Thank you for purchasing the Karlsson Funky Vibes Alarm Clock with Bluetooth Speaker. This device combines a digital alarm clock with a portable wireless speaker, offering both timekeeping and audio entertainment. This manual provides essential information for the safe and efficient use of your new device. Please read it thoroughly before use and retain it for future reference.

## IMPORTANT SAFETY INFORMATION

---

- Do not expose the device to water or excessive moisture.
- Avoid extreme temperatures, direct sunlight, and dusty environments.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Use only the provided USB Type-C cable for charging.
- Keep out of reach of children.

## PACKAGE CONTENTS

---

Please check the package for the following items:

- Karlsson Funky Vibes Alarm Clock with Bluetooth Speaker (Model: KA6060PU)
- USB Type-C Charging Cable (1 meter length)
- User Manual (this document)

## PRODUCT OVERVIEW

---

Familiarize yourself with the different parts of your Funky Vibes Alarm Clock.



Image: The Karlsson Funky Vibes Alarm Clock is available in various colors, featuring a clear digital display and an integrated speaker.

## Front View



Image: The front of the alarm clock features a large digital display for time, date, and temperature, with a speaker grille at the top.

- **Digital Display:** Shows time, date, and temperature.
- **Speaker Grille:** Located at the top front, for audio output.

### Side View



Image: The side panel of the alarm clock, displaying the Karlsson brand logo.

## Top/Rear View (Controls and Ports)



Image: The top/rear panel features the control buttons and the USB-C charging port.

- **Power Button (U):** Press and hold to turn on/off. Short press to toggle display.
- **Settings Button (⚙️):** Enter settings mode for time, alarm, etc.
- **Up Button (▲):** Increase values or navigate menus.
- **Down Button (▼):** Decrease values or navigate menus.
- **USB Type-C Port:** For charging the device.

## SETUP

---

### 1. Charging the Device

1. Connect the provided USB Type-C cable to the USB-C port on the back of the alarm clock.
2. Connect the other end of the USB cable to a compatible USB power adapter (DC 5V--1A, not included) or a computer USB port.
3. The charging indicator (if present) will illuminate. A full charge takes approximately 5 to 6 hours.
4. Once fully charged, disconnect the cable. The device can be used while charging.

## 2. Powering On/Off

- **To Power On:** Press and hold the Power button (U) for a few seconds until the display illuminates.
- **To Power Off:** Press and hold the Power button (U) for a few seconds until the display turns off.

## 3. Setting Time and Date

1. With the device powered on, press the Settings button (⚙️) to enter time setting mode. The hour digits will flash.
2. Use the Up (▲) and Down (▼) buttons to adjust the hour.
3. Press the Settings button (⚙️) again to move to minute setting. Adjust with Up (▲) and Down (▼) buttons.
4. Continue pressing the Settings button (⚙️) to cycle through year, month, and day settings, adjusting each with the Up (▲) and Down (▼) buttons.
5. After setting the day, press the Settings button (⚙️) one last time to exit setting mode.

## 4. Setting the Alarm

1. From the normal time display, press the Settings button (⚙️) repeatedly until the alarm time (e.g., "AL 00:00") appears and the hour digits flash.
2. Use the Up (▲) and Down (▼) buttons to set the desired alarm hour.
3. Press the Settings button (⚙️) to move to minute setting. Adjust with Up (▲) and Down (▼) buttons.
4. Press the Settings button (⚙️) again to confirm and activate the alarm. An alarm icon will appear on the display.
5. **To Deactivate Alarm:** Repeat the steps to enter alarm setting mode and press the Settings button (⚙️) until the alarm icon disappears.

# OPERATING INSTRUCTIONS

---

## 1. Bluetooth Pairing

1. Ensure the alarm clock is powered on.
2. The device will automatically enter Bluetooth pairing mode, indicated by a flashing Bluetooth icon on the display.
3. On your smartphone or other Bluetooth-enabled device, enable Bluetooth and search for available devices.
4. Select "Funky Vibes" (or similar name) from the list of devices.
5. Once paired, the Bluetooth icon on the alarm clock's display will stop flashing and remain solid. You can now play audio through the speaker.

## 2. Playing Music

- After successful Bluetooth pairing, start playing music on your connected device.
- Audio will be streamed through the alarm clock's speaker.

### 3. Adjusting Volume

- Volume can be adjusted directly from your connected Bluetooth device.
- Alternatively, use the Up (▲) and Down (▼) buttons on the alarm clock to control the speaker volume.

### 4. Snooze Function

- When the alarm sounds, short press any button (except the Power button) to activate the snooze function. The alarm will temporarily stop and sound again after a set interval (typically 5-10 minutes).
- To turn off the alarm completely, press and hold the Power button (U) or follow the alarm deactivation steps in the Setup section.

### 5. Display Brightness

- Short press the Power button (U) while the device is on to cycle through different display brightness levels.

## MAINTENANCE

---

### Cleaning

- Ensure the device is powered off and disconnected from any power source before cleaning.
- Wipe the exterior with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays.

### Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- If storing the device for an extended period, charge it to about 50% and recharge every few months.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the device using the USB Type-C cable.
Cannot pair via Bluetooth.	Bluetooth not enabled on source device. Device too far from source.	Ensure Bluetooth is on. Move devices closer (within 10 meters). Restart both devices.
No sound from speaker.	Volume too low. Device not paired.	Increase volume on both the alarm clock and the connected device. Ensure successful Bluetooth pairing.
Alarm does not sound.	Alarm not set or deactivated.	Verify alarm settings and ensure the alarm icon is visible on the display.

## SPECIFICATIONS

---

- **Model:** KA6060PU
- **Material:** Engineered Wood (MDF)
- **Dimensions (L x W x H):** 9.5 cm x 6.5 cm x 11.5 cm
- **Weight:** 0.36 kg
- **Power Supply:** DC 5V--1A
- **Bluetooth Version:** V5.0
- **Wireless Transmission Distance:** Up to 10 meters
- **Rechargeable Battery Type:** 18650
- **Rechargeable Battery Capacity:** 1200 mAh, 4.44 Wh
- **Rechargeable Battery Voltage:** 3.7 V
- **Charging Time:** 5 to 6 hours
- **Display Type:** Digital
- **Features:** Alarm Clock, Bluetooth Speaker
- **Included:** USB Type-C Cable (1 meter)
- **Indoor/Outdoor Use:** Indoor
- **Country of Origin:** China

## WARRANTY INFORMATION

---

This Karlsson Funky Vibes Alarm Clock with Bluetooth Speaker (Model: KA6060PU) comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

## SUPPORT

---

For further assistance, technical support, or warranty inquiries, please contact your retailer or visit the official Karlsson website. You can find more information and contact details on the [Karlsson Brand Store](#).